DSR-20MD/20MDP

SERVICE MANUAL





Photo: DSR-20MD

US Model Canadian Model DSR-20MD

AEP Model Australian Model New Zealand Model DSR-20MDP

E MECHANISM

SPECIFICATIONS

System

Recording format DVCAM format

Video signal

DSR-20MD: EIA STANDARD, NTSC color.

system

DSR-20MDP: CCIR STANDARD, PAL colour

system

Usable cassettes Standard-DVCAM cassettes and

Mini-DVCAM cassettes

Recording time 184 minutes (when using the PDV-

184ME cassette)

40 minutes (when using the PDVM-40ME cassette)

Clack

Quartz locked

DSR-20MD: 12-hour cycle display DSR-20MDP:

Power back-up

24-hour cycle display

Built-in self-charging capacitor

Back-up duration: up to about 100

hours

(After 8-hour charges)

inputs and outputs

Video input

BNC connector

Input signal: 1 Vp-p

(75 ohms unbalanced) BNC connector

Video output

Output signal: 1 Vp-p (75 ohms unbalanced)

S video input

Mini DIN 4-pin

Luminance signal: 1 Vp-p

(75 ohms unbalanced) Chrominance signal:

0.286 Vp-p (DSR-20MD) 0.3 Vp-p (DSR-20MDP) (75 ohms unbalanced)

S video output Mini DIN 4-pin

Luminance signal: 1 Vp-p (75 ohms unbalanced)

Chrominance signal:

0.286 Vp-p (DSR-20MD)

0.3 Vp-p (DSR-20MDP)

(75 ohms unbalanced) Audio input Phono jack (L, R)

Input level: 2 Vrms (full bit)

Input impedance: more than

47 kohms

Phono jack (L, R) Audio output

Output level: 2 Vrms (full bit)

Output impedance: less than

10 kohms

Monitor output **BNC** connector

Output signal: 1 Vp-p (75 ohms unbalanced)

Stereo minijack (1) Control S input

For the optional DSRM-10 Remote

Control Unit

Foot switch input Stereo minijack (1)

For the optional Foot Switch

LANC input/output

Stereo mini-mini jack (1)

For the optional RM-95 Remote

Commander

- Continued on next page -

DVCAM

DIGITAL VIDEO CASSETTE RECORDER



SONY

RS-232C input/output

D-sub 9-pin connector (1) Output: 3 kilohms at load Typ ±9V

Input: 5 kilohms at load High level 5 to 15V Low level -5 to -15V

Headphones output

Stereo minijack (1)

DV input/output 4-pin jack (1)

General

Power requirements

120 V AC, 60 Hz DSR-20MD:

12 V DC, 2.0 A (4.0 A at the peak) DSR-20MDP: 220-240 V AC, 50 Hz

12 V DC, 2.0 A (4.0 A at the peak)

Power consumption

0.45 A at 77°F, 120 V AC, 60 Hz DSR-20MD:

(during playback)
DSR-20MDP: 0.35 A at 25°C, 220 – 240 V AC,

50 Hz (during playback)

Operating temperature

5°C to 40°C (41°F to 104°F)

Storage and transport temperature

-20°C to +60°C (-4°F to +140°F)

Operating humidity


20% to 80%

Storage and transport humidity

20% to 80%

Dimensions

Approx. 212 × 98 × 395 mm (8 % × 3 % × 15 % inches) (w/h/d, including projecting parts and controls)



Mass

Approx. 5 kg (11 lb.)

Supplied accessories

Remote commander (1) Size AA (R6) batteries (2) AC power cord (1) Cleaning cassette (1)

Instructions for Use (1)

Design and specifications are subject to change without notice.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK A OR DOTTED LINE WITH MARK A ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUB-LISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!


LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE A SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COM-POSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

SAFETY CHECK-OUT

(US Model only)

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

- Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
- 2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
- Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
- Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
- 5. Check the line cord for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
- 6. Check the B+ voltage to see it is at the values specified.
- Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.



LEAKAGE TEST


The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

- A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
- 2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
- 3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75V, so analog meters must have an accurate lowvoltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)

SERVICE NOTE

Note for Repair

Make sure that the flat cable and flexible board are not cracked or bent at the terminal. Do not insert the cable insufficiently nor crookedly.



Cut and remove the part of gilt which comes off at the point. (Take care that there are some pieces of gilt left inside)




TABLE OF CONTENTS

<u>Sect</u>	ion <u>Title</u>	<u>Page</u>	Section	<u>Title</u> <u>P</u> a	ag
SER	/ICE NOTE	4	•		83
			•	VA-102 (HI MICOM) Schematic Diagram 4-	86
	•		•	RS-78 Printed Wiring Board 4-	89
1.	GENERAL		•	RS-78, VA-102 (RS MICOM)	
				Schematic Diagram 4-	89
	ıres		•	MD-63, MD-64, MD-65, FP-406	
	s on Video Cassettes			Printed Wiring Boards 4-	94
Note	s on Recording /Playback	1-1	•	MD-63, MD-64, MD-65, FP-406	
	tion and Function of Parts			Schematic Diagram 4-	
	pack		•	HP-100 Printed Wiring Board4-	
	ections for Playback		•	HP-100 Schematic Diagram4-	
	ngs for Playback		•	CM-56 Printed Wiring Board4-	
Playb	eack Procedure	1-4	•	CM-56 Schematic Diagram 4-	
Playb	ack Functions	1-5	•	FR-136 Printed Wiring Board 4-	
	rding		•	FR-136 Schematic Diagram 4-	
	ections for Recording		•	HG-1 Printed Wiring Board4-	
Settir	ngs for Recording	1-7	•	HG-1 Schematic Diagram 4-	
Reco	rding Procedure	1-7	•	U-1 Printed Wiring Board 4-	
	ging Menu Settings		•	U-1 Schematic Diagram 4-	
	ging the SET UP MENU Settings		•	U-2 Printed Wiring Board 4-	
Menu	Contents	1-8	•	U-2 Schematic Diagram 4-	12
Alarr	n Messages	1-9			
	bleshooting			·	
Note	s on Use	1-9	5. A	DJUSTMENTS	
			5-1. M	ECHANICAL SECTION ADJUSTMENTS 5-	1
2.	DISASSEMBLY			Information 5-	
			1-1. H	ow to Search Reference Pages for Removal 5-	1
2-1.	Removal of Upper Case	2-1		hase Adjustment Mark " PH- " 5-	
2-2.	Removal of Front Panel Assembly		5-1-2.	Preparation for Mechanical Check,	
2-3.	Removal of VA-102 Board			Adjustment and Maintenance 5-	2
2-4.	Removal of Power Block	2-1	2-1.	FL Block Assembly 5-:	2
2-5.	Removal of MD Block Assembly		2-2.	Cassette Positions 5-/	2
2-6.	Removal of CM-56 Board		2-3.	Loading/Unloading 5-	3
2-7.	Removal of JC-19 Board		2-4.	Manual Up/Down the FL Block 5-5	
2-8.	Removal of RP-228 Board		2-5.	Service Jigs List 5-	
2-9.	Circuit Boards Location		5-1-3.		
_ 0.	Official Boardo Ecoation IIII		3-1.	Phase Adjustment	
			- 1:	(Loading/Unloading Driving Section) 5-	6
3.	BLOCK DIAGRAMS		3-2,	Phase Adjustment	
J.	DECOR DIAGNAMO			(S/L Cassette Selection Section) 5-	8
2 1	Overall Block Diagram 1	2_1	3-3.	Phase Adjustment	
3-1.				(Mechanism Chassis Upper Surface Parts) 5-	10
3-2.	Overall Block Diagram 2 Overall Block Diagram 3		5-1-4.		
3-3.	Overall Block Diagram 3	3-8	4-1.	Cleaning of Rotary Drum Assembly 5-	
			4-2.	Cleaning of Tape Path System 5-	
	PRINTED WIRING POARDO AND		4-3.	Periodic Checks	
4.	PRINTED WIRING BOARDS AND		5-1-5.	Mechanism Section Checks and Replacements 5-	
	SCHEMATIC DIAGRAMS		5-1.	Tape Stopper, Motor FPC Assembly and	
			J-1.	Elastic Connector 5-	11
4-1.	Frame Schematic Diagram		5-2.	Drum Assembly and Drum Base 5-	
4-2.	Printed Wiring Boards and Schematic Diagrams		5-2. 5-3.	LM Cover, LM Worm Wheel, LM Holder and	+
	RP-228 Printed Wiring Board	4-5	5-5.	LM Motor Assembly 5-	15
	RP-228 Schematic Diagram	4-9	E 1	TG3/4 Catcher Block Assembly.	15
	JC-19 Printed Wiring Board		5-4.		4 -
	JC-19 (AD/DA CONVERTER)			Pinch Driving Gear and TC Arm Assembly 5-	15
	Schematic Diagram	4-19	5-5.	Pinch Arm Assembly, Pinch Limiter and	
	JC-19 (S1 AFC) Schematic Diagram			Tension Coil Spring (Pinch) 5-	16
	JC-19 (U1) Schematic Diagram		5-6.	HC Arm, HC Roller Assembly,	
	JC-19 (D1) Schematic Diagram			Pinch Retainer, Pinch Cam Gear and	
	JC-19 (C1 SPCON) Schematic Diagram			TG5/6 Catcher Block Assembly 5-	
	JC-19 (MODE) Schematic Diagram		5-7.	RL Arm and RL Link 5-	
	JC-19 (DV IN/OUT) Schematic Diagram		5-8.	Gooseneck Guard and Gooseneck Arm Assembly 5-	17
	JC-19 (AUDIO CORE) Schematic Diagram		5-9.	Tension Coil Spring (TG2), Spring Adjustor,	
	JC-19 (DIGITAL AUDIO) Schematic Diagram			TG2 Spring Hook, TG2 Selection Arm and Damper	
	• JC-19 (AUDIO D/A, A/D CONVERTER)	T-00		Sheet 5-1	18
	Schematic Diagram	4-59	5-10.	Tension Coil Spring (TG7), Spring Adjustor and	
	RE-32 Printed Wiring Boards			TG7 Spring Hook 5-	
	RE-32 Schematic Diagram		5-11.	TG2 Retainer, TG2 Arm Assembly (TG2 Plate Spring	
	VA-102 Printed Wiring Board	1-0Z		and ET Magnet), S Tension Regulator Band Assembly	y
				and TG2 Load Arm Assembly 5-	19
	VA-102 (IF) Schematic Diagram VA-102 (VIDEO IN) Schematic Diagram		5-12.	TG7 Retainer, TG7 Arm Assembly (TG7 Plate Spring	
	VICTOR (VIDEO III) CONSTITUTE Plagram			and ET Magnet), T Tension Regulator Band Assembly	
	VA-102 (VIDEO OUT) Schematic Diagram			and TG7 Load Arm Assembly 5-2	
	VA-102 (UVIC, DV IN/OUT) Schematic Diagram VA-102 (MONITOR OUT) Schematic Diagram	4-79	5-13.		

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
5-14.	T Reel Holder and T Reel Table Block Assembly	5-22 5-22	1.	Power Supply Voltage Check, Power Block (U-2 Board)	5-62
5-15.	S Reel Plate Assembly T Reel Plate Assembly	5-22 5-24	2.	Video/Audio Block Power Supply Voltage Check,	0 02
5-16.	TG1/8 Base Assembly, S Brake and T Ratchet		~ ·	Power Block (U-2 Board)	5-62
5-17.	TG3/6 Roller Assembly and TG3/6 Lock Spring		3-3. Sv	stem Control System Adjustment	
5-18 5-19.	FL Joint Gear, TG5/6 Retainer and	J-20	1.	Initializing the C, D, E Page Data	
5-19.	Capstan Motor	5-26	2.	Input of C Page Initial Data	
E 00	FL Selection Arm, FL Relay Gear and FL Joint Arm	J-20 1	3.	Input of D Page Initial Data	
5-20.	Assembly	ı 5-97	3. 4.	Input of E Page Initial Data	5-63
E 04	Assembly		5.	Modification of C, D, E Page Data	5-63
5-21.	Rotary Switch, TC Gear and Relay Gear		5. 6.	Page C Address List	5-64
5-22.	GL Arm Retainer and GL Arm		7.	Page D Address List	
5-23.	M Slider and M Slider Arm	5-20	7. 8.	Page E Address List	
5-24.	TG7 Selection Arm, TG7 Cam Gear and T Cam Gear	5-28			
5-25.	Main Cam, TG2 SL Arm Assembly and			ervo System Adjustments	5-00
	Tension Coil Spring (TG2 SL)	5-29	1.	Switching Position Adjustment (CM-56 Board)	
5-26.	TG3/4 Arm Block Assembly (TG3/4 Arm Assembly		2.	Capstan FG Duty Adjustment (CM-56 Board)	
	TG3/4 Limiter Spring and TG3/4 Gear), TG3/4 Bas			deo System Adjustments	
	Block Assembly (TG3/4 Base Assembly)			RP-228 Board Adjustments	
5-27.	TG5/6 Arm Block Assembly (TG5/6 Arm Assembly	,	1.	Recording Current Adjustment (RP-228 Board)	
	TG5/6 Limiter Spring and TG5/6 Gear), TG5/6		2.	PLL fo Adjustment (RP-228 Board)	
	Base Block Assembly (TG5/6 Base Assembly)		3.	CLK Delay Adjustment (RP-228 Board)	5-68
5-28.	Reel Motor		<u>4</u> .	AGC Center Level Adjustment (RP-228 Board)	
5-29.	RS Arm Assembly	5-34	5.	AEQ Adjustment (RP-228 Board)	5-69
5-30.	RS Gear Assembly, Mic Press Spring and		6.	PLL Capture Range Adjustment	
	Mic Lever	5-34		(RP-228 Board)	
5-31.	Rack Joint Gear, Rack Holder, Mic Holder,		7.	IC774 41.85 MHz VCO Check (RP-228 Board)	
	Rack (LC) and Rack (SC)		3-5-2.	JC-19 Board Adjustments	5-71
5-32.	Plate Link Assembly	5-36	1.	A/D Converter Reference Voltage Adjustment 1	
5-33.	Roller Shaft Assembly and Roller Belt	5-38		(JC-19 Board)	5-71
5-34.	Lid Opener	5-39	2.	A/D Converter Reference Voltage Adjustment 2	
5-35.	C Door	5-40		(JC-19 Board)	5-71
5-36.	Damper Arm and Tension Spring (DB)	5-40	3.	Y Signal Clamp Reference Voltage Adjustment	
5-37.	Gear (A), Gear (B), and C Worm	5-40		(JC-19 Board)	5-71
5-38.	Tension Coil Spring (HS), Tension (DB), Shift Plate Spring and C Sloat Block Assembly)	4.	CR Signal Clamp Reference Voltage Adjustment (JC-19 Board)	5-71
5-1-6.	Adjustments and Checks		5.	CB Signal Clamp Reference Voltage Adjustment	
6-1.	Adjustment Position		0.	(JC-19 Board)	5-71
6-2.	Adjustment Order		6.	Playback Y Signal Level Adjustment	
6-3.	Adjustment and Checking Method		-	(JC-19 Board)	5-72
6-3-1.	Reel Table Height Adjustment		7.	Playback CR Signal Level Adjustment	
6-3-2.	TG2/TG7 Height Adjustment			(JC-19 Board)	5-72
6-3-3.	FWD/RVS Position Adjustment	5-45	8.	Playback CB Signal Level Adjustment	
6-3-4.	TG2/TG7 Electric Tension Regulator Adjustment	5-46		(JC-19 Board)	5-73
	FWD/RVS Back Tension Adjustment	5-48	9.	IC422 27MHz XTAL fo Adjustment (JC-19 Board)	
	Adjustment Preparations and	0 .0	10.	AFC Preliminary Adjustment (JC-19 Board)	5-73
0-3-0.	RF Waveform Check	5-40	11.	AFC Picture Frame Adjustment (JC-19 Board)	
607		5-50	12.	AFC Adjustment (JC-19 Board)	
6-3-7.			3-5-3.		5-75
6-3-8.	Tracking Check	5.50	1.	AGC Adjustment (VA-102 Board)	5-75
	CUE and REV Check			Analog E-E VIDEO Signal Output Level	
6-3-10	. Rising Check	5-53	2.	Adjustment (VA-102 Board)	575
6-3-11	. Tape Path Check	5-54	•	Analog E-E Y Signal Output Level Check	0.0
			3.		5.76
5-2. S	ERVICE MODE	5-55		(VA-102 Board)	3-70
5-2-1.	Adjusting Remote Commander	5-55	4.	Analog E-E Chroma Signal Output Level Check	5.76
1.	Used Adjustment Remote Commander	5-55	-	(VA-102 Board)	
2.	Precautions Upon Using The Adjusting Remote		5.	Decoder VXO Freerunning Frequency Adjustment	
	Commander		_ ''	(VA-102 Board)	5-77
5-2-2.	Data Processing	5-56	6.	Video Input Y/C Separation Adjustment	c
5-2-3.	Service Mode	5-57	_	(VA-102 Board)	5-77
1.	Emergence Memory Address	5-57	7.	Decoder HUE Adjustment (VA-102 Board)	5-78
1-1.	EMG Code (Emergency Code)	5-57	8.	REC Y Level Adjustment (VA-102 Board)	5-79
			9.	REC CR Level Adjustment (VA-102 Board)	5-79
5-3. VI	DEO SECTION ADJUSTMENTS	5-58	10.	REC CB Level Adjustment (VA-102 Board)	5-80
3-1. Pi	reparations Before Adjustment		11.	Encoder Freerunning Frequency Adjustment	
3-1-1.	Equipment Used	5-58		(VA-102 Board)	5-80
3-1-2.	Connection of Equipment	5-58	12.	Playback Y Level Check (VA-102 Board)	5-80
3-1-3	Adjusting Connectors (RP 228 Board CN775)	5-59	13.	Playback Chroma Level Adjustment	
3-1-4.	Checking the Input Signals	5-60		(VA-102 Board)	5-81
1.	S Video Input		14.	Playback Burst Level Adjustment (VA-102 Board)	
2.	Video Input			(PAL Model Only)	5-81
	Alignment Tapes		3-5-4.	General Adjustment	5-82
3-1-6	Input/Output Level and Impedance	5-62	1.	Y Output Level Adjustment (JC-19 Board)	5-82
3-2. Po	ower Supply System Adjustment	5-62			

<u>Section</u>	<u>Title</u>	<u>Page</u>
2.	Encoder R-Y Input Level Adjustment	
۷.	(JC-19 Board)	5-82
3.	Encoder B-Y Input Level Adjustment	
	(JC-19 Board)	5-83
4.	Decoder HUE Input Adjustment (JC-19 Board)	5-83
5.	Battery Down Adjustment and Confirmation	
3-5-5.	BIST Check	5-85
1.	Playback System Check (JC-19, RP-228 Boards)	5.05
2.	Record System Check	5-86
	dio System Adjustments	
1.	Playback Level/Indicator Check	5-87
2.	E-E Level Check	
3.	Recording/Playback Check (Audio Lock Mode)	5-87
3-7. Arı	rangement Diagram for Adjustment Parts	5-88
6. RI	EPAIR PARTS LIST	
6-1. Ex	ploded Views	6-1
6-1-1.	Overall Assembly	6-1
6-1-2.	Chassis Assembly	
6-1-3.	MD Block Assembly	
6-1-4. 6-1-5.	FL Cassette Compartment Assembly Mechanism Chassis Assembly (1)	6-4
6-1-5.	(Top Side View (1))	6-5
6-1-6.	Mechanism Chassis Assembly (2)	
•	(Top Side View (2))	6-6
6-1-7.	Mechanism Chassis Assembly (3)	
	(Top Side View (3))	6-7
6-1-8.	Mechanism Chassis Assembly (4)	6.0
6-1-9.	(Bottom Side View (1)) Mechanism Chassis Assembly (5)	0-0
o-1-9.	(Bottom Side View (2))	6-9
6-2. Ele	ectrical Parts List	6-10
	e List	



Features

The DSR-20MD/20MDP is a 1/4-inch digital video The DSR-20MD/20MDP is a \(\frac{1}{\text{inth}}\) digital video cassette recorder that uses the DVCAM digital recording format. This system achieves stable, superb picture quality by digitally processing video signals that are separated into color difference signals and luminance signals (component video). The unit is equipped with a full-fledged analog interface to support hybrid systems that combine conventional analog equipment with digital equipment,

The DSR-20MD/20MDP's main features are described

DVCAM Format

DVCAM is based on the consumer DV format, which uses the 4:1:1 component digital format (DSR-20MD) or the 4:2:0 format (DSR-20MDP), and provides a V-inch digital recording format for professional use.

High picture quality, high stability

Video signals are separated into color difference Video signals are separated into corr difference signals and luminance signals, which are encoded and compressed to one-fifth size before being recorded to ensure stable and superb picture quality. Because the recording is digital, multi-generation dubbing can be performed with virtually no deterioration of quality.

Wide track pitch

The recording track pitch is 15 µm, fully 50 percent wider than the DV format's 10 µm track pitch. Thanks to this feature, the DV CAM format sufficiently meets the cellability and precision requirements of professional editing.

High-quality PCM digital audio

PCM recording makes for a wide dynamic range and a high signal-to-noise ratio, thereby enhancing sound quality.

There are two recording modes: 2-channel mode

note are two recording modes: 2-channel mode (48 kHz sampling and 16-bit linear code), which offers sound quality equivalent to the DAT (Digital Audio Tape) format, or 4-channel mode (32 kHz sampling and 12-bit nonlinear code).

Playback compatibility with DV format

A DV cassette recorded on a DV-format VCR can be played back on this unit. (Cassettes recorded in LP mode cannot be played back.)

Choice of two cassette sizes

- The unit can use both standard-size and mini-size DVCAM cassettes.

 -According to cassette size, it automatically changes the position of the real drive plate.

 -The maximum recording/playback times are 184 minutes for standard size cassettes and 40 minutes for mini-size cassettes.

Other Features

Compact size

The unit achieves compact size suitable for using on a demonstration. The unit is also equipped with basic functions that are needed for videocassette recorders and players used in professional digital video editing systems.

- DC IN connector

The unit is equipped with the --- DC IN connector to use in the case that the AC power is not available. Connect the optional BP-90A Ni-Cd Battery Pack with the battery adaptor and DC cable

Menu system for functionality and operation settings

The unit provides a menu system to make its various functions easier to use and set up its operation conditions.

Superimposition function

Time code, menus, error messages, and other text data can be superimposed and output in analog composite video signals.

Remote control

The unit can be operated by remote control from an editing controller that supports the RS-232C interface or from a SIRCS¹¹-system remote controller or foot switch such as the optional DSRM-10 or SVRM-100A.

SIRCS
 SIRCS-system has the same function as CONTROL S-system.

Checter 1 Overview 30

Features

Notes on Video Cassettes

Usable cassettes

Uso Standard-DVCAM cassettes or Minl-DVCAM cassettes with this VCR. PDV-184ME can record programs for 184 minutes and PDVM-40ME can record for 40 minutes. You can get the highest quality pictures with this digital video cassette recorder using DVCAM cassettes. You rany not be able to get as good quality with other cassettes. We recommend using DVCAM cassettes so that you can record your one-time events in highest quality.






Cassette memory

Cassette memory is an optional feature that is mounted on some Standard DVCAM cassettes and Mini DVCAM cassettes. When you record a program, the recording date and time, and the program's position on the tape are stored in the cassette memory so that you can quickly locate the program later on. Chrisk indicates that you can use the cassettes 16 kbits of data can be stored on. On this VCR, you can use the cassettes up to 16 kbits of data can be mounted on.

To save a recording

To prevent accidental erasure of a recording, slide in the safety switch on the cassette so that the red portion becomes visible. To record on a tape, slide out the switch so that the red portion is hidden.




Note

DVCAMI, DY, "DY and CI'll are trademarks.

Checking the tape for slack

Using a paper clip or a similar object, turn the reel gently in the direction shown by the arrow. If the reel does not move, there is no stack, insert the cassette into the cassette compartment, and after about 10 seconds take it



Notes on Recording / Playback

Copyright precautions

On recording
You cannot record any software having copyright protection signals on
this VCR. If you start recording protected video and audio signals, a
warning message appears on the monitor screen and the VCR stops
recording.
On playback
When you play back software having copyright protection signals on this
VCR, you may not be able to copy it onto other equipment.

Limitations caused by the difference in format

This VCR can record, play back and edit the tapes recorded in DVCAM format. It can also play back the tapes recorded in DV format (SP mode). However, due to the difference in format, you may not be able to record or edit some tapes affected by recording conditions of the tape (e.g., A tape originally recorded in DV format is dubbed in DVCAM format). For details, refer to "Compatibility of DVCAM and DV format" on page 42.

No compensation for contents of the recording

Contents of the recording cannot be compensated for if recording or playback is not made due to a malfunction of the VCR, video tape, etc.

You cannot play back a DVCAM tape recorded in other color systems on this VCR.

Chapter 1 Overview 5⁶⁸

O Cassette compariment

Accepts standard-size or mini-size DVCAM digital videocassettes. When using a mini-size cassette, insert it into the middle of the compartment, For details of usable cassettes, see page 4.

② C ON/STANDBY switch and ON/STANDBY lamp

lamp
Press this switch to turn on the power, and the ON/
STANDBY lamp lights in green. Press it again to turn
to standby mode, and the lamp goes off.

When the REMOTE/LOCAL switch is set to REMOTE, you cannot turn the unit to standby mode.

Remote sensor

nnect stereo headphones for headphone monitoring during recording or playback.

The audio signal you want to monitor can be selected

with the AUDIO MONITOR selector inside of the door (3).

Ø → PHONE LEVEL control knob Controls the volume of the headphones connected to the \(\Omega \) PHONES jack.

♠ AUDIO INPUT LEVEL control knobs When recording, you can use these knobs to set audio input levels for CH-1 (channel 1) and CH-2,


◆ COUNTER RESET button

Press this button to reset the tape counter in the display window to "0:00:00 (0:0000003)." This button does not work when displaying the time code or the remaining time.

⊕ EJECT button

Press this button to eject a cassette.

1 Display section



• Audio level meter Indicates the recording level during recording or BB modell and the playback level during playback. When the audio level exceeds 0 dB, the red indicator lights,

If you play back the tape whose audio was only recorded on channel 2, the audio level meter for CH2/4 may not function.

@ Time counter display

- Time counter display
 Indicates the following:
 Time data: count value of the time counter, time code and remaining time
 Alarm messages (see page 35)
 Messages for solf-diagnosis function (see page 39)

- For DSR-20MDP: Time code is set to the non drop
- frame mode only.

 Time code is indicated as follows:
 Drop frame: "00:00.00:00" ("00:00.00:00" on the monitor) (DSR-20MD only) Non drop frame: "00:00:00:00"

Video input signals indicators
Indicates the currently selected video input signals.
INPUT VIDEO, INPUT S VIDEO or INPUT DV

NS (Non Standard) AUDIO indicutor
Lights when the VCR plays back a tape whose audio recording was made in the unlock mode, or when unlock mode signals are input through the DV § jack.

For details of unlock mode, see page 42.

 Audio mode indicators Indicates the audio mode during playback or recording, or while in EE mode.

- During playback it indicates the audio mode in which was recorded.
- the tape was recorded.

 During recording or while in EE mode, it indicates
 the currently selected audio recording mode. You can
 select audio recording mode by setting "AUDIO
 MODE" menu (see page 33).

 F\$32k: Lights when playing the tapes recorded in
 4-channel mode, or recording a tope in 4-channel
 mode.
- mode. Fa48k: Lights when playing the tapes recorded in 2-channel mode, or recording a tape in 2-channel mode.

Note
When recording in 4-channel mode on this VCR, audio signals are recorded only in channels 1/2.

@ TIMER indicator Lights when setting the TIMER switch to REPEAT or REC.

O DVCAM indicator Lights except playing back the DV-formatted tapes.

1) EE mode EE mode
"EE" stands for "Electric to Electric". When in this mode, the video and sudio signals that are input to the VCR's
recording circuitry do not pass through any magnetic conversion circuits but instead are output via electric circuits only.
This mode is used to check input signals and adjust input levels.

Chapter 1 Overview 7^{at}


Location and Function of Parts

Cassette indicator

Lights when inserting a digital video cassette available for this VCR, It flashes when ejecting a cassette,

Mini indicator
Lights when inserting mini-size digital video cassette,

2 Tape transport control section



Tape Transport indicators

② DUP (duplicate) button
Use this button to make a work tape having the same
time code as the source tape.
For details of duplicate, see page 30.

REC (record) button

When you press the PLAY button while holding down this button, the indicator lights and recording begins. To set the VCR to recording pause mode, press the II PAUSE button while holding down this button.

II PAUSE button When you press this button, the indicator lights and the VCR is set to pause mode.

♠ ► F FWD (fast forward) button When you press this button, the indicator lights and the tape is fast forwarded. During fast forward, the picture does not appear on the monitor (you can see the picture of the EE mode during fast forward). To search forward, hold this button down during fast forward.

O > PLAY button

When you press this button, the indicator lights and playback begins. If you press this button while holding down the **
REW button during stop, the tape is rewound to its beginning and starts playing automatically (during rewind, the REW indicator lights and the PLAY indicator flashes),

② ◄< REW (rewind) button

When you press this button, the indicator lights and the


tape starts rewinding. During rewind, the picture does not appear on the monitor (you can see the picture of the EE mode during rewind).

To search backward, hold this button down during

If you press the PLAY button while holding do It you press the PLA1 button white nothing of this button during stop, the tape is rewound to its beginning and starts playing automatically (during rewind, the REW indicator lights and the PLAY

 $\underline{}=\underline{}$ vector. Press this button to stop the current tape transport operation.

3 Inside of the door



1 INPUT SELECT button

Select video input signals. Each press of this button cycles through three video signal selection options: video, S-video, and DV input. When you select one of these options, the corresponding indicator in the

O COUNTER SELECT selector

Select the type of time data in the time counter display.
TC: Time code
COUNTER: Count value of the time counter
TAPE REMAIN: Remaining time

 AUDIO MONITOR selector Use to select the audio track you want to hear when playing back a tape recorded in 4-channel mode (Fs32k).

Fs32k). CH-1/2: Channels 1/2 only MIX: Channels 1/2 and char CH-3/4: Channels 3/4 only

O TIMER selector

☼ TIMER selector
Uses to select timer recording or outo repeat using an external AC timer (not supplied).
REPEAT: When the power is supplied to this VCR, as uper tewfinds to its beginning automatically and playback starts. The VCR repeats the playback from the beginning to the first index (if there is no index on the tape, to the unrecorded portion; if no unrecorded portion, to the tape end). Auto repeat also functions if you set this selector to REPEAT during playback. during playback. OFF: Timer is released.

REC: When the power is supplied to this VCR, recording starts

@ REMOTE/LOCAL switch

➡ REMOTE/LOCAL switch Selects whether the unit is operated from its front panel or from external (remote) equipment. REMOTE: The unit is operated from an editing controller connected to the RS-232C 22 connector on the rear panel. No operation on the front panel works except sliding the switch or selectors. LOCAL: The unit is operated from its front panel, from an external equipment connected to the LANC e jeck on the rear panel, or from a SIRCS-system remote controller connected to the REMOTE 22 CONTROL S jack on the rear panel.

MENU button

Press this button to display the menu on the monitor screen. Press it again to return from the menu display to the usual display.

Note

If you set the REMOTE/LOCAL switch to REMOTE while the menu display is on the monitor, it returns to the usual display.

On how to use the menu, see Chapter 3 "Menu Settings."

SET button

Press this button to save selected menu items to the unit's memory.

Arrow (☆ ♣) buttons
Use these buttons to move around the menu items.

Chapter 1 Overview 968

8^{as} Chapter 1 Overview

O INPUT -o connectors

Input video and audio signals. To connect a VCR equipped with the S-video output jack, use the S VIDEO jack on this VCR.

OUTPUT & connectors

Output video and audio signals. To connect a VCR equipped with the S-video input jack, use the S VIDEO jack on this VCR.

MONITOR e- connectors
 Output video and audio signals for monitoring.

O SYNC switch

Selects the reference signal. The video signal is locked to V-syne or H-syne, but not locked to sub-career. The syne phase is not adjusted. The video signal is not locked to DV input.

locked to DV input.

INT: Selects the playback signal on this VCR as the reference signal.

EXT: Selects the input video signal from the external equipment connected to this VCR as the reference signal.

Notes

- The picture and the sound may be distorted if:

 You set the SYNC switch during playback.

 The enalog signal is input from the INPUT-oconnectors during playback with the SYNC switch set to EXT.
- If the SYNC switch is set to EXT during playback, the INPUT SELECT button does not work.

10^{as} Chapter I Overview

Chapter

@ REMOTE 121 CONTROL Sinck

Connect a SIRCS-system remote controller. When controlling this VCR from a remote controller such as the DSRM-10 or SVRM-100A (not supplied), connect the unit to the editing controller via this jack.

Note

SIRCS-system has the same function as CONTROL S-system.

© REMOTE 122 FOOT SWITCH ≥ jack
Connect the optional Foot Switch to control this VCR.

The Foot Switch must be conformed with Standard UL2601-1/EN60601-1,

For details on the Foot Switch, consult with authorized Sony dealers.

ALANC & lack

When you connect the LANC e jacks on this VCR and the other VCR, you can control this VCR (player) from the other VCR. The LANC connection transmits the other VCR. The LANC connection transmits signals such as control signals, time code and time counter data and status data.

You can control this VCR by connecting the optional RM-95 Remote Commander to this jack.

- The other VCR (recorder) receives the time code data from the LANC e jack only when this VCR (player) is set to show the time code indications.

 If the REMOTE/LOCAL switch is set to REMOTE,
- the LANC connection does not transmit signals
- © RS-232C 22 connector (D-sub 9-pin)
 Connect an editing controller or a personal computer with the RS-232C interface for remote-control of this VCR.

⊕ DV Ł Jack
 The DV Ł Jack is i.LINK compatible. Use when the equipment connected to the VCR has a DV ₺ jack. If you connect the VCR and the other equipment using DV ₺ jacks, you can minimize deterioration of picture quality during dubbing, editing or capturing still pictures into a personal computer by digital processing. For datalis, refer to the instruction manual of the equipment you use.

Note

L is a trademark of Sony Corporation and indicates

that this product is in agreement with IEEE1394-1995 specifications and their revisions.

Connect to an AC power outlet using the supplied power cord.

To see DC IN connector

Connect the optional BP-90A Ni-Cd Battery Pack with
the battery adaptor and DC cable.

- If the voltage of the Battery Pack falls less than 11 V, a beep sound is output (when BEEP in the menu is set to OFF, it is not output) and "dolo" appears in the display window. Replace the battery by a charged one or remove it to use the AC power outlet.

 If the voltage of the Battery Pack falls less than 10.5 V, a beep sound is output (when BEEP in the menu is set to OFF, it is not output) and the VCR is set to the standby mode. As you cannot turn on the VCR at this moment, replace the battery by a charged one or remove it to use the AC power outlet. one or remove it to use the AC power outlet.

Chapter 1 Overview 11 as

Location and Function of Parts

Supplied Remote Commander ° ● EJECT button O () Onistandby switch O COUNTER RESET O INPUT SELECT button DISPLAY bullon O DATA CODE butto SEARCH SELECT 0.0 8 Buttone for playing at warlovs speeds **8** PE PLAY E PLAY button **© ▶** FF button ® ■ STOP buller

- @ COUNTER RESET button
- **@** INPUT SELECT button
- SEARCH SELECT buttons ss these buttons to search for scones using the index Press those buttons to search for scenes using the int function.

 For details, see "Searching using the index function" on page 19.
- 12^{G8} Chapter 1 Overview

- 6 Buttons for playing at various speeds
- ®/⊕ buttons × 1/10 button
- × 1/5 button × 1 button

FRAME <11/11> buttons
For details, see "Playing at various speeds" on page 18.

6 II PAUSE button

- O > PLAY button @ 44 REW button
- O (On/standby switch

DISPLAY button

1 DATA CODE button

Press this button to see the indications, such as tape counter, on the monitor screen.

Press this button to see tape information on the monitor screen.
For details, see "Displaying tape information" on page 22.

Buttons for menu operation MENU button

SET button

⊕ REC buttons


When you press these buttons at the same time, the indicator lights and recording begins.

- @ STOP hutton


When using the supplied remote commander, set REMOTE CONTROL in the menu to VTR4 (see page 34). Otherwise, you cannot operate this VCR with the supplied remote commander.

Battery Installation


1 Push and slide the lid to open.



2 Install the two size AA (R6) batteries (supplied) with the correct polarity.



3 Replace the lid.



- Notes on batteries

 Make sure that the battery orientation is correct when
- inserting batteries.

 Do not mix an old battery with a new one, or
- different types of batteries.

 If you will not use the Remote Commander for a long time, remove the batteries to avoid damage from battery leakage. If batteries have leaked, remove them, whipe the batteries to compartment dry and replace the batteries with new ones.


Chapter 1 Overview 13⁶⁹

This section describes the necessary connections, settings and operations to perform playback on this unit. The same settings and operations apply whether you are using the unit as part of an editing system, for dubbing, or as a stand-alone videocassette player.

Connections for Playback

To digital video equipment with DV jack

The video and audio signals are sent with hardly any degradation, enabling high-quality editing. The signal flow is automatically detected so you need not make separate connections for input and output.




Solution 1. Set of the monut of the set of t

mode.
As for the LANC connection, see "Notes for LANC connection" on the

Chapter 2 Playback and Recording

To video equipment without DV Jack



- when you connect output lacks of the recorder to input jacks of this VCR, select the input correctly to prevent a humming noise. Distorted signals (e.g., when played back at a speed other than normal) will not be recorded properly. The indications displayed on the monitor screen are output only via the MONITIOR 6 connector.

Notes for LANC connection

- With the LANC connection, refer to the instruction for use supplied with the recorder VCR.

- With the LANC connection, refer to the instruction for use supplied with the recorder VCR.
 The LANC connection transmits signals such as control signals, time code, time counter data and status data.
 If the other VCR has a LANC © jack of 5-pin DIN type, connect with the VK-810 Control L connecting cable (not supplied).
 The jacks labeled CONTROL L have the same function as LANC © jacks. The jacks labeled REMOTE on other equipment may also have the same.
- Same.

 *The other VCR (recorder) receives the line code data from the LANC a jack only when this VCR (player) is set to show the time code indications.

 *With the LANC connection, this VCR only works as a slave unit.

Chapter 2 Playback and Recording 15^{GB}

Playback

Settings for Playback

Preparation on the player (this VCR)

- 1 Power on the video monitor, then set the monitor's input according to the input signals from the recorder.
- 2 Set up the recorder.
 For details, see "Preparation on the recorder" below.

A STATE OF THE STA

3 Power on this unit by pressing the ON/STANDBY switch.

The ON/STANDBY lamp lights in green.

- 4 If the other equipment that controls this VCR has the time code function, set the COUNTER SELECT selector to TC (see page 9).
- 5 When you play back a lape recorded in 4-channel mode (Pe 32k), set the AUDIO MONITOR selector to MIX (see page 9). Then select the precise balance between the tracks with the AUDIO MIX BALANCE in the menu (see page 33).

- With the DV connection, the playback VCR's AUDIO MONITOR (sound selection) and AUDIO MIX BALANCE (audio balance adjustment) do not function on the source audio output through the DV |
- adjustment) do not function on the source audio output through the DV B jack.

 *You cannot change the input signal selection during playback or playback pause mode.

Preparation on the recorder

- Insert a tape for recording.
 Select the formats of video and audio input signal to be recorded,
 Set the LANC mode to M.

Notes

• Editing is not possible with a tape that is copyright protected.
• You cannot use the video equipment that has no LANC mode switch as a


Playback Procedure

- When controlling this unit from an editing controller or a personal computer, set the REMOTE/LOCAL switch to REMOTE. When not, set the switch to LOCAL (See page 9).

 Do not insert the cassette forcibly, The VCR may be damaged.

After checking the tape for slack, hold the cassette so that the tape window is facing upward, then insert it into this unit as illustrated below.

For details of checking the tape for slack, see page 5.



2 Press > PLAY.

This starts the playback operation.

16⁸⁸ Chapter 2 Playback and Recording

hapter 2 Playback and Recording 17⁰⁸

Chapter 2 Playback and Recording 19^{db}

Searching using the index function

Playback Functions

Playback

Playing at various speeds

You can enjoy playback functions using supplied remote comm

Playback options	Operation	
Play at 1/10 of normal speed	Press x 1/10 during playback	
Play at 1/5 of normal speed	Press x 1/5 during playback	
Play at normal speed	Press x 1 during playback	
Play at twice the normal speed	Press x 2 during playback	
Play frame by frame	Press FRAME <11//1> during pause.	

To hear the sound during playing at various speeds. If you want to hear the sound during playing at various speeds, set JOG WITH SOUND in the menu to ON (see page 33).

Three kinds of search are available on this VCR:

- Searching for the beginnings of recordings: Index search

- Searching for a point on the tape where the recorded date changes:
Date search

- Searching for scenes recorded in the photo mode with a digital
camcorder: Photo search

Searching with the cassette memory
If the tape has a cassette memory, the recordings are listed in the
chronologically in the order they were made. You can search using this

chronological list.

If the tape does not have a cassette memory, you cannot search for scenes in the chronological order.

1 Press SEARCH SELECT to select the search type: INDEX, DATE or PHOTO SEARCH.

The chronological list appears on the monitor screen



2 Press | or > to select a recording.

The VCR starts searching and when it locates the recording, begins playback. During Photo search, the VCR pauses.

18^{ga} Chapter 2 Playback and F

Playback

Searching without cassette memory
When you use a tape without a cassette memory, the VCR searches in the
order of the actual positions of the recordings, regardless of the setting of
CASSETTE MEMORY SEARCH in the mean.

When you use a tape with a cassotte memory, set CASSETTE MEMORY SEARCH in the menu to OFF (see page 34).

1 Press SEARCH SBLECT to select the search type.



2 Press I≪or ➤ repeatedly to locate the recording you want.

The VCR starts searching backwards or forwards until the index number comes to zeto, then plays back the recording. During Photo search, the VCR pauses.

How eignais are recorded

The VCR marks the tape when REC button is pressed.

There are three different signals for each search method, The type of signal recorded and where it is recorded (on the tape or in the cassette memory) depends on the video equipment used for recording, Please note that if the signals for certain search type are not recorded, you cannot do that type of

When you record with a Sony digital camcorder

Signals for	in cassette memory	On tape
Index search*	No	No
Date search	Yes	Yes
Photo search	Yes	Yes

When you record on this VCR

Signals for	in caseette memory	On tape	
Index search*	Yes	Yes	
Date search	No	Yes	
Photo search	No	No	

The signals for Index search are recorded when you start recording in stop mode.

When recording on this VCR, signals for index search do not have information on a day of the week.

About the cassette memory

•If you use a tape with dv mark, the cassette memory stores up to 135 index signals. (The number changes depending on the data size combination of index, date, and photo data stored on a tape.) This VCR is capable of storing and retrieving up to 16 kilss of cassette memory.

•To locate recordings whose signals are disabled to be stored in the cassette memory, or to locate recordings in order of their position on the tape, set CASSETTE MEMORY SEARCH in the menu to OFF (zee page 34). You can use the same procedure to search for a recording on a tape without cassette memory.

Notes

Exach program is indexed at its beginning. If you record another program over the beginning of the first program, you will not be able to locate the original program.

		rder	aign	el .	
-	Α	Ť	В	ပ	M D is recorded over the beginning of B
Ī		¥,) canno	t be searched
=	Α	D	В	С	

You cannot add indexes after recording.
To add indexes only for Auto Repeat, start recording from the point you want to start indexing.
You cannot emae indexes after recording.
To delete indexes for Auto Repeat, set INDEX WRITE in the ment to OFF (see page 34). Then record over the index signal you want to crase.
Searching may not be done correctly if the signals were not recorded on a Sony-brand digital video equipment.


20^{GB} Chapter 2 Playback and Re

Chapter 2 Playback and Recording 21 at

Displaying tape information

If you record on a tape using a Sony digital camcorder DSR-200/200P/ 200A/200A/PD100/PD100P/PD100A/P

Press DATA CODE during playback.
Each time you press DATA CODE, the display changes as follows.



Notes

- •When the information was not recorded, "---" appears instead.
 •The carneorder data displayed on the monitor screen by this VCR are partially different from those shown by the digital carneorder.

Auto Repeat

This VCR can repeat the playback of all or a part of the tape.

1 Set the TIMBR selector on the front panel to REPEAT.


The TIMER indicator on the front panel lights.

- 2 Press REW to rewind the tape to its beginning.
- 3 Press ➤ PLAY.

Playback starts automatically. The VCR repeats the playback from the beginning to the first index (if there is no index on the tape, to the unrecorded portion; if no unrecorded portion, to the tape end).

Auto Repeat using an external AC timer
If you connect an external AC timer (not supplied) to this VCR, you can repeat playback automatically at the preset time.

1 Connect an external AC timer (not supplied) to this VCR.



2 Set the TIMER selector on the front panel to REPEAT.

The TIMER indicator in the display window lights.

3 Set the timer-on time on the external AC timer.

At the preset time, the power turns on, and Auto Repeat playback starts automatically within one minute. The VCR repeats the playback from the beginning to the first index (if there is no index on the tape, to the unrecorded portion; if no unrecorded portion, to the tape end).

22^{GP} Chapter 2 Playback and Recording

Playback

- NAGIGE

 The VCR cannot search for an index or unrecorded portion within 20 seconds from the beginning of the tape.

 While a tape is running, do not turn off the power using an AC timer. The VCR and a tape may be damaged. When turning off the power of the VCR, make sure to press the \$\exists STOP button on this VCR first to stop the tape transport, then turn off the power.

To stop Auto Repeat Press the STOP button.

To release Auto Repeat mode Set the TIMER selector to OFF.

Chapter 2 Playback and Recording 23 gg


Recording

This section describes the necessary connections, acttings and operations to perform recording on this unit. The same settings and operations apply whether you are using the unit as part of an editing system, for dubbing, or as a stand-alone recorder.

Connections for Recording

To digital video equipment with DV jack

The video and audio signals are sent with hardly any degradation, enabling high-quality editing. The signal flow is automatically detected so you need not make separate connections for input and output.



Notes

- Audio signals are not output during playing at various speeds.
 With the DV connection, the sound is recorded in the same audio recording mode as that of the source tape. To record in a different sudio recording mode from the source tape, use the INPUT \bullet connectors
- instead.

 With the DV connection, tape information (recording date, camcorder data, etc.) recorded on the source tape is transmitted from the other VCR (player). As a result, when you play back a recorded upe and press the DATA CODE button, the same tape information recorded on the source tape is displayed on the mointor screen. However, contents of the cassette memory are not transmitted. In addition, the time code is newly recorded on the tape on this VCR, except when cepying a tape in Duplicate mode.

 As for the LANC connection, see "Notes for LANC connection" on the next page.

Chapter 2 Recording and Playback 25gs

Preparation on the recorder (this VCR)

Settings for Recording

- Before recording, set the clock on the VCR so that the recording time can be written into the index signal. You can set the clock by setting the CLOCK SET menu (see page 34).

 When controlling this unit from an editing controller or a personal computer connected to the RS-232C E2 connector, set the REMOTE/LOCAL switch to REMOTE. When not, set the switch to LOCAL (See page 9).

 Editing is not possible with a tape that is copyright protected.
- Power on the video monitor, then set the monitor's input according to the input signals from this unit.
- 2 Set up the player to play back a tape.

 For details, see "Preparation on the player" on the next page.
- 3 Power on this unit by pressing the ON/STANDBY switch.
 - The ON/STANDBY lamp lights in green.
- 4 Use the COUNTER SELECT selector to select the type of time data to

Type of time data	Set the selector to
Count value of the time counter	COUNTER
Time code	TC


5 Select the video and audio input signals to be recorded.

Press iNPUT SELECT to select the desired signal, Each press of this button cycles through three video signal selection options: video, S-video, and DV input. Each selection is shown by a lit indicator in the display window.

Once you have started recording, you cannot change the input signal selection (except during recording pause mode).

pter 2 Recording and Playback 27^{ca}

To video equipment without DV jack



Notes

- *When recording the analog input signals, this VCR can digitally output the signals from the DV b jack for backup. Set DV EB OUT in the menu to ON (see page 34).

 *When you connect output jacks of this VCR to input jacks of the player, select the input orrectly to prevent a humming noise.

 *Distorted signals (e.g., when played back at a speed other than normal) will not be recorded properly.

 The indications displayed on the monitor screen are output only via the MONITOR O- connector.

Notes for LANC connection

- · With the LANC connection, refer to the instruction for use supplied with the player VCR.

 The LANC connection transmits signals such as control signals, time

- The LANC connection transmits signals such as control signals, time code and time counter data and status data.

 If the other VCR has a LANC ♥ jack of 5-pin DIN type, connect with the VK.810 Control L connecting cable (not supplied).

 The jack labeled CONTROL L has the same function as LANC ♥ jacks. The jacks labeled REMOTE on other equipment may also have the same.

 This VCR (recorder) receives the time code data from the LANC ♥ jack only when the other VCR (player) is set to show the time code indications.

With the LANC connection, this VCR only works as a slave unit,

Recording

26 Chapter 2 Recording and Pla

6 When using the line connections (INPUT -o connectors), select the

Select the desired mode by setting the AUDIO MODE menu.

Audio mode	Set the menu to
2-channel mode	Fs48k
4-channel mode	Fs32k

On how to use the menu, see Chapter 3 "Menu Settings."

- be the DVCAM format, there are two audio recording modes, with either two channels at 48 kHz or four channels at 32 kHz. It is not possible to select other modes (for example with four channels at 48 kHz).
- .48 kHz).

 When recording in 4-channel mode on this VCR, audio signals are recorded only in channels 1/2.

 Once you have started recording, you cannot change the audio mode
- 7 Use the

 △ AUDIO INPUT LEVEL control knobs to adjust audio

Watching the audio level meter (see page 7), adjust the level so that the meter does not indicate higher values than 0 dB when the audio signal is at its maximum.

When the level exceeds 0 dB, sound distortion occurs.

With the DV connection, the recorder VCR's AUDIO MODE (sound selection) and
AUDIO INPUT LEVEL (audio balance adjustment) do not function.

Preparation on the player

- Insert a source tape.
 If the player VCR has an EDIT switch, set it to ON,
 Turn off the on-screen display.
 Set the LANC mode to M.

With the DV connection, the playback VCR's AUDIO MONITOR (sound selection) and AUDIO MIX BALANCE (audio balance adjustment) do no function on the source audio output through the DV & jack.

Recording Procedure

NOM

When controlling this unit from an editing controllor or a personal computer connected to the RS-232C 22 connector, set the REMOTE/
LOCAL switch to REMOTH. When not, set the switch to LOCAL (See page 9).

1 After checking that the cassette's safety switch is set to write enabled position and the tape for slack, hold the cassette so that the tape window is facing upward, then insert it into this unit.

For details of the cassene's safety switch, see page 4. For details of checking the tape for slack, see page 5.

The cassette is automatically drawn into the unit and the tape is wound round the head drum. The tape is stationary while the head drum

2 Press the playback button on the player.

This starts the player's playback operation.

3 Press and hold ● REC, and press ► PLAY.

This starts the recorder's recording operation.

To stop recording Press the ESTOP button.

To record using the optional Foot Switch

1 Press the pedal of the Foot Switch when the VCR is in stop mode. The VCR starts recording.

2 Press the pedal again.

The recording stops and the VCR goes into recording pause mode.

To stop recording
Press the ■ STOP button on the VCR.

- "You should set the REMOTE/LOCAL switch to REMOTE to prevent concurrent use of the foot switch and the from panel controls.

 "The beginning of the recording (for about two seconds) cannot be made. If you immediately start recording, press the pedal twice to go into recording pause mode, then start recording.

 "The Foot Switch must be conformed with Standard UL_2601-1/EN60601-1.

Chapter 2 Recording and Playback 29 as

28^{GB} Chapter 2 Recording and Playback

• The recording pause mode will be automatically released after five minutes to protect the tape, and the VCR goes into stop mode.
• The foot switch operation works even if the VCR is in any operation mode. To prevent accidental erasure of a recording, you should slide in the safety switch on the cassette so that the red portion becomes visible before you insert the cassette into this VCR.

Duplicate

If you copy a source tape, using the DUP (duplicate) button on this VCR, you can copy the time code recorded on the source tape as they are. You can easily make a work tape having the same time codes as the source

The duplicate function on this VCR works only when using a source tape recorded in DVCAM format and making DV connections.

- 1 Connect this VCR and the other (playback) VCR, using an i.LINK cable (DV connecting cable) (not supplied) and select DV with the INPUT SELECT selector on this VCR.
- 2 Locate the points where you want to start playback and recording.
- 3 Press STOP on this VCR to stop the tape transport operation.
- 4 Press and hold DUP on this VCR, and press > PLAY.

The DUP indicator flashes and this VCR enters into duplicate-standby mode,

- If the other (playback) VCR has already started playback, the DUP indicator lights and duplicate starts immediately, if the other (playback) VCR is in the playback passe mode, duplicate starts immediately and this VCR continues to record a still picture and a certain time code.
- **5** Press the play button on the other VCR to start playback.

The DUP indicator lights and duplicate starts.

To adjust the point where duplicate starts
In step 4 above, press and hold the DUP button instead of the ▶ PLAY
button, and press the #I PAUSE button. This VCR remains recording
standby mode until you press the #I PAUSE button again.

After the other VCR starts playback, press the #I PAUSE button at the
point where you want to start duplicate.


30° Chapter 2 Recording and Playbo

Recording

AC timer recording

By connecting this VCR to an external AC timer (not supplied), you can rt recording at a preset time.

1 Connect this VCR to an external AC timer (not supplied).



- 2 Insert a tape for recording.
- 3 Press INPUT SELECT to select the recording source.
- 4 Set the timer-on time on the con

At the preset time, the power of this VCR and the recording source turn on automatically and recording starts about several to 10 seconds later. Set the timer allowing a margin for the recording to start.

5 Set the TIMER selector at the front to REC.

You need not press ● REC.

If the tape ends before the recording source stops operation. The tape stops without rewinding. If you set AUTO REWIND in the menu to ON, the tape rewinds to its beginning automatically (see page 34).

To stop recording during the timer recording Press the **E** STOP button.

To release AC timer recording Set the TIMER selector to OFF.

While a tape is running, do not turn off the power using an AC timer. The VCR and a tape may be damaged. When turning off the power of the VCR, make sure to press the STOP button on this VCR first to stop the tape, then turn off the power.

Changing Menu Settings

This VCR has various functions available, and you can set and check them on the monitor screen. Before operation, set the clock by setting the CLOCK SET menu.

You can change the menu settings on the SET UP MENU screen.

If necessary, change the settings manually during editing, etc.

Changing the SET UP MENU Settings

Follow the instructions below to change the settings.

Notes

Notes:
During duplicate, do not change the speed of the player's tape or set it to
pause mode. Otherwise, the time code of the recorded tape becomes out
of sequence and you cannot use it for editing.
During duplicate, time counter does not appear. Check it in the other
VCR.

When you start duplicating, the first part of the source tape may be dropped on the copied tape. Play back the source tape from the preceding point. You cannot completely copy the tape if the source tape is recorded

point. You cannot completely copy the tape if the source tape is recorded from its beginning point.

- You may not be able to copy the first part or an unrecorded portion of the source tape. Locate the recorded portion on the source tape, then start copying.

- The recording does not stop the moment you press the III STOP button to stop editing. The source picture may be recorded a little longer than you expected.

stop change, are souther product may be rectored a many tonges and you expected.

If you duplicate a tape by using two DSR-20MD/20MDPs, set DV EB OUT in the menu of the player to OFF (see page 34).

The index signals are not recorded when the duplicate starts.

If you set the REMOTE/LOCAL switch to REMOTE during duplicate,

The SET UP MENU appears on the monitor screen. To cancel the menu settings, press MENU again.



2 Press 4 / 4 to select the option you want to change, and press SET.

Each menu option appears on the monitor screen (see the table below).

3 Press 4 to change the setting, and press SET.

The menu disappears from the monitor screen.

Menu Contents

Initial settings are indicated in bold letters

Menu options	Set this option to	Description of settings
AUDIO MIX BALANCE		If you set the AUDIO MONITOR selector to MIX, you can select the precise balance between channels 1/2 and channels 3/4 by the steps
AUDIO MODE	Fa48k Fa32k	• To set the sudio mode to 2-channel mode (19bit mode). This mode uses the whole such area to record one stereo track. You can get higher sound quality. • To set the sudio mode to 4-channel mode (12bit mode). This mode separates the sudio mode to 4-channel mode (12bit mode). This mode separates the sudio area tho two parts. You can record two kinds of sudio, stereo 1 and stereo 2. When recording on this VCR, sudio signals are recorded only in channels 1/2.
JOG WITH SOUND	OFF	To listen to the sound when playing a tape in various speeds. To turn off the sound when playing a tape in various speeds.

32⁶⁸ Chapter 2 Recarding and Fleyb

339

Menu Organization

Menu options	Set this option to	Description of settings
REMOTE CONTROL		Set the command mode (VTR1 to 6, INST) on this VCR. Change this setting when using infrared remote commander or external (remote) equipment to remotely control the unit. When using the supplied remote commander, select VTR4 (fulled setting), When using the remote controler such as the optional DSRM-10 or SVRM-100A, select INST, When selecting OFF, you cannot remotely control the unit.
RS232C BAUD RATE	9600bps 19200bps	To set the baud rate with an editing controller that supports RS-232C interface to 9800bps. To set the baud rate to 19200bps.
DISPLAY POSITION	CENTER LOWER RIGHT	To display the tape counter in the center of the monitor screen. To display the tape counter in the lower right of the monitor screen.
CAUTION DISPLAY	ON OFF	To display the alarm message on the monitor screen. Not to display the alarm message.
BEEP	ON OFF	To culput a beep sound when an illogical operation is made. To deactivate it.
INDEX WRITE	AUTO OFF	To record index signals when recording begins. Not to record index signals.
CASSETTE MEMORY SEARCH	AUTO OFF	To search recordings with the cassette memory. If the tape does not have a cassette memory, the VCR will search recordings using index signals recorded on the tape itself. To search recordings using the index signals recorded on the tape.
CASSETTE MEMORY ERASE	ALL DATA INDEX DATA DATE DATA PHOTO DATA	To erase all the data in the cassette memory. To erase index data in the cassette memory. To erase date data in the cassette memory. To erase date data in the cassette memory. To erase photo data in the cassette memory. ROTIO When using the cassette whose memory can store over 16 Kbits of data, you can only select ALL DATA. You cannot vase index data on the tape.
TIME CODE (DSR-28MD only)	NOF DF	- To set the time code to the same one as afreedy recorded on the tape To set the time code to Non Drop Frame To set the time code to Drop Trame.
AUTO OFF	ON OFF	To turn off the VCR automatically if there is no operation for an hour during stop mode (Auto Off). To descrivate Auto Off.
AUTO REWIND	ON OFF	*To rewind the tape to its beginning automatically if the tape reaches to an end (Auto Rewind). *To deactivate Auto Rewind.
РНОТО РВ	FIELD FRAME	To prevent the picture from blurring when playing a tape recorded in photo mode. To see clear picture when playing a still picture. Total the picture when playing a still picture. Total the picture recorded in photo mode may blur.
CLOCK SET		Sat the clock on this VCR so that the recording time can be written into the index signal. Using \$14\$ and SET buttons, set the date and time.
HOURS METER		The digital hours meter keeps cumulative counts of the head drum rotation time and the number of unthreading operations. These counts can be displayed on the monitor screen and are unresettable.
	DRUM ROTATION THREADING	 The cumulative total hours of drum rotation with tape threaded is displayed in 10-tour increments. The cumulative number of tape unthreading operation is displayed in 10-operation increments.
DV EE OUT	ON OFF	• To output the selected line input signals from the DV & jack. • To output only playback video and audio signals from the DV & jack.

Alarm Messages

Various messages appear on the monitor screen ("Err" appears in the display window). Check them with the

Message	Meaning / Remedy
PLEASE CONFIRM THE SAFETY SWITCH OF THE CASSETTE	Check that the protect tab is still in so that the red portion visible Slide back the safety switch (see page 4).
NO CASSETTE MEMORY	You try to erase cassette memory when there is no cassette memory.
VCR IS RECORDING	You press a certain operation button during recording or editing.
PLEASE INSERT A NEW CASSETTE	Though no cassette is inserted in the cassette compartment, you press > PLAY, etc Insert a cassette.
THE TAPE IS REWOUND	You press ◄◄ REW at the beginning of the tape.
PLEASE REWIND OR INSERT A NEW CASSETTE	You try to start playback or recording at the tape end. Rewind the tape or insert a new cassotte.
PLEASE SET THE CLOCK	When turning on the power, the clock has not been set, Set the clock in the menu (see page 34).
THIS PROGRAM IS COPYRIGHT PROTECTED	You try to dub the tape on which copyright protect signals are recorded.
CASSETTE MEMORY IS TOO LARGE TO ERASE	You try to erase "INDEX DATA," "DATE DATA," or "PHOTO DATA" on a tape having more than 18 Kbits memory capacity. → Erase "ALL DATA" on the tape (see page 34).
WRITING ON CASSETTE MEMORY, PLEASE WAIT	You do certain operation white the VCR is writing on caseste memory. — Operate after writing on cassatte memory is complete.
VCR IS IN DUP MODE	You press a certain operation button during duplicate.

Chapter 4 Maintenance and Troubleshooths 35°

Troubleshooting

If the VCR does not function or functions incorrectly, check the following.

Symptom	Cause / Remedy
The power cannot be turned on.	The power plug is disconnected Connect the plug.
The unit will not operate even if the power has been turned on.	 The REMOTE/LOCAL switch is set to REMOTE. → Set it to LOCAL (See page θ).
	Moleture condensation occurs. Turn of the power and disconnect the power plug. After about one minute, connect the plug and turn on the power. Wait for about one hour with the power turned on.
	 The cassette is not inserted straight. → Insert it straight.
The unit cannot be controlled using buttons on the unit.	The REMOTE/LOCAL switch is set to REMOTE. → Set it to LOCAL (See page 9).
The cassette cannot be ejected.	The REMOTE/LOCAL switch is set to REMOTE. → Set it to LOCAL (See page 9).
The cassette cannot be inserted, or it is ejected promptly.	There is moisture condensation on the head drum, Wait for about an hour. The caseste is not inserted straight Insert it straight.
No picture.	The video heads are dirty,— Clear the video heads using the cleaning cassette.
Noise appears on the screen.	A damaged casselle is inserted. → Insert other cassette. The video heads are dirty. → Clear the video heads using cleaning cassette.
No picture via the DV jack.	Reconnect an I.LINK cable (DV connecting cable) (not supplied).
The audio is noisy.	A damaged cassette is inserted, Insert other cassette.
The playback automatically starts when the power is turned on.	The TIMER selector is set to REPEAT Set it to OFF (See page 9).
The recording automatically starts when the power is turned on.	The TIMER selector is set to REC. → Set it to OFF (See page 9).
The remote commander does not function.	The batteries are dead. → Replace the batteries, Something is blocking the intered rays. → Remove the obstacle. The command mode is wrong. → Set up REMOTE CONTROL in the SET UP MENU (See page 34).
The menu does not appear,	Connect the video monitor to the MONITOR G- connector.

Notes on Use

Notes on the video cassette recorder

Do not install the unit in a place subject to direct sunlight or heat sources If you do, its cabinet, mechanical parts, etc., may be damaged.

Do not install the unit in an extremely hot place If the unit is left in a car parked with its windows closed (especially in summer), its cabinet may be damaged or it may not work correctly.

If the unit is brought directly from a cold to a warm

If the unit is brought directly from a cold to a warm location. Moisture may condense inside the unit and cause damage to the video head and tape. If you use the unit in a place subject to direct cold currents from an air conditioner, moisture may also condense inside the

Do not place a heavy objects on the unit The cabinet may be damaged, or the VCR may not work correctly.

Do not handle the recorder roughly Avoid rough handling or mechanical shock.

To avoid damaging the cabinet finish

Plastic is often used for the surface finishing of the
recorder. Do not spray a volatile solvent such as an
insecticide toward the cabinet or place rubber or vinyl products on the cabinet for a long time. If you do, the finish of the cabinet may be damaged or the coating may come off.

Do not clean the cabinet with thinner or benzine
The cabinet may be damaged or its coating may come
off. When you use a chemical-impregnated cloth, use
it according to its directions.

Clean the cabinet with soft dry cloth
When the cabinet is very dirty, clean it with a soft dry
cloth lightly moistened with a mild detergent solution
and finish it with dry cloth.

Do not put magnetic objects close to the unit Magnetic fields may damage the recording.

Checking the video heads every 1000 hours Checking the video heads every aloue hours A VCR is a high-precision piece of equipment that records and plays back the picture on a magnetic tape. In particular, the video head and other mechanical parts become dirty or worn. To maintain a clean picture, we recommend maintenance every 1000 hours, though the using condition may differ depending on temperature, humidity, dust, etc.

Cleaning of the video heads

If the video heads are contaminated, the pictures cannot be recorded properly or the playback pictures become noisy. If the following phenomena occur, use the cleaning casestie PDWA-12CL (supplied) or PDV-12CL (not supplied) to clean the heads.

- Square-shaped noise appears on the playback picture.

- A part of the playback picture does not move.

- The playback picture does not appear on the screen.

Symptoms caused by contaminated video heads







To use the cleaning cassette
Refer to your cleaning cassette's operating
instructions.

After prolonged use, the video heads may become worn out. If optimum picture quality is not restored even after you have cleamed the video heads with the cleaming cassette, the video heads may have worn out. In that case, you have to replace the video heads with new ones, Picase consult your Sony dealer.

36⁶⁸ Chapter 4 Maintenance and Troublushooking

Notes on the video cassettes

Cleaning the terminal
If the terminal of the Standard-DVCAM or MiniDVCAM cassette gets dirty, or dust sticks to the
terminal, the VCR may not work correctly.
Clean the terminal with the swab once every ten times you eject a cassette.



When affixing a label on the cassette
Be sure to affix a label on only the correct location so
as not to cause malfunction of the VCR.

After using a cassette
After use, please be sure to rewind the tape completely
(to prevent picture and sound distortion). Return it to
its case and store in upright position.

About moisture condensation

If the unit or tape is brought directly from a cold to a warm location, moisture may condense inside or outside the unit or tape. If you use the tape or video heads in this condition, the tape may adhere to the head drum, and the video heads or the tape may be damaged, or malfunction may occur.

Moisture condensation is likely to occur under the

- following conditions:

 The unit is brought from the cold outdoors to a warm indoor location.

 The unit is brought from the air-conditioned indoors
- to the hot outdoors.

 The unit is used in a place subject to cold currents

• The unit is used in a place subject to cold currents from an air conditioner.
When bringing the unit from a cold place to a warm place or vice versa, put it in a plastic bag and seal the bag tightly. After bringing it into the new place, leave the bag on for about an hour, and remove the bag when the air temperature inside it has reached the temperature surrounding it.

If moisture condensation occurred

at mossure condensation occurred
You cannot operate the unit except to press \(^{\text{\ti}}}\text{\texi{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\ti}\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\texi{\texi{\texi{\texi{\texi{\texi{\texi{\texi{\texi{\texi{\text{\texi{\texi}\texit{\text{\tet

Digital hours meter

The digital hours meter keeps cumulative counts of the head drum rotation time and the number of unthreading operations. These counts can be displayed on the monitor screen. Use them as guidelines for scheduling maintenance.

In general, consult your Sony dealer about necessary periodic maintenance checks.

The digital hours meter has the following two display modes and you can check them in the HOURS METER menu (see page 34).

- DRUM ROTATION mode
 The cumulative total hours of drum rotation with tage threaded is displayed in 10-hour increments.
 THREADING mode
 The cumulative number of tage unthreading operation is displayed in 10-operation increments.

Self-diagnosis function

The unit is equipped with the self-diagnosis function that works to prevent the VCR from malfunctioning. A two-digit service number appears in the display window. In this case, check the following table.

Message	Symptom	Remady
22	The video heads are dirty.	Clear the heads. (See page 38)
32	To prevent the unit from malfunctioning, the self-diagnosis function has worked.	Disconnect the power cord. After reinstalling the power source, operate the unit, Remove the cassette or lum on/off the unit.
21	Moisture condensation has occurred.	Remove the casselle and leave the unit for at least one hour.

If you are unable to resolve the problem, contact your Sony dealer or local authorized Sony service facility and inform them of the number.

 38^{as} Chapter 4 Makalanance and Troubleshooting


Chapter 4 Maintenance and Troubleshooting 3909

SECTION 2 DISASSEMBLY


Note: Follow the disassembly procedure in the numerical order given.

2-1. REMOVAL OF UPPER CASE


2-3. REMOVAL OF VA-102 BOARD




2-2. REMOVAL OF FRONT PANEL ASSEMBLY



2-4. REMOVAL OF POWER BLOCK




2-5. REMOVAL OF MD BLOCK ASSEMBLY 2-7. REMOVAL OF JC-19 BOARD




2-6. REMOVAL OF CM-56 BOARD

(CN003) (Flat cable (CN003) (CN002) (P3 × 6) (Three flat cables (CN005, 007, 008) (CN001, 006)

2-8. REMOVAL OF RP-228 BOARD




2-9. CIRCUIT BOARDS LOCATION







SECTION 3 BLOCK DIAGRAMS


3-1. OVERALL BLOCK DIAGRAM 1







3-2. OVERALL BLOCK DIAGRAM 2





3-3. OVERALL BLOCK DIAGRAM 3







SECTION 4
PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

4-1

SP1268 / Druck 7



4-2



DSR-20MD/20MDP

4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

RP-228 BOARD (SIDE A)

A-4 B-6 A-5

A-1 B-5 C-5

C-1 D-3 B-1 B-3 C-5

C-2 B-3 A-1 A-1 B-2 B-2 A-3 B-3

CN101 A-2

CN102 CN771

CN775

D772 D774


IC770 IC771 IC772 IC775 IC777

Q105 Q109 Q774 Q775 Q776 Q777

Q779 Q784

THIS NOTE IS COMMON FOR PRINTED WIRING **BOARDS AND SCHEMATIC DIAGRAMS.** (In addition to this, the necessary note is printed in each block) For printed wiring boards: : Pattern from the side which enables seeing. (The other layers' pattern are not indicated) Circled numbers refer to waveforms. Through hole is omitted.

- There are few cases that the part printed on diagram isn't mounted in this model.
- Chip parts.



For schematic Diagram:

- All capacitors are in μF unless otherwise noted. pF: μμF 50V or less are not indicated except for electrolytics and
- Chip resistors are $^{1}/_{10}\,W$ unless otherwise noted. $k\Omega$: $1000\Omega,\,M\Omega$: $1000k\Omega.$
- Caution when replacing chip parts.
- New parts must be attached after removal of chip. Be careful not to heat the minus side of tantalum capacitor, because it is damaged by the heat.
- Some chip part will be indicated as follows.

Example	C 541	L 452
	22U	10UH
	TA A	<u>2520</u>
Kinds of capacitor	Temperature characteristics	External dimensions (mm)

- Constants of resistors, capasitors, ICs and etc with XX indicate that they are not used. In such cases, the unused circuits may be indicated.
- Parts with ★ differ according to the model/destination. Refer to the mount table for each function.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- Signal name

XEDIT → EDIT PB/XREC → PB/REC : nonflammable resistor.

: fusible resistor.

: panel designation. : B+ Line.*

--- : B- Line.*

: IN/OUT direction of B line (+, -).* : adjustment for repair.*

Circled numbers refer to waveforms.*

Measuring conditions voltege and waveform:

- · Voltages and waveforms are measured between the measurement points and graound when color bar signal input. They are reference values and reference waveforms.* (VOM of DC 10 M Ω input impedance is used)
- Voltage values change depending upon input impedance of VOM used.
- Indicated by the color red.

Note: The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.	Note: Les composants identifiés par une marque ∆ sont critiques pour la sécurité. Ne les remplacer que par une piéce portant le numéro spécifié.
When indicating parts by reference number, please include the board	

RP-228 (REC/PB AMP) PRINTED WIRING BOARD

- Ref. No.: RP-228 board; 3,000 series -

• For Printed Wiring


• RP-228 board is si of layers 2 to 5 hav

• There are few case is printed on this d

• Chip transistor



RP-228 BOARD (SIDE A)




• For Printed Wiring Board.

- RP-228 board is six-layer print board. However, the patterns
- of layers 2 to 5 have not been included in the diagram.

 There are few cases that the part isn't mounted in this model is printed on this diagram.
- Chip transistor






RP-228 BOARD


CN103 D-5

IC773 IC774

Q701 Q702 Q772 Q773 Q778

RP-228 BOARD (SIDE B)







SP1268 / Druck 10

4-7


4-8



4-9



The first account of the section of



RP-228 BOARD 3.4 Vp-p 0.04 μsec IC772 ② – ⑧ PB 3.3 msec IC777 ③ REC 0 41.8 MHz 6.7 msec IC777 ②, ③, ⑥, ⑦ REC IC772 12 PB 1 1.6 Vp-p 3.3 msec IC775 @ PB IC774 (9) REC/PB 4 0.5 Vp-p 3.6 Vp-p 8.38 MHz 3.3 msec IC774 ⑤ REC/PB IC775 @ PB IC774 ® PB 6 æ 3.4 Vp-p 0.6 Vp-p 0.25 μsec 6.7 msec IC777 ⁽¹⁾ PB IC774 ① - ④, @ REC 6 Œ 3.4 Vp-p 3.0 Vp-p 0.25 μsec 6.7 msec IC777 2 REC/PB IC774 69 - 63 PB 6.0 Vp-p 3.3 msec IC777 @ REC

4-13

(TAPE DETECT)


JC-19 (AD/DA CONVERTER, S1 AFC, U1, D1, C1 SPCON, MODE, DV IN/OUT, AUDIO CORE, DIGITAL AUDIO, AUDIO D/A, A/D CONVERTER) PRINTED WIRING BOARD JC-19 BOARD (SIDE A) - Ref. No.: JC-19 board; 2,000 series -A-6 A-3 A-9 A-10 D-5 D-10 CN103 CN103 CN104 CN411 CN412 CN501 CN831 C-2 C-2 C-1 B-4 C-11 E-2 E-1 D-4 D-4 B-6 B-10 B-8 F-9 E-10 E-7 F-6 E-4 D-8 E-9 D-9 D-11 IC013 IC014 IC018 IC019 IC200 IC209 IC210 IC211 IC212 IC213 IC214 IC410 IC410 IC701 IC702 IC801 IC804 IC805 IC807 IC833 IC840 JC-19 BOARD (SIDE A) Q039 Q040 Q041 Q042 Q043 Q044 Q045 Q050 Q051 Q052 Q053 Q200 Q201 Q801 B-3 B-3 B-3 B-2 B-2 A-3 B-4 A-2 B-1 B-1 C-3 D-7 (31)(30)/ IF, VIDEO IN/OUT, UVIC, (RS-232C IF) DV IN/OUT, MONITOR OUT, AUDIO, HI MICOM, RS MICOM (POWER 2) RP-228 (REC/PB AMP) RE-32 MD-65 (V/A IN/OUT) (TAPE DETECT) MD-63 OVER DISCHARGE PROTECT AD/DA CONVERTER, S1 AFC, U1, HEADPHONE D1, C1 SPCON, MODE, DV IN/OUT AUDIO CORE, DIGITAL AUDIO, (DISPLAY CONTROL) (SERVO, SYSTEM CONTROL)

AD/DA CONVERTER, S1 AFC, U1, D1, C1 SPCON, MODE, DV IN/OUT, AUDIO CORE, DIGITAL AUDIO, AUDIO D/A, A/D CONVERTER
SP1268 / Druck 14


- For Printed Wiring Board.
- JC-19 board is six-layer print board. However, the patterns of
- layers 2 to 5 have not been included in the diagram.

 There are few cases that the part isn't mounted in this model is printed on this diagram.
- Chip transistor







JC-19 BOARD (SIDE B)




JC-19 BOARD (SIDE B)





10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | **--**€∑ 2-11 ₹ 3-18 ₹ 3-19 ₹ 3-20 ₹ 3-21 ₹ 3-22 ₹ 3-22 IC011 R139 1k 1 C168 IC017 Y CLAMP REF REG IC013 C150 0.01u)39738999332 IC018 R113 4700 C152 ± C161 100 + C161 6 3V + C161 R125 R134 10k 4700 R138



4-21

VIDEO SIGNAL


CHROMA Y Y/CHROMA


-

 \Rightarrow

REC


TO VA-102 BOARD(1/8 CN101 (SEE PAGE 4-69)








DSR-20MD/20MDP


JC-19 BOARD (2/10) 3.8 Vp-p 13.5 MHz IC200 99, 99 REC/PB IC205 ⑦ REC Ø 0.15 μsec IC200 (11)- (11) REC/PB IC205 ® REC/PB 19 B 3.0 Vp-p IC205 18, 20 REC/PB IC200 @- @ REC/PB • 3.0 Vp-p Н IC205 @ REC/PB IC200 [®] PB IC205 4 REC/PB IC200 (PB 1 IC200 (6) PB






















4-38


4-37






В TO JC-19 BOARD(3/10,4/10,5/10,8/10) (SEE PAGE 4-29,34,37,52) 13 JC-19 BOARD (6/10) 8 8-7 ∑> 8-8 32) TO JC-19 BOARD(4/10) 32-1 ∑≫ IC501 @ REC/PB CL510 CL511 CL512 TO JC-19 BOARD(1/10) (SEE PAGE 4-19) 0.01u 8 CL531 CL596 Ε C524 0.01u B CL532 IC504 IC501 @ REC/PB 19 R506 0 MO_48 TO JC-19 BOARD(2/10,5/10) (SEE PAGE 4-27,39) F 8-3 ∑≫ R510 0 MO_50 8 - CL519 CL522 R513 100 W - CL521 CL524 • R514 100 W R515 100 W R517 100


JC-19 (MODE) SCHEMATIC DIAGRAM • See page 4-14 for JC-19 printed wiring board.






4-46

4-45







JC-19 BOARD (8/10)


1.1 msec


|< →| 1.1 msec




AUDIO CORE SP1268 / Druck 339 (8/10)











AUDIO D/A, A/D CONVERTER
SP1268 / Druck 37 JC-19 (10/10)




- For Printed Wiring Board.
 There are few cases that the part isn't mounted in this model is printed on this diagram.

RE-32 (V/A IN/OUT) PRINTED WIRING BOARD


- Ref. No.: RE-32 board; 7,000 series -



RE-32 (V/A IN/OUT) SCHEMATIC DIAGRAM



SCHEMATIC DIAGRAM



VA-102 / IF, VIDEO IN/OUT, UVIC, RS-78 (RS-232C IF) DV IN/OUT, MONITOR OUT, AUDIO, HI MICOM, RS MICOM (POWER 2) RP-228 VA-102 (IF, VIDEO IN/OUT, UVIC, DV IN/OUT, MONITOR OUT, For Printed Wiri (REC/PB AMP) AUDIO, HI MICOM, RS MICOM) PRINTED WIRING BOARD VA-102 board is RE-32 of layers 2 to 5 ha - Ref. No.: VA-102 board; 1,000 series -(V/A IN/OUT) MD-65 There are few ca (TAPE DETECT) is printed on this MD-63 Chip transistor (TAPE DETECT) VA-102 BOARD (SIDE A) CN051 CN101 A-1 E-5 E-6 B-5 A-2 D-8 E-2 B-7 E-3 OVER DISCHARGE CN101 CN102 CN401 CN602 CN701 CN702 LANC PROTECT VA-102 BOARD(SIDE A) U-1 (POWER 1) AD/DA CONVERTER, S1 AFC, U1, / HEADPHONE D1, C1 SPCON, MODE, DV IN/OUT & REC VR E-4 C-5 C-5 A-4 A-4 B-4 D-1 C-1 D401 AUDIO CORE, DIGITAL AUDIO, D403 D404 D851 D852 D853 AUDIO D/A, A/D CONVERTER FR-136 (DISPLAY CONTROL) MD-64 (SERVO, SYSTEM CONTROL) (TAPE DETECT) D866 D867 000000 IC051 B-2 B-3 E-2 E-2 E-2 E-2 E-3 D-3 B-6 C-6 C-7 C-7 B-7 E-1 B-2 B-4 E-8 E-7 E-1 IC052 IC101 IC102 IC103 IC104 IC105 IC106 IC202 IC401 IC402 IC652 IC701 IC702 IC703 IC706 IC715 IC715 IC852 IC853 IC856 IC862 IC863 IC865 Q214 Q215 Q217 Q218 Q221 Q222 Q223 Q224 Q25 Q231 Q30 Q400 Q410 Q410 Q411 Q412 Q415 Q417 Q420 Q852 Q855 Q855 Q857 D-6 C-7 C-7 E-C-6 C-6 E-6 C-C-5 D-5 C-5 D-5 C-5 D-5 C-4 E-7 D-1 A-1 30 05 2 3 5


T,

T)

• For Printed Wiring Board.


- VA-102 board is six-layer print board. However, the patterns of layers 2 to 5 have not been included in the diagram.
- There are few cases that the part isn't mounted in this model is printed on this diagram.

• Chip transistor




HARGE)


U1, OUT, O,





VA-102 BOARD (SIDE B)


W. TOE BOTH ID (OIDE B)			
CN601 CN852	A-6 E-1	Q103 Q107 Q108 Q201 Q202 Q203 Q204 Q205 Q206 Q207 Q208 Q210 Q211 Q212 Q213 Q216 Q226 Q227 Q228 Q233 Q403 Q405 Q406 Q416 Q416 Q416 Q416 Q405 Q405 Q405 Q405 Q405 Q405 Q405 Q407 Q601 Q602 Q607 Q604 Q605 Q606 Q607 Q605 Q606 Q607 Q605 Q606 Q701 Q701 Q701 Q701 Q702 Q703 Q703 Q709 Q709 Q709 Q709 Q709 Q709 Q709 Q709	E E B C B B B B B B B B
D051 D052 D201 D202 D855 D856 D858 D859 D861 D862 D863 D864	B-6 B-6 D-2 D-3 C-8 C-8 E-1 E-1 A-6 E-1 C-8		
ICO53 IC201 IC203 IC204 IC206 IC207 IC208 IC207 IC208 IC210 IC213 IC404 IC405 IC406 IC407 IC602 IC6513 IC602 IC6513 IC704 IC705 IC705 IC707 IC718 IC712 IC713 IC714 IC717 IC718 IC854 IC857 IC858 IC861 IC864 IC866	B-7 B-2 C-3 D-3 D-4 E-5 B-4 D-7 C-5 C-1 D-1 D-1 D-1 D-1 D-1 D-1 D-1 D-1 D-1 D		
Q101 Q102	E-3 E-4		C-















THE SCHOOL STATE

S(0 t) W














VIDEO OUT VA-102 (3/8)



































(18) VA-102 BOARD (6/8) (SEE PAGE 4-85)

2.2u B

R960 10k


IC864

RS-78 (RS-232C IF) PRINTED WIRING BOARD


- Ref. No.: RS-78 board; 6,000 series -


- For Printed Wiring Board.
 There are few cases that the part isn't mounted in this model is printed on this diagram.

RS-78 BOARD(SIDE A)



RS-78 BOARD(SIDE B)








4-92

MD (TA

HP-: (HEA & R









MD-63, MD-64, MD-65 (TAPE DETECT), FP-406 (TAPE SENSOR) PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAM


- Ref. No.: MD-63 board; 6,000/MD-64 board; 7,000/MD-65 board; 5,000/FP-406 boad; 5,000 series -





- For Printed Wiring Board.
- There are few cases that the part isn't mounted in this modis printed on this diagram.




- For Printed Wiring Board.
- There are few cases that the part isn't mounted in this model is printed on this diagram.











SIGNAL PATH

SIGNAL PATH			
	REC	REC/PB	PB
Drum speed servo		Λ	
Drum phase servo	,		
Drum servo (speed and phase)			
Capstan speed servo			
Capstan phase servo			
Capstan servo (speed and phase)			
Ref. signal			-


HP-100 (HEADPHONE & REC VR) PRINTED WIRING BOARD

- Ref. No.: HP-100 board; 5,000 series -






- For Printed Wiring Board.
- HP-100 board is six-layer print board. However, the patterns of layers 2 to 5 have not been included in the diagram.
- There are few cases that the part isn't mounted in this model is printed on this diagram.



4-99




SP1268 / Druck 50

DSR-20MD/20MDP

CM-56 (SERVO, SYSTEM CONTROL) PRINTED WIRING BOARD

- Ref. No.: CM-56 board; 4,000 series -



• For Printed Wiring Board.

• There are few cases that the part isn't mounted in this model is printed on this diagram.

Chip transistor



VA-102 RS-78 (IF, VIDEO IN/OUT, UVI)
DV IN/OUT, MONITOR (RS-232C IF) U-2 AUDIO, HI MICOM, RS RP-228 (POWER 2) (REC/PB AMP) RE-32 MD-65 (TAPE DETECT) MD-63 (TAPE DETECT) OVER DI PROTEC U-1 (POWER 1) HP-100 AD/DA CONVERTER, S1 AI D1, C1 SPCON, MODE, DV AUDIO CORE, DIGITAL AU / HEADPHONE & REC VR AUDIO D/A, A/D CONVERT (DISPLAY CONTROL) (SERVO, SYSTEM CONTROL) (TAPE DETECT)


D004 D011 D501 D502 E-2 C-6 D-2 B-5

IC003 IC005 IC008 IC009 IC014 IC017 IC021 C-7 B-9 C-4 B-7 F-6 F-7 A-6

Q002 Q012 Q500 Q502 Q503 F-8 E-2 E-5 D-2 E-9

SERVO, SYSTEM CONTROL SP1268 / Druck 51

t mounted in this model is



RS-78
(RS-232C IF)

IF, VIDEO IN/OUT, UVIC,
DV IN/OUT, MONITOR OUT,
AUDIO, HI MICOM, RS MICOM

RE-32
(V/A IN/OUT)

RE-32
(V/A IN/OUT)

U-1 (POWER 1)

JC-19

AD/DA CONVERTER, S1 AFC, U1,
D1, C1 SPCON, MODE, DV IN/OUT,
AUDIO CORE, DIGITAL AUDIO,
AUDIO D/A, A/D CONVERTER


CM-56
(SERVO, SYSTEM CONTROL)


DETECT)


4-105

4-107

SP1268 / Druck 53











FR-136 (DISPLAY CONTROL) PRINTED WIRING BOARD

- Ref. No.: FR-136 board; 5,000 series -











FR-136 (DISPLAY CONTROL) SCHEMATIC DIAGRAM



FR-136 (DISPLAY CONTROL) SCHEMATIC DIAGRAM





HG-1 (OVER DISCHARGE PROTECT) PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM


- Ref. No.: HG-1 board; 8,000 series -

• For Printed Wiring Board.

- : Pattern from the side which enables seeing.
- : Pattern on the rear side.
- There are few cases that the part isn't mounted in this model is printed on this diagram.








U-1 (POWER 1) PRINTED WIRING BOARD


- Ref. No.: U-1 board; 10,000 series -


- For Printed Wiring Board.
- :: Pattern from the side which enables seeing.
- : Pattern on the rear side.
- There are few cases that the part isn't mounted in this model is printed on this diagram.

U-1 BOARD		
CN1	A-4	
CN3	A-1	
D1 D4 D5 D6 D8 D9 D10 D11 D12	B-4 B-2 B-3 B-2 B-3 B-1 A-2 A-2	
Q1	B-3	
Q3	A-2	
Z1	A-3	
Z2	A-2	
Z3	A-2	



DSR-20MD: 1-468-441-DSR-20MDP: 1-468-442-





The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified.


Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une piéce portant le numéro spécifié.

DSR-20MD/20MDP


U-2 (POWER 2) PRINTED WIRING BOARD

- Ref. No.: U-2 board; 20,000 series -

U-2 BOARD				
CN1	B-1			
CN2	B-1			
CN10	A-5			
CN11	A-4			
CN12	A-1			
CN13	B-1			
D1	B-2			
D2	B-3			
D3	B-3			
D4	A-2			
D5	B-4			
D6	B-5			
D7	A-2			
D8	A-3			
Q1	B-1			
Q2	A-2			
Q3	A-4			
Q4	A-5			
Z1	B-2			
Z2	A-1			
Z3	B-3			
Z4	A-3			
Z5	B-4			
Z6	A-2			
Z7	B-4			
Z8	B-5			
Z10	A-5			
Z11	A-3			




- For Printed Wiring Board.
 : Pattern from the side which enables seeing.
- : Pattern on the rear side.
- There are few cases that the part isn't mounted in this model is printed on this diagram.



DSR-20MD: 1-468-441-DSR-20MDP: 1-468-442-

U-2 (POWER 2) SCHEMATIC DIAGRAM




4-126 E

SP1268 / Druck 63

SECTION 5 ADJUSTMENTS


5-1. MECHANICAL SECTION ADJUSTMENTS

5-1-1. INFORMATION




1-2. PHASE ADJUSTMENT MARK "(PH-)"

Numerous phase adjustments must be performed for removing and attaching parts (replacing parts) of the E mechanism. When removing and attaching parts, be sure to check the phase adjustment of corresponding parts. Parts that need phase adjustment are indicated with PH- mark. When replacing parts indicated with PH- mark, check their positions and phases so that the parts are attached smoothly in later.




In case of the above figure, refer to (B) and (E) of "5-1-3. PHASE ADJUSTMENTS"




5-1-2. PREPARATION FOR MECHANICAL CHECK, ADJUSTMENT AND MAINTENANCE

2-1. FL BLOCK ASSEMBLY


Removing/Attaching




2-2. CASSETTE POSITIONS



2-3. LOADING/UNLOADING



2-4. MANUAL UP/DOWN THE FL BLOCK



2-5. SERVICE JIGS LIST

Ref. No.	Name	Part No.	Fixtur No.	Usage, Others Application, etc
J-1	Cleaning fluid	Y-2031-001-0		For cleaning drum assembly and tape guide
J-2	Wiping cloth	7-741-900-53		For cleaning drum assembly
J-3	Super fine applicator (Made by NIPPON APPLICATOR (P752D))			For cleaning tape guide
J-4	Mirror (Small oval type)	J-6080-840-A	GD-2038	Tape path
J-5	Tracking tape (XH2-1AST) Standard cassette Tracking tape (XH2-1ASE) Standard cassette Tracking tape (XH2-1A1) Mini cassette	8-967-999-01 8-967-999-06 8-967-999-03	32 2030	Tape path (for tape top checking) Tape path (for tape end checking) Tape path (for checking)
J-6	Mini DV torque cassette	J-6082-360-A		For adjusting FWD/RVS back tension
J-7	Cassette standard plate (D/E mechanism)	J-6082-330-A		For adjusting tape guide and reel table
J-8	Reel standard plate (D/E mechanism)	J-6082-331-A		For adjusting reel table
J-9	TG2/7 preset plate	J-6082-358-A	•	For adjusting tape guide
J-10	Screwdriver for tape path	J-6082-026-A		For adjusting tape guide
J-11	Adjusting remote commander (RM-95 remodeled partly) Note 1	J-6082-053-B		Tape path
J-12	Torque driver	J-9049-330-A		Machaniam abada and and
J-13	Tension regulator adjustment board	J-6082-359-A		Mechanism check and replacement
J-14	CPC 8-jig	J-6082-388-A		Electric tension regulator adjustment Tape path


Other equipment used


- Oscilloscope
- DC power supply
- Digital voltage meter

Note 1: If the micro processor IC in the adjusting remote commander is not the new micro processor (UPD7503G-C56-12), the pages cannot be switched.

In this case, replace with the new micro processor (8-759-148-35).

- 1. Make a checking and adjustment at the tape top using the XH1-1AST tape.
- 2. Then, make a checking with the XH2-1ASE (for tape end) and XH2-1A1 (Mini cassette for tape top and end).
- 3. Again make a checking with the XH2-1AST.






5-1-3. PHASE ADJUSTMENTS


• This section classifies the phase adjustment into three blocks for clarity. The attaching order of each part is not described here. For details of the attaching order, refer to "5-1-5. MECHANISM SECTION CHECKS AND REPLACEMENTS".

3-1. PHASE ADJUSTMENT (Loading/Unloading Driving Section)


Note 1: Adjust it at the **UNLOADING** position unless otherwise specified. Note 2: A to G shown below are the orders for the phase adjustment.




PHASE ADJUSTMENT (A)




PHASE ADJUSTMENT ®




PHASE ADJUSTMENT ©




PHASE ADJUSTMENT ®




PHASE ADJUSTMENT (E)



PHASE ADJUSTMENT (F)




PHASE ADJUSTMENT @




3-2. PHASE ADJUSTMENT (S/L Cassette Selection Section)

Note 1: Adjust if at the S/L cassette position unless otherwise specified.


Note 2: (H) to (M) shown below are the orders for the phase adjustment.




PHASE ADJUSTMENT (H)




PHASE ADJUSTMENT ①




PHASE ADJUSTMENT (6)



PHASE ADJUSTMENT (L)




PHASE ADJUSTMENT M




3-3. PHASE ADJUSTMENT (Mechanism Chassis Upper Surface Parts)

Note: Adjust if at the **UNLOADING** position unless otherwise specified.


PHASE ADJUSTMENT N




PHASE ADJUSTMENT (P)




PHASE ADJUSTMENT @




PHASE ADJUSTMENT ®




PHASE ADJUSTMENT ®




PHASE ADJUSTMENT ①




PHASE ADJUSTMENT (1)




PHASE ADJUSTMENT **(V)**



PHASE ADJUSTMENT W



PHASE ADJUSTMENT &



5-1-4. PERIODIC CHECK AND MAINTENANCE

 Carry out the following maintenance and periodic checks not only to fully display the functions and performance of the set, but also for the equipment and tape. After repairing, service the set as follows, regardless of the length of use.

4-1. CLEANING OF ROTARY DRUM ASSEMBLY

1) Press a wiping cloth (Ref No. J-2) moistened with cleaning fluid (Ref No. J-1) against the rotary drum assembly gently, and clean it while rotating the upper rotary drum assembly slowly with your finger in the counterclockwise direction.

Note: Do not rotate the motor on power or rotate the upper rotary drum assembly in the clockwise direction with your finger. The head tip will also be damaged if the wiping cloth is moved perpendicularly against it.

Therefore, be sure to follow the above instructions when cleaning the rotary drum assembly.

4-2. CLEANING OF TAPE PATH SYSTEM (See Fig. 1.)

1) In the EJECT mode, clean the tape path systems (TG-1, 2, 3, 4, 5, 6, 7, 8, capstan) and the lower drum using a superfine applicator (Ref No. J-3) moistened with cleaning fluid.

Note 1: Make sure that no oil or grease of the link mechanisms sticks to the superfine applicator. (Ref No. J-3)

Note 2: Do not use a applicator moistened with alcohol to the other guide cleaning. But clean the pinch roller using alcohol.




Fig. 1.

4-3. PERIODIC CHECKS

Location of Maintenance and Check		Hours of Use (H)										Remarks
		500	1000	1500	2000	2500	3000	3500	4000	4500	5000	Hellarks
	Cleaning of tape path surface	0	0	0	0	0	0	0	0	0	0	Take care not to adhere the oil.
	Cleaning and degaussing of rotary drum assembly	0	0	0	0	0	0	0	0	0	0	
Driving System	Capstan shaft (Bearing)	_	☆	_	☆	_	☆		☆	-	☆	Make sure that no oil gets on the tape path surface.
	Loading motor	_	☆	_	☆	_	☆	_	☆		☆	A-7026-007-A
Performance Confirmation	Abnormal noise	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	
	Back tension measurement	_	☆	-	☆	-	☆	-	☆	-	∵☆	
	Brake system	-	☆	_	☆	-	☆	_	☆	_	☆	
	FWD Torque measurement	_	☆	_	☆	-	☆	_	☆	_	☆	

O: Cleaning ☆: Confirmation

Note: When overhauling, refer to the checks above and replace parts.

Note: Grease

• Be sure to use the specified the grease. (The SG-055G is used all in the E mechanism)


Check the quantity of grease when installing the parts which is needed to apply the grease.

• FLOIL (SG-055G): Part No. 7-651-000-09

5-1-5. MECHANISM SECTION CHECKS AND REPLACEMENTS


5-1. TAPE STOPPER, MOTOR FPC ASSEMBLY AND ELASTIC CONNECTOR

· Removing/Attaching



5-2. DRUM ASSEMBLY AND DRUM BASE


· Removing/Attaching



(PH-G) : Page 5-7 (PH-S) : Page 5-11

5-3. LM COVER, LM WORM WHEEL, LM HOLDER AND LM MOTOR ASSEMBLY

· Removing/Attaching



5-4. TG3/4 CATCHER BLOCK ASSEMBLY, PINCH DRIVING GEAR AND TC ARM ASSEMBLY

· Removing/Attaching


Removing: After removing the LM motor assembly (Refer to 5-3.), remove each part. · Attaching: After attaching each part and the LM motor block assembly, adjust them according to the flowchart (START-3) on page 5-43. (Only when the TG3/4 catcher block assembly is removed) Screw (M1.4 × 2.5) Never turn this screw as it has been adjusted. TG3/4 catcher block assembly (PH-G) Pinch driving gear PH-S TC arm assembly Claw Claw Fixing torque: 0.0686 Nem (0.7 kgecm)

5-5. PINCH ARM ASSEMBLY, PINCH LIMITER AND TENSION COIL SPRING (PINCH)


1. Removing

①. Set the **UNLOADING** position. (Refer to page 5-3)

2. Pinch arm block assembly.



3. Pinch arm assembly and pinch limiter.



2. Attaching

1. Attach the parts in the order of $\bigcirc \rightarrow \bigcirc \rightarrow \bigcirc$.

2. Adjust them according to the flowchart (START-3) on page 5-43.


5-6. HC ARM, HC ROLLER ASSEMBLY, PINCH RETAINER, PINCH CAM GEAR AND TG5/6 CATCHER BLOCK ASSEMBLY

1. Removing


1. Set the **UNLOADING** position. (Refer to page 5-3)

2. Pinch arm block assembly. (Refer to 5-5)


3. Flexible board.



4. HC arm, HC roller assembly and pinch retainer.



(5). Pinch cam gear and TG5/6 catcher block assembly.




2. Attaching

1. Attach the parts in the order of $\bigcirc \rightarrow \bigcirc \rightarrow \bigcirc \rightarrow \bigcirc \rightarrow \bigcirc \rightarrow \bigcirc \rightarrow \bigcirc$.

2. Adjust them according to the flowchart (START-3) on page 5-43.


5-7. RL ARM AND RL LINK

• Removing/Attaching (L cassette) position. (Refer to page 5-2))



5-8. GOOSENECK GUARD AND GOOSENECK ARM ASSEMBLY

• Removing/Attaching (Lassette) position. (Refer to page 5-2))




5-9. TENSION COIL SPRING (TG2), SPRING ADJUSTOR, TG2 SPRING HOOK, TG2 SELECTION ARM AND DAMPER SHEET


1. Removing

1. Set the **UNLOADING** position. (Refer to page 5-3)


2. Tension coil spring (TG2) and spring adjustor.



3. LM motor block assembly.



4. TG2 spring hook and TG2 selection arm.



2. Attaching


2. Adjust them according to the flowchart (START-2) on page 5.43

5-10. TENSION COIL SPRING (TG7), SPRING ADJUSTOR AND TG7 SPRING HOOK


1. Removing

1. Set the **UNLOADING** position. (Refer to page 5-3)

2. Tension coil spring (TG7) and spring adjustor.



3. TG7 spring hook.



2. Attaching


1. Attach the parts in the order of \bigcirc \bigcirc \bigcirc \bigcirc \bigcirc .

2. Adjust them according to the flowchart (START-2) on page 5-43.


5-11. TG2 RETAINER, TG2 ARM ASSEMBLY (TG2 PLATE SPRING AND ET MAGNET), S TENSION REGULATOR BAND ASSEMBLY AND TG2 LOAD ARM ASSEMBLY

1. Removing


- ①. Tension coil spring (TG2), spring adjustor, LM motor block assembly and TG2 spring hook. (Refer to 5-9)
- 2. TG2 retainer.




- 3. Set the **LOADING** position. (Refer to page 5-3)
- 4. TG2 arm assembly and S tension regulator band assembly.



(5). S tension regulator band assembly, TG2 plate spring and ET magnet.



6. TG2 load arm assembly.



2. Attaching

1. Set the **UNLOADING** position. (Refer to page 5-3)

2. Attach the parts in the order of $\textcircled{6} \rightarrow \textcircled{3} \rightarrow \textcircled{5} \rightarrow \textcircled{4} \rightarrow \textcircled{2} \rightarrow \textcircled{1}$.


3. Operation check: **LOADING**/**UNLOADING**. (Refer to page 5-3)

4. Adjust them according to the flowchart (START-2) on page 5-43.


5-12. TG7 RETAINER, TG7 ARM ASSEMBLY (TG7 PLATE SPRING AND ET MAGNET), T TENSION REGULATOR BAND ASSEMBLY AND TG7 LOAD ARM ASSEMBLY

1. Removing


①. Tension coil spring (TG7), spring adjustor.




②. TG7 spring hook.




- 3. Set the **LOADING** position. (Refer to page 5-3)
- 4. TG7 arm assembly and T tension regulator band assembly.



(5). TG7 plate spring, ET magnet and T tension regulator band assembly.



TG7 load arm assembly.



2. Attaching

1. Set the UNLOADING position. (Refer to page 5-3)


- 2. Attach the parts in the order of $\textcircled{6} \rightarrow \textcircled{3} \rightarrow \textcircled{5} \rightarrow \textcircled{4} \rightarrow \textcircled{2} \rightarrow \textcircled{1}$.
- 3. Operation check: **LOADING**/**UNLOADING**. (Refer to page 5-3.)
- 4. Adjust them according to the flowchart (START-2) on page 5-43.

5-13. S REEL TABLE BLOCK ASSEMBLY


1. Removing

1. Set the (L cassette) position. (Refer to page 5-2)


2. RL arm




3. Gooseneck guard.



4. S band adjustor.



⑤. S reel table block assembly.




- **1**. Attach the parts in the order of $\textcircled{1} \rightarrow \textcircled{5} \rightarrow \textcircled{4} \rightarrow \textcircled{3} \rightarrow \textcircled{2}$.
- 2. Adjust them according to the flowchart (START-1) on page 5-43.

5-14. T REEL HOLDER AND T REEL TABLE BLOCK ASSEMBLY


1. Removing

①. Set the **L cassette** position. (Refer to page 5-2)

2. T band adjustor.



3. T reel holder and T reel table block assembly.



2. Attaching

1. Attach the parts in the order of \bigcirc \rightarrow \bigcirc \bigcirc \bigcirc .


2. Adjust them according to the flowchart (START-1) on page 5-43.

5-15. S REEL PLATE ASSEMBLY

1. Removing


1). Set the **L cassette** position. (Refer to page 5-2)

2. S band adjustor.




3. Set the **LOADING** position. (Refer to page 5-3)


4. S brake.




⑤. RL arm and RL link.




6. Gooseneck guard.



7. Plate spring



(8). S reel plate assembly.



- **1.** Attach the parts in the order of $(1) \rightarrow (8) \rightarrow (7) \rightarrow (4) \rightarrow (3) \rightarrow (2) \rightarrow (6) \rightarrow (5)$.
- 2. Adjust them according to the flowchart (START-1) on page 5-43.


PH-P, PH-R: Page 5-10

5-16. T REEL PLATE ASSEMBLY

1. Removing


1). Set the **L cassette** position. (Refer to page 5-2)

2. T band adjustor.




3. Set the **LOADING** position. (Refer to page 5-3)


4. T ratchet.



3. Plate spring.



6. T reel plate assembly.




- ①. Attach the parts in the order of ① \rightarrow ⑥ \rightarrow ⑤ \rightarrow ③ \rightarrow ④ \rightarrow ②.
- 2. Adjust them according to the flowchart (START-1) on page 5-43.

5-17. TG1/8 BASE ASSEMBLY, S BRAKE AND T RATCHET


1. Removing

1). Set the **LOADING** / **L cassette** positions. (Refer to pages 5-2 to 5-3)

2. TG1/8 base assembly.




3. S brake and T ratchet.



- **1**. Attach the parts in the order of \bigcirc \bigcirc \bigcirc \bigcirc \bigcirc .
- 2. Adjust them according to the flowchart (START-2) on page 5-43.

5-18. TG3/6 ROLLER ASSEMBLY AND TG3/6 LOCK SPRING


· Removing/Attaching



Note: After attaching each part, adjust them according to the flowchart (START-3) on page 5-43.

5-19. FL JOINT GEAR, TG5/6 RETAINER AND CAPSTAN MOTOR


• Removing/Attaching



PH-A : Page 5-6 PH-D , PH-G : Page 5-7

5-20. FL SELECTION ARM, FL RELAY GEAR AND FL JOINT ARM ASSEMBLY

· Removing/Attaching




5-21. ROTARY SWITCH, TC GEAR AND RELAY GEAR

1. Removing


1. Set the **UNLOADING** position. (Refer to page 5-3)

2. Rotary switch, TC gear and relay gear.



2. Attaching

①. Remove the LM motor block assembly and LM worm wheel. (To synchronize phase of the pinch driving system (front side) and the loading driving system (back side))




2. Attach the TC gear, relay gear and rotary switch.

3. Attach the LM worm wheel and LM motor block assembly.

5-22. GL ARM RETAINER AND GL ARM

• Removing/Attaching (UNLOADING) position. (Refer to page 5-3))




5-23. M SLIDER AND M SLIDER ARM

1. Removing

1. Set the **UNLOADING** position. (Refer to page 5-3)


2). GL arm retainer and GL arm. (Refer to 5-22)

3. M slider and M slider arm.



2. Attaching

• Attach the parts in the order of $\bigcirc \rightarrow \bigcirc \rightarrow \bigcirc$.



5-24. TG7 SELECTION ARM, TG7 CAM GEAR AND T CAM GEAR


1. Removing

1. Set the **UNLOADING** position. (Refer to page 5-3)

2. GL arm retainer and GL arm. (Refer to 5-22)

3. M slider and M slider arm. (Refer to 5-23)

4. TG7 selection arm, TG7 cam gear and T cam gear.



2. Attaching

1. Attach the parts in the order of $\bigcirc \rightarrow \bigcirc \rightarrow \bigcirc \rightarrow \bigcirc$.



Cam groove on the T cam gear.

Apply the grease (3 mm dia) to of cam groove (part).

T cam gear (T ratchet driving side)

<u>PH-A</u>: Page 5-6 <u>PH-G</u>: Page 5-7 <u>PH-T</u>, <u>PH-U</u>: Page 5-11


5-25. MAIN CAM, TG2 SL ARM ASSEMBLY AND TENSION COIL SPRING (TG2 SL)

The two grooves on one side of the main cam drive the TG2 selection arm and the TG2 load arm assembly. Since it is difficult to attach the main cam, fix the TG2 selection arm and the TG2 load arm assembly with the main cam's phase adjusted correctly (Nearly unloading position (See 3-1. Phase Adjustment (a): page 5-6)), so that later mounting work can be performed smoothly. If fixed parts are shifted, follow "3-3. Phase Adjustment (a): page 5-11".


1. Removing

1. Set the **UNLOADING** position. (Refer to page 5-3)


2. LM motor block assembly and LM worm wheel.



- 3. GL arm retainer and GL arm. (Refer to 5-22)
- 4. M slider and M slider arm. (Refer to 5-23)
- (5). TG2 spring hook.



(6). Main cam, TG2 SL arm assembly and tension coil spring (TG2 SL).



2. Attaching

- ①. Attach the parts in the order of ① \rightarrow ⑥ \rightarrow ⑤ \rightarrow ④ \rightarrow ③ \rightarrow ②.
- 2. Adjust them according to the flowchart (START-2) on page 5-43.



Main cam (rear side)

Cam groove on the main cam.

Apply the grease (12 mm dia.) to each two of cam groove (part).


PH-A : Page 5-6 PH-F , PH-G : Page 5-7

5-26. TG3/4 ARM BLOCK ASSEMBLY (TG3/4 ARM ASSEMBLY, TG3/4 LIMITER SPRING AND TG3/4 GEAR), TG3/4 BASE BLOCK ASSEMBLY (TG3/4 BASE ASSEMBLY)


1. Removing

①. Set the **UNLOADING** position. (Refer to page 5-3)


2. LM motor block assembly and LM worm wheel.




3. Pinch arm block assembly and pinch retainer.




4. TG3/4, TG5/6 catcher block assembly and pinch cam gear.



(5). GL arm retainer and GL arm.




6. Rotary switch, TC gear and TG5/6 retainer.




7. Set the **LOADING** position. (Refer to page 5-3)


8. TG3/4 arm block assembly.



TG3/4 base block assembly.



①. TG3/4 arm assembly, TG3/4 limiter spring, TG3/4 gear, TG3/6 roller assembly, TG3 lock spring and TG3/4 base assembly.




2. Attaching

1. Set the **LOADING** position. (Refer to page 5-3)

2. TG3/4 arm assembly, TG3/4 limiter spring, TG3/4 gear, TG3/6 roller assembly, TG3 lock spring and TG3/4 base assembly.

3. TG3/4 base block assembly.

4. TG3/4 arm block assembly.




6. Attach the parts in the order of $(6) \rightarrow (5) \rightarrow (4) \rightarrow (3) \rightarrow (2)$.

6. Adjust them according to the flowchart (START-3) on page 5-43.


5-27. TG5/6 ARM BLOCK ASSEMBLY (TG5/6 ARM ASSEMBLY, TG5/6 LIMITER SPRING AND TG5/6 GEAR), TG5/6 BASE BLOCK ASSEMBLY (TG5/6 BASE ASSEMBLY)

1. Removing


- 1. Set the UNLOADING position. (Refer to page 5-3)
- 2. LM motor block assembly and LM worm wheel.




3. Pinch arm block assembly and pinch retainer.




TG3/4, TG5/6 catcher block assembly, screw of capstan motor and pinch cam gear.



(5). GL arm retainer and GL arm.




6. FL joint gear, capstan motor and TG5/6 retainer.




7. Set the **LOADING** position. (Refer to page 5-3)


TG3/4 arm block assembly and TG5/6 arm block assembly.



TG5/6 base block assembly.



(1). TG5/6 arm assembly, TG5/6 limiter spring, TG5/6 gear, TG3/6 roller assembly, TG6 lock spring and TG5/6 base assembly.




2. Attaching

1. Set the **LOADING** position. (Refer to page 5-3)

2. TG5/6 arm assembly, TG5/6 limiter spring, TG5/6 gear, TG3/6 roller assembly, TG6 lock spring and TG5/6 base assembly.

3. TG5/6 base block assembly.

4. TG3/4 arm block assembly and TG5/6 arm block assembly.




5. Attach the parts in the order of $(6) \rightarrow (5) \rightarrow (4) \rightarrow (3) \rightarrow (2)$.

6. Adjust them according to the flowchart (START-3) on page 5-43.

5-28. REEL MOTOR

· Removing/Attaching




5-29. RS ARM ASSEMBLY

1. Removing

①. Set the **S/L cassette** position. (Refer to page 5-2)

2. RS arm assembly.



2. Attaching

• Attach the parts in the order of \bigcirc \rightarrow \bigcirc .


5-30. RS GEAR ASSEMBLY, MIC PRESS SPRING AND MIC LEVER

1. Removing


①. Set the **S/L cassette** position. (Refer to page 5-2)

②. RS arm assembly. (Refer to 5-29)

3. RS gear assembly.



4. Mic press spring and Mic lever.




2. Attaching

• Attach the parts in the order of $\textcircled{1} \rightarrow \textcircled{4} \rightarrow \textcircled{3} \rightarrow \textcircled{2}$.


5-31. RACK JOINT GEAR, RACK HOLDER, MIC HOLDER, RACK (LC) AND RACK (SC)

1. Removing


1. FL joint gear, TG7 selection arm.



- 2. Set the **S/L cassette** position. (Refer to page 5-2)
- 3. RS arm assembly. (Refer to 5-29)
- (4). RS gear assembly, Mic press spring and Mic lever. (Refer to 5-30)
- (5). Rack joint gear, rack holder, rack (LC) and rack (SC).



- (6). FL block assembly. (Refer to page 5-2)
- 7. Push switch, Connector (4P), Mic holder.



2. Attaching


• Attach the parts in the order of $② \to ⑦ \to ⑥ \to ⑤ \to ④ \to$ $③ \to ①$.

5-32. PLATE LINK ASSEMBLY


1. Removing

1. Set the L cassette position. (Refer to page 5-2)


2. RL arm.




3. Gooseneck guard.




4. S and T band adjustor.



(5). TG1/8 base assembly. (S brake and T ratchet)




6. T reel plate assembly.




PH-H : Page 5-8 PH-M : Page 5-9 PH-N : Page 5-10


7. S reel plate assembly.



- (8). Set the **S/L cassette** position. (Refer to page 5-2)
- 9. RS arm assembly.




10. Plate link assembly.



- **1**. Attach the parts in the order of $\textcircled{8} \rightarrow \textcircled{10} \rightarrow \textcircled{9} \rightarrow \textcircled{7} \rightarrow \textcircled{6} \rightarrow \textcircled{5} \rightarrow \textcircled{1} \rightarrow \textcircled{4} \rightarrow \textcircled{3} \rightarrow \textcircled{2}.$
- 2. Adjust them according to the flowchart (START-1) on page 5-43.


5-33. ROLLER SHAFT ASSEMBLY AND ROLLER BELT

• Removing/Attaching




5-34. LID OPENER

• Removing/Attaching




5-35. C DOOR

Removing/Attaching



5-36. DAMPER ARM AND TENSION SPRING (DB)

Removing/Attaching




5-37. GEAR (A), GEAR (B) AND C WORM


1. Removing

①. FL block assembly. (Refer to page 5-2)


②. Screw. $(M1.4 \times 2.5)$



3. Gear cover.



4. Gear (A), Gear (B) and C worm.




2. Attaching

• Attach the parts in the order of $(4) \rightarrow (3) \rightarrow (2) \rightarrow (1)$.


5-38. TENSION COIL SPRING (HS), TENSION SPRING (DB), SHIFT PLATE SPRING AND C SLOAT BLOCK ASSEMBLY

• Removing/Attaching (Remove the FL block assembly. (Refer to page 5-2))




5-1-6. ADJUSTMENTS AND CHECKS

6-1. ADJUSTMENT POSITION



6-2. ADJUSTMENT ORDER



6-3. ADJUSTMENT AND CHECKING METHOD

6-3-1. REEL TABLE HEIGHT ADJUSTMENT


1. Preparation before adjustment


FL block: Remove.

Position: LOADING / S cassette

Jig used: Cassette standard plate (J-7), Reel standard plate (J-8) and screwdriver (+)

2. Adjusting





6-3-2. TG2/TG7 HEIGHT ADJUSTMENT

1. Preparation before adjustment


FL block: Remove.

Position: LOADING / S cassette

Jig used: Cassette standard plate (J-7), TG2/7 preset plate (J-9) and screwdriver

(For attaching jigs, refer to page 5-5)

2. Adjusting



6-3-3. FWD/RVS POSITION ADJUSTMENT


1. Preparation before adjustment

FL block: Remove.

Position: (LOADING (The pinch roller should be stuck))/(S cassette)

Jig used: Cassette standard plate (J-7), TG2/7 preset plate (J-9) and screwdriver for tape path

2. Adjusting



6-3-4. TG2/TG7 ELECTRIC TENSION REGULATOR ADJUSTMENT

1. Preparation before adjustment


FL block: Remove.

Position: (LOADING (The pinch roller should be stuck)) / (S cassette)


Jig used: Cassette standard plate (J-7), TG2/7 preset plate (J-9) and screwdriver for tape path

(For attaching jigs, refer to page 5-5)


2. Connecting, setting, and adjusting methods



3. Adjusting



4. Adjustment order



6-3-5. FWD/RVS BACK TENSION ADJUSTMENT


1. Preparation before adjustment

Mechanism deck: Install to the unit.


Jig used : Mini DV torque cassette (J-6), pinset (For change the hooking of spring)

2. Adjusting


Note: At the FWD (TG2) side, measure the Mini DV torque cassette (J-6) in the FWD mode. At the RVS (TG7) side, measure the Mini DV torque cassette (J-6) in the RVS mode.




6-3-6. ADJUSTMENT PREPARATIONS AND RF WAVEFORM CHECK




6-3-7. TRACKING ADJUSTMENT




6-3-8. TRACKING CHECK




6-3-9. CUE AND REV CHECK



6-3-10. RISING CHECK



6-3-11. TAPE PATH CHECK



3 After adjustment and check, return the data set by the adjusting remote commander to the original value.

5-2. SERVICE MODE

5-2-1. ADJUSTING REMOTE COMMANDER

The adjusting remote commander is used for changing the calculation coefficient in signal processing, EVR data, etc. The adjusting remote commander performs bi-directional communication with the unit using the remote commander signal line (LANC). The resultant data of this bi-directional communication is written in the non-volatile memory.

1. Used Adjustment Remote Commander

- 1) With the unit set in STANDBY mode, connect the adjusting remote commander to the remote (LANC) terminal.
- Adjust the HOLD switch of the adjusting remote commander to "HOLD" (SERVICE position).
- 3) Turn on the power with the ON/STANDBY switch of the unit. If it has been properly connected, the LCD on the adjusting remote commander will display as shown in Fig. 5-2-1.




Fig. 5-2-1.

- 4) Operate the adjusting remote commander as follows.
 - Changing the page

The page increases when the EDIT SEARCH + button is pressed, and decreases when the EDIT SEARCH - button is pressed. There are altogether 16 pages, from 0 to F.

Hexadecimal notation	0 1 2 3 4 5 6 7 8 9 A B C D E F
LCD Display	0 123456789AbcdEF
Decimal notation	0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
conversion value	0125450765101112151415

Table 5-2-1.

- · Changing the address
- The address increases when the FF ($\triangleright \triangleright$) button is pressed, and decreases when the REW (\blacktriangleleft) button is pressed. There are altogether 256 addresses, from 00 to FF.
- Changing the data (Data setting)

 The data increases when the PLAY (▶) button is pressed, and decreases when the STOP (▶) button is pressed. There are altogether 256 data, from 00 to FF.
- Writing the adjustment data
 The PAUSE button must be pressed to write the adjustment data (C page, D page and E page) in the nonvolatile memory.
 (The new adjustment data will not be recorded in the nonvolatile memory if this step is not performed.)

2. Precautions Upon Using The Adjusting Remote Commander

Mishandling of the adjusting remote commander may erase the correct adjustment data at times. To prevent this, it is recommended that all adjustment data be noted down before beginning adjustments and new adjustment data after each adjustment.

5-2-2. DATA PROCESSING

The calculation of the adjusting remote commander display data (hexadecimal notation) are required for obtaining the adjustment data of some adjustment items. In this case, after converting the hexadecimal notation to decimal notation, calculate and convert the result to hexadecimal notation, and use it as the adjustment data. Table 5-2-2. indicates the hexadecimal notation- the decimal notation, calculation table.

Hexa	xadecimal nontation-Decimal notation						2										
			· · · · · ·	1								↓					
	The lower digits of the	0	1	2	3	4	5	6	7	8	9	A	В	С	D	E	F .
	hexadecimal notation				ļ			,									1
	The upper digits of the											(FI)	(b)	(c)	(d)	(E)	(F)
	hexadecimal notation \																
	0	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
	1	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
	. 2	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
	3	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
	4	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79
	5	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95
	6	96	.97	98	99	100	101	102	103	104	105	106	107	108	109	110	111
	7	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127
	8	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143
	9	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159
	A (A)	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175
\bigcirc	B (b)	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191
	C (c)	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
	D (d)	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223
	E (E)	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239
	F (F)	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255
1												l		L			

Note: () indicate the adjusting remote control unit display.

(Example) In the case that the adjusting remote control unit display are BD (bd).

As the upper digit of the hexadecimal notation is B (b), and the lower digit is D (d), the intersection "189" of the ① and ② in the above table is the decimal notation to be calculated.

Table 5-2-2.

5-2-3. SERVICE MODE

1. Emergence Memory Address

Page C	Addresses 30 to 3B

Address	Contents			
30	EMG code when first error occurs			
32	Upper: MSW code when shift starts when first error occurs Lower: MSW code when first error occurs			
33	Lower: MSW code to be moved when first error occurs			
34	EMG code when second error occurs			
36	Upper: MSW code when shift starts when second error occurs Lower: MSW code when second error occurs			
37	Lower: MSW code to be moved when second error occurs			
38	EMG code when last error occurs			
3A	Upper: MSW code when shift starts when last error occurs Lower: MSW code when last error occurs			
3B	Lower: MSW code to be moved when last error occurs			

When no error occurs in the unit, data 00 is written in the above addresses (30 to 3B). When the first error occurs in the unit, the data corresponding to the error is written in the first emergency address (30 to 33). In the same way, when the second error occurs, the data corresponding to the error is written in the second emergency address (34 to 37).

Finally, when the last error occurs, the data corresponding to the error is written in the last emergency address (38 to 3B). Consequently, addresses 30 to 3B are updated each time errors occur.

Note 1: After completing adjustments, be sure to rewrite the data of addresses 30 to 3B to 00.

- 1) Select page: 0, address: 01, and set data: 01.
- Select page: C, address: 30, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 3) Select page: C, address: 31, set data: 00, and press the PAUSE button of the adjusting remote commander.
- Select page: C, address: 32, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 5) Select page: C, address: 33, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 6) Select page: C, address: 34, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 7) Select page: C, address: 35, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 8) Select page: C, address: 36, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 9) Select page: C, address: 37, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 10) Select page: C, address: 38, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 11) Select page: C, address: 39, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 12) Select page: C, address: 3A, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 13) Select page: C, address: 3B, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 14) Select page: 0, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.

1-1. EMG Code (Emergency Code)

Codes corresponding to the errors which occur are written in addresses 30, 34, 38. The type of error indicated by the code are shown in the following table.

Code	Error Type		
00	No error (Initial state)		
· 10	Loading motor time-out during LOAD		
11	Loading motor time-out during UNLOAD		
20	Reel motor error		
22	T reel error		
23	S reel error		
24	Swing error		
32	Error during normal capstan rotation		
33	Cassette compartment LOAD error		
35	Cassette compartment UNLOAD error		
40	FG error during drum start-up		
42	FG error during normal drum rotation		
50	DEW detection		
52	Wet DEW detection		
60	Electrical tension regulator error		

5-3. VIDEO SECTION ADJUSTMENTS

When performing adjustments, refer to the layout diagrams for adjustment related parts on page 5-88.

3-1. PREPARATIONS BEFORE ADJUSTMENT

3-1-1. Equipment Used

- 1) TV monitor
- 2) Oscilloscope with 2-phenomenon, 30 MHz band, and delay mode (Unless specified otherwise, use a 10:1 probe)
- 3) Frequency counter
- 4) Digital voltmeter
- 5) Audio generator
- 6) Audio level meter
- 7) Audio distortion meter
- 8) Audio attenuator
- Pattern generator (with VIDEO OUTPUT terminal and external sync function)
- 10) Digital camera recorder NTSC: DCR-VX1000

PAL : DCR-VX1000E

11) Vectorscope

- 12) Alignment tape
 - SW/OL reference (XH2-3)

Parts code: 8-967-997-11

• Audio operation check for NTSC (XH5-3)

Parts code: 8-967-997-51

System operation check for NTSC (XH5-5)
 Parts code: 8-967-997-61

Audio operation check for PAL (XH5-3P)

Parts code: 8-967-997-55
• System operation check for PAL (XH5-5P)

Parts code: 8-967-997-66

- BIST check for NTSC (XH5-6)
- Parts code: 8-967-997-71

 BIST check for PAL (XH5-6P)
- BIST check for PAL (XH5-6P)
 Parts code: 8-967-997-76
- 13) Adjusting remote control unit (J-6082-053-B)
- 14) Multi CPC-8 jig (J-6082-388-A). (CN775 of the RP-228 board)
- 15) Extension board
 - For extension between CN101 of the RP-228 board and CN412 of the JC-19 board.
 - For extension between CN102 of the RP-228 board and CN411 of the JC-19 board. (30P, 0.5 mm) (J-6082-270-A)
 - For extension between CN771 of the RP-228 board and drum (M901) (10P, 1 mm) (J-6082-064-A)
 - For extension between CN002 of the CM-56 board and CN501 of the VA-102 board (8P, 1 mm) (J-6082-058-A)
 - For extension between CN006 of the CM-56 board and the reel motor (M904) (15P, 1.25 mm) (J-6902-354-A)
 - For extension between CN001 of the CM-56 board and CN101 of the MD-63 board (16P, 1 mm) (J-6082-020-A)
- 16) Regulated power supply

NTAC: DSR-20MD PAL: DSR-20MDP

3-1-2. Connection of Equipment

VIDEO SELECT button on the front panel.

According to the specification for the input terminal (S VIDEO input, VIDEO input, or DV input), connect measuring equipment as shown in Fig. 5-3-1, and make adjustment.

The input terminal is specified in () of the signal column.

Any input terminal can be used unless otherwise specified.

To switch between S VIDEO INPUT and VIDEO INPUT, use the

- Note 1: In adjustments specifying for the S VIDEO input to be used, using the VIDEO input would disable the product specifications of this unit from being satisfied. Always use the input signal specified.
- Note 2: If adjustments are used with the VTR with the S video output terminal as the signal source, the performance of this unit may be affected by the VTR. Use a pattern generator with a Y/C separator terminal as much as possible.




Fig. 5-3-1.

3-1-3. Adjusting Connectors (RP-228 Board CN775)

Some of the adjusting points of the video section are concentrated at CN775 of the RP-228 board. Connect the instruments via the multi CPC-8 jig (J-6082-388-A)

Pin No.	Signal Name	Pin No.	Signal Name
1	TCK	2.	TMS
3	TDI	4	GND
5	TRACK ID	6	JSWP
7	GND	8	RF MONITOR
9	VCC2	10	AGC IN
11	VCC1	12	EQ IN
13	LOCK	14	REF OUT
15	ENV OUT	16	GND
17	TDO	18	C1ERP
19	FLTD	20	GND

Table 5-3-1.

3-1-4. Checking the Input Signals

Because the video signal obtained from the pattern generator is used as the adjustment signal for adjustments, the video output signal must satisfy the given specifications.

1. S VIDEO Input

Connect the oscilloscope to the Y signal terminal of the S VIDEO input terminal, and check that the sync signal of the Y signal is approximately <0.286> [0.30] V and that the amplitude of the video section is approximately <0.714> [0.70] V. (When a VTR with the S VIDEO output terminal is used, also check that the chroma signal and burst signal have not remained)

Connect the oscilloscope to the chroma signal terminal of the S VIDEO input terminal, and check that the burst signal amplitude of the chroma signal is approximately <0.286> [0.30] V and flat. and that the red signal amplitude of the chroma signal is approximately <0.66> [0.67] V. The Y and chroma signals used in the adjustment are shown in Fig. 5-3-2.

>: NTSC model

ſ 1: PAL model

2. VIDEO Input

Connect the oscilloscope to the VIDEO input terminal, and check that the sync signal amplitude of the video signal is approximately <0.286> [0.30] V, the amplitude of the video section is approximately <0.714> [0.70] V, the amplitude of the burst signal is approximately <0.286> [0.30] V and flat, and that the red signal amplitude of the chroma signal is approximately <0.66> [0.67] V. The video signal (color bar) used for adjustments is shown in Fig. 5-3-3.

>: NTSC model 1: PAL model

> NTAC: DSR-20MD : DSR-20MDP




Fig. 5-3-2. Color Bar Signal of Pattern Generator




Fig. 5-3-3. Color Bar Signal of Pattern Generator

3-1-5. Adjustment Tapes

Use the alignment tapes shown in the following table. Use tapes specified in the signal column of each adjustment.

Name	Use
SW/OL standard (XH2-3)	Switching position adjustment
Audio operation check (XH5-3 (NTSC), XH5-3P (PAL))	Audio system adjustment
System operation check (XH5-5 (NTSC), XH5-5P (PAL))	Operation check
BIST check (XH5-6 (NTSC), XH5-6P (PAL))	BIST check

Table 5-3-2.

Fig. 5-3-4. shows the 75% color bar signals recorded on the alignment tape for Audio Operation Check (NTSC).




Fig. 5-3-4. Color Bar Signal of Alignment Tapes

3-1-6. Input/ Output Level and Impedance

LINE IN

Video input BNC connector

Input signal: 1 Vp-p

(75 ohms unbalanced)

S Video input Mini DIN 4-pin

Luminance signal: 1 Vp-p

(75 ohms unbalanced)

Chrominance signal: 0.286 Vp-p (NTSC), 0.3 Vp-p (PAL),

(75 ohms unbalanced)

Audio input Phono jack (L, R)

Input level: 2 Vrms (full bit)

Input impedance: more than 47 kohms

LINE OUT

Video output BNC connector

Output signal: 1 Vp-p

(75 ohms unbalanced)

S Video output Mini DIN 4-pin

Luminance signal: 1 Vp-p

(75 ohms unbalanced)

Chrominance signal: 0.286 Vp-p

(NTSC), 0.3 Vp-p (PAL),

(75 ohms unbalanced)

Audio output Phono jack (L, R)

Output level: 2 Vrms (full bit)

Output impedance: less than 10 kohms

3-2. POWER SUPPLY SYSTEM ADJUSTMENT

1. Power Supply Voltage Check Power Block (U-2 Board)

ModePlaybackMeasuring InstrumentDigital voltmeterUNSW6V CheckPin ① of CN11Specified Value $6.0 \pm 0.5 \text{Vdc}$ UNSW3.1V CheckPin ② of CN11Measuring PointPin ② of CN11Specified Value $3.1 \pm 0.2 \text{Vdc}$ VIDEO5V, AUDIO5V CheckMeasuring PointMeasuring PointPin ③, ⑦ of CN11Specified Value $5.0 \pm 0.12 \text{Vdc}$ SW3.1V CheckMeasuring PointMeasuring PointPin ④ of CN11Specified Value $3.1 \pm 0.1 \text{Vdc}$ VIDEO-5V, AUDIO-5V CheckMeasuring PointPin ⑥, ⑨ of CN11Specified Value $-5.0 \pm 0.12 \text{Vdc}$ SW5V CheckMeasuring PointPin ⑥ of CN11Specified Value $5.0 \pm 0.12 \text{Vdc}$ DRUM6V CheckMeasuring PointPin ⑥ of CN10Specified Value $6.0 \pm 0.5 \text{Vdc}$ MOTOR14V CheckMeasuring PointPin ⑥ of CN10Specified Value $14.0 \pm 2 \text{Vdc}$	1 Ollor Blook (O 2 Bould)			
UNSW6V Check Measuring Point Pin ① of CN11 Specified Value 6.0 ± 0.5 Vdc UNSW3.1V Check Measuring Point Pin ② of CN11 Specified Value 3.1 ± 0.2 Vdc VIDEO5V, AUDIO5V Check Measuring Point Pin ③, ① of CN11 Specified Value 5.0 ± 0.12 Vdc SW3.1V Check Measuring Point Pin ④ of CN11 Specified Value 3.1 ± 0.1 Vdc VIDEO-5V, AUDIO-5V Check Measuring Point Pin ⑥, ⑨ of CN11 Specified Value -5.0 ± 0.12 Vdc SW5V Check Measuring Point Pin ⑥, ⑨ of CN11 Specified Value 5.0 ± 0.12 Vdc SW5V Check Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Pin ③ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Measuring Point Pin ⑥ of CN10	Mode	Playback		
Measuring Point Pin ① of CN11 Specified Value 6.0 ± 0.5 Vdc UNSW3.1V Check Measuring Point Pin ② of CN11 Specified Value 3.1 ± 0.2 Vdc VIDEO5V, AUDIO5V Check Measuring Point Pin ③, ⑦ of CN11 Specified Value 5.0 ± 0.12 Vdc SW3.1V Check Measuring Point Pin ④ of CN11 Specified Value 3.1 ± 0.1 Vdc VIDEO-5V, AUDIO-5V Check Measuring Point Pin ⑥, ⑨ of CN11 Specified Value -5.0 ± 0.12 Vdc SW5V Check Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Pin ④ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Measuring Point Pin ⑥ of CN10	Measuring Instrument	Digital voltmeter		
Specified Value 6.0 ± 0.5 Vdc UNSW3.1V Check Measuring Point Pin ② of CN11 Specified Value 3.1 ± 0.2 Vdc VIDEO5V, AUDIO5V Check Measuring Point Pin ③, ⑦ of CN11 Specified Value 5.0 ± 0.12 Vdc SW3.1V Check Measuring Point Pin ④ of CN11 Specified Value 3.1 ± 0.1 Vdc VIDEO-5V, AUDIO-5V Check Measuring Point Pin ⑥, ⑨ of CN11 Specified Value -5.0 ± 0.12 Vdc SW5V Check Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc SW5V Check Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Pin ③ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Measuring Point Pin ⑥ of CN10	UNSW6V Check			
UNSW3.1V Check Measuring Point Pin ② of CN11 Specified Value 3.1 ± 0.2 Vdc VIDEO5V, AUDIO5V Check Measuring Point Pin ③, ⑦ of CN11 Specified Value 5.0 ± 0.12 Vdc SW3.1V Check Measuring Point Pin ④ of CN11 Specified Value 3.1 ± 0.1 Vdc VIDEO-5V, AUDIO-5V Check Measuring Point Pin ⑥, ⑨ of CN11 Specified Value -5.0 ± 0.12 Vdc SW5V Check Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc SW5V Check Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Pin ④ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Measuring Point Pin ⑥ of CN10	Measuring Point	Pin ① of CN11		
Measuring Point Pin ② of CN11 Specified Value 3.1 ± 0.2 Vdc VIDEO5V, AUDIO5V Check Measuring Point Pin ③, ⑦ of CN11 Specified Value 5.0 ± 0.12 Vdc SW3.1V Check Measuring Point Pin ④ of CN11 Specified Value 3.1 ± 0.1 Vdc VIDEO−5V, AUDIO−5V Check Measuring Point Pin ⑥, ⑨ of CN11 Specified Value −5.0 ± 0.12 Vdc SW5V Check Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc SW5V Check Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Pin ④ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Measuring Point Pin ⑥ of CN10	Specified Value	$6.0 \pm 0.5 \text{Vdc}$		
Specified Value 3.1 ± 0.2 Vdc VIDEO5V, AUDIO5V Check Pin ③, ⑦ of CN11 Specified Value 5.0 ± 0.12 Vdc SW3.1V Check Pin ④ of CN11 Measuring Point Pin ④ of CN11 Specified Value 3.1 ± 0.1 Vdc VIDEO-5V, AUDIO-5V Check Measuring Point Measuring Point Pin ⑥, ⑨ of CN11 Specified Value -5.0 ± 0.12 Vdc SW5V Check Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Pin ④ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Pin ⑥ of CN10	UNSW3.1V Check			
VIDEO5V, AUDIO5V Check Measuring Point Pin ③, ⑦ of CN11 Specified Value 5.0 ± 0.12 Vdc SW3.1V Check Measuring Point Pin ④ of CN11 Specified Value 3.1 ± 0.1 Vdc VIDEO-5V, AUDIO-5V Check Measuring Point Pin ⑥, ⑨ of CN11 Specified Value -5.0 ± 0.12 Vdc SW5V Check Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Pin ⑥ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Measuring Point Pin ⑥ of CN10	Measuring Point	Pin ② of CN11		
Measuring Point Pin ③, ⑦ of CN11 Specified Value 5.0 ± 0.12 Vdc SW3.1V Check Pin ④ of CN11 Measuring Point Pin ④ of CN11 Specified Value 3.1 ± 0.1 Vdc VIDEO-5V, AUDIO-5V Check Measuring Point Measuring Point Pin ⑥, ⑨ of CN11 Specified Value -5.0 ± 0.12 Vdc SW5V Check Measuring Point Measuring Point Pin ⑥ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Pin ⑥ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Pin ⑥ of CN10	Specified Value	$3.1 \pm 0.2 \text{Vdc}$		
Specified Value 5.0 ± 0.12 Vdc SW3.1V Check Pin ④ of CN11 Measuring Point Pin ④ of CN11 Specified Value 3.1 ± 0.1 Vdc VIDEO-5V, AUDIO-5V Check Measuring Point Measuring Point Pin ⑥, ⑨ of CN11 Specified Value -5.0 ± 0.12 Vdc SW5V Check Measuring Point Measuring Point Pin ⑥ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Measuring Point Pin ⑥ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Pin ⑥ of CN10	VIDEO5V, AUDIO5V (Check		
SW3.1V Check Measuring Point Pin ④ of CN11 Specified Value 3.1 ± 0.1 Vdc VIDEO-5V, AUDIO-5V Check Measuring Point Pin ⑥, ⑨ of CN11 Specified Value -5.0 ± 0.12 Vdc SW5V Check Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Pin ④ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Measuring Point Pin ⑥ of CN10	Measuring Point	Pin ③, ⑦ of CN11		
Measuring Point Pin ④ of CN11 Specified Value 3.1 ± 0.1 Vdc VIDEO-5V, AUDIO-5V Check Measuring Point Pin ⑥, ⑨ of CN11 Specified Value -5.0 ± 0.12 Vdc SW5V Check Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Pin ④ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Measuring Point Pin ⑥ of CN10	Specified Value	5.0 ± 0.12 Vdc		
Specified Value 3.1 ± 0.1 Vdc VIDEO-5V, AUDIO-5V Check Measuring Point Pin ⑥, ⑨ of CN11 Specified Value -5.0 ± 0.12 Vdc SW5V Check Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Pin ④ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Pin ⑥ of CN10	SW3.1V Check			
VIDEO-5V, AUDIO-5V Check Measuring Point Pin ⑥, ⑨ of CN11 Specified Value -5.0 ± 0.12 Vdc SW5V Check Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Pin ④ of CN10 Measuring Point Pin ④ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Measuring Point Pin ⑥ of CN10	Measuring Point	Pin ④ of CN11		
Measuring Point Pin ⑥, ⑨ of CN11 Specified Value −5.0 ± 0.12 Vdc SW5V Check Fin ⑥ of CN11 Measuring Point Pin ⑥ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Pin ⑥ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Pin ⑥ of CN10 Measuring Point Pin ⑥ of CN10	Specified Value	3.1 ± 0.1 Vdc		
Specified Value −5.0 ± 0.12 Vdc SW5V Check Pin ③ of CN11 Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Pin ④ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Pin ⑥ of CN10	VIDEO-5V, AUDIO-5V	/ Check		
SW5V Check Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Pin ④ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Measuring Point Pin ⑥ of CN10	Measuring Point	Pin 6 , 9 of CN11		
Measuring Point Pin ③ of CN11 Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Measuring Point Pin ④ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Measuring Point Pin ⑥ of CN10	Specified Value	-5.0 ± 0.12 Vdc		
Specified Value 5.0 ± 0.12 Vdc DRUM6V Check Pin ② of CN10 Measuring Point Pin ③ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Pin ⑥ of CN10	SW5V Check			
DRUM6V Check Measuring Point Pin ④ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Pin ⑥ of CN10	Measuring Point	Pin ③ of CN11		
Measuring Point Pin ⓓ of CN10 Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Pin ⑥ of CN10	Specified Value	5.0 ± 0.12 Vdc		
Specified Value 6.0 ± 0.5 Vdc MOTOR14V Check Pin (6) of CN10	DRUM6V Check			
MOTOR14V Check Measuring Point Pin (a) of CN10	Measuring Point	Pin ④ of CN10		
Measuring Point Pin (6) of CN10	Specified Value	6.0 ± 0.5 Vdc		
	MOTOR14V Check			
Specified Value 14.0 ± 2 Vdc	Measuring Point	Pin 6 of CN10		
	Specified Value	14.0 ± 2 Vdc		

2. Video/Audio Block Power Supply Voltage Check Power Block (U-2 Board)

Mode	Playback
Measuring Instrument	Digital voltmeter
UNSW6V Check	
Measuring Point	Pin ② of CN12
Specified Value	6.0 ± 0.5 Vdc
UNSW3.1V Check	
Measuring Point	Pin ④ of CN12
Specified Value	3.1 ± 0.2 Vdc
UNSW-9V Check	
Measuring Point	Pin ⑦ of CN12
Specified Value	−9 ± 0.5 Vdc
UNSW14V Check	
Measuring Point	Pin ® of CN12
Specified Value	14 ± 2.0 Vdc
UNSW12V Check	
Measuring Point	Pin ③ of CN12
Specified Value	12.0 ± 1 Vdc

3-3. SYSTEM CONTROL SYSTEM ADJUSTMENT

1. Initializing the C, D, E Page Data

Note 1: If "Initializing the C, D, E Page Data" is performed, all data of the C page, D page and E page will be initialized.

Note 2: If the C, D, E page data has been initialized, "Modification of C, D, E page Data" and all adjustments need to be performed again.

Mode	E-E
Signal	Arbitrary
Adjustment Page	С
Adjustment Address	00 to 6F
Adjustment Page	D
Adjustment Address	00 to 4F
Adjustment Page	Е
Adjustment Address	00 to 3B

2. Input of C page Initial Data

Input method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: 4, address: 02, set data: 01, and press the PAUSE button of the adjusting remote commander.
- 3) Select page: 4, address: 02, and confirm that the data change in the order of "01" \rightarrow "03" \rightarrow "05" \rightarrow "00".
- 4) Modify the C page data. (Refer to C page address)

3. Input of D page Initial Data Input method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: 2, address: 00, set data: 2D, and press the PAUSE button of the adjusting remote commander.
- 3) Select page: 2, address: 01, set data: 2D, and press the PAUSE button of the adjusting remote commander.
- 4) Select page: 2, address: 02, and confirm that the data is "01".
- 5) Modify the D page data. (Refer to D page address)

4. Input of E page Initial Data Input method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: 5, address: 00, set data: 2D, and press the PAUSE button of the adjusting remote commander.
- 3) Select page: 5, address: 01, set data: 2D, and press the PAUSE button of the adjusting remote commander.
- 4) Select page: 5, address: 02, and confirm that the data is "01".
- 5) Modify the E page data. (Refer to E page address)

5. Modification of C, D, E, Page Data

If the C, D, E page data has been initialized, change the data of the "Fixed data-2" address shown in the following tables by manual input.

Modifying Method:

- 1) Before changing the data, select page: 0, address: 01, and set data: 01.
- New data for changing are not shown in the tables because they are different in destination. When changing the data, copy the data built in the same model.

Note: If copy the data built in the different model, this set may not operate.

- 3) When changing the data, press the PAUSE button of the adjusting remote commander each time when setting new data to write the data in the non-volatile memory.
- 4) Check that the data of adjustment addresses is the initial value. If not, change the data to the initial value.
- 5) After completing "Modification of C, D, E Page Data", select page: 0, address: 01, and set data: 00. Also perform all adjustments.

6. Page C Address List

Note 1: Fixed data 1: Initialized data. (Refer to 2. Input of C Page Initial Data)

Fixed data 2: Modified data (Refer to 5. Modification of

Fixed data 2: Modified data. (Refer to 5. Modification of C, D, E, Page Data)

Address	Initial Value	Remark	
00	Fixed data 1 (Initial data)		
01	Fixed data 2 (Changed data. Read from same model and		
01	copy it.)		
02 to 07	Fixed data 1 (Ir		
08	Extraction of the second secon	hanged data. Read from same model and	
	copy it.)		
09	Fixed data 1 (In		
OA to 0C	Fixed data 1 (Ir		
OD.	Fixed data 2 (C copy it.)	hanged data. Read from same model and	
0E,0F	Fixed data 1 (In	nitial data)	
10 to 19	Fixed data 1 (In	nitial data)	
1A to 1F	Fixed data 1 (Ir	nitial data)	
20 to 29	Fixed data 1 (Ir	nitial data)	
2A to 2F	Fixed data 1 (Initial data)		
30 to 39	00	Emargency memory address	
3A, 3B	00	Emargency memory address	
3C, 3D	F8	PLL fo adjustment	
3E, 3F	70	Recording current adjustment	
40, 41	C0	AEQ adjustment	
42, 43	90	AEQ adjustment	
44	86	AGC Center level adjustment	
45	Fixed data 1 (Ir	nitial data)	
46	86	PLL Capture range adjustment	
47	C8	CLK delay adjustment	
48, 49	Fixed data 1 (Ir	nitial data)	
4A, 4B	Fixed data 1 (Initial data)		
4C to 4F	00	Switching position adjustment	
50	54	Capstan FG duty adjustment	
51	31	Capstan FG duty adjustment	
52 to 59	Fixed data 1 (Initial data)		
5A	00 AEQ adjustment		
5B to 5F	Fixed data 1 (Ir	nitial data)	
60 to 69	Fixed data 1 (Initial data)		
6A to 6F	Fixed data 1 (Initial data)		

Table 5-3-3.

7. Page D Address List

Note 1: Fixed data 1: Initialized data. (Refer to 3. Input of D Page Initial Data)

Fixed data 2: Modified data. (Refer to 5. Modification of C, D, E, Page Data)

Address	Initial Value	Remark		
00 to 0F				
10 to 12	Fixed data 1 (Initial data)			
13	Fixed data 2 (Changed data, Read from same model and copy it.)			
14	Fixed data 1 (In	nitial data)		
15 to 18	Fixed data 2 (C copy it.)	hanged data. Read from same model and		
19	Fixed data 1 (In	nitial data)		
1A to 1E	Fixed data 1 (In	nitial data)		
1 F -	Fixed data 2 (C copy it.)	hanged data. Read from same model and		
20 to 29	Fixed data 1 (In	nitial data)		
2A, 2B	Fixed data 1 (In	nitial data)		
2C to 2F	Fixed data 2 (Changed data, Read from same model and copy it.)			
30 to 32	Fixed data 1 (Initial data)			
33	59	IC422 27 MHz XTAL fo adjustment		
34	19	Playback CR signal level adjustment/ Encoder R-Y input level adjustment		
35	37	Playback CB signal level adjustment/ Encoder B-Y input level adjustment		
36	18	Playback Y signal level adjustment/ Y output level adjustment		
37 to 39	Fixed data 1 (In	nitial data)		
3A to 3F	Fixed data 1 (In			
40	Fixed data 1 (In			
41	00	Playback burst level adjustment		
42	Fixed data 2 (Changed data. Read from same model and copy it.)			
43	Fixed data 1 (Initial data)			
44 to 46	Fixed data 2 (Changed data. Read from same model and copy it.)			
47 to 49	Fixed data 1 (Initial data)			
- 4 A	Fixed data 2 (Changed data. Read from same model and copy it.)			
4B to 4F	Fixed data 1 (Initial data)			

Table 5-3-4.

8. Page E Address List

Note 1: Fixed data 1: Initialized data. (Refer to 4. Input of E Page Initial Data)

Fixed data 2: Modified data. (Refer to 5. Modification of C, D, E, Page Data)

Address	Initial Value	Remark
00 to 1B	Fixed data 1 (Initial data)	
The second of th	Fixed data 2 (Copy it.)	Changed data. Read from same model and
1D 1E 1F	8D 86 80	Battery down adjustment and check
20 to 23	Fixed data 1 (Initial data)	
24	Fixed data 2 (Changed data, Read from same model and copy it.)	
25 to 3F	Fixed data 1 (Initial data)	

Table 5-3-5.

3-4. SERVO SYSTEM ADJUSTMENTS

1. Switching Position Adjustment (CM-56 Board)

Mode	Playback
signal	SW/OL reference tape
Measurement Point	Page: 3, address: 03 on displayed data of adjusting remote commander
Measuring Instrument	Adjusting remote commander
Adjustment Page	С
Adjustment Address	4C, 4D, 4E, 4F
Specified Value	"00"

Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- Select page: 3, address: 01, set data: 0E, and press the PAUSE button of the adjusting remote commander.
- Select page: 3, address: 02, and confirm that the data changes from "0E" to "00".
- 4) Select page: 3, address: 03, and confirm that the data is "00".
- 5) Turn OFF the HOLD switch on he adjusting remote commander and wait for more than 2 seconds. (The adjusted data are automatically written to page: C, address: 4C to 4F)
- 6) Turn ON the HOLD switch on the adjusting remote commander.
- 7) Select page: 0, address: 01, and set data: 00.
- 8) Stop the tape playback.
- 9) Turn the POWER switch OFF.

2. Capstan FG Duty Adjustment (CM-56 Board)

Mode	Playback
signal	Arbitrary tape
Measurement Point	Page: 3, address: 03 on displayed data of adjusting remote commander
Measuring Instrument	Adjusting remote commander
Adjustment Page	С
Adjustment Address	50, 51
Specified Value	"00"

Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- Select page: 3, address: 01, set data: 15, and press the PAUSE button of the adjusting remote commander.
- Select page: 3, address: 02, and confirm that the data changes from "15" to "00".
- 4) Select page: 3, address: 03, and confirm that the data is the following value

When "00": Normal

When "01": Faulty

Perform the following adjustment only when "00" is displayed.

5) Select page: 3, address: 04 and 05, read the data, and take the values as Do4 and Do5 respectively.

(The data on page: 3, address: 05 must be 2F to 3F)

- 6) Select page: C, address: 50, set data: D₀₄, and press the PAUSE button of the adjusting remote commander.
- 7) Select page: C, address: 51, set data: Dos, and press the PAUSE button of the adjusting remote commander.
- 8) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 9) Select page: 0, address: 01, and set data: 00.
- 10) Stop the tape playback.
- 11) Turn the POWER switch OFF.

3-5. VIDEO SYSTEM ADJUSTMENTS

3-5-1. RP-228 Board Adjustments

1. Recording Current Adjustment (RP-228 Board)

Mode	E-E
Measurement Point	ODDch adjustment CH1: Pin (a) of CN771 (CL812) CH2: Pin (b) of CN771 (CL813) EVENch adjustment CH1: Pin (2) of CN771 (CL816) CH1: Pin (3) of CN771 (CL815)
Measuring Instrument	Oscilloscope ADD mode CH2 INV mode
Adjustment Page	С
Adjustment Address	3E, 3F
Specified Value	$A = 4.1 \pm 0.1 \text{ Vp-p}$

Connection: Disconnect CN771 and connect as follows.

- 1) ODDch adjustment: Connect a 180 Ω resistor between Pin (6) of CN771 (CL812) and Pin (5) of CN771 (CL813).
- EVENch adjustment: Connect a 180 Ω resistor between Pin
 ② of CN771 (CL816) and Pin
 ③ of CN771 (CL815).
 180 Ω resistor (Parts code: 1-249-408-11)

Adjusting method:

- 1) Equalize the vertical range of CH1 and CH2 of the oscilloscope.
- Set the oscilloscope to the ADD mode, and set CH2 to the INV mode.
- 3) Select page: 0, address: 01, and set data: 01.
- 4) Select page: 3, address: 01, set data: 0C, and press the PAUSE button of the adjusting remote commander.
- 5) Select page: 3, address: 34, and set data: 01.
- 6) Select page: C, address: 3F (ODDch adjustment) or 3E (EVENch adjustment), change the data, and adjust the signal voltage (A) to the specified value, press the PAUSE button on the adjusting remote commander.
- 7) Select page: 3, address: 34, and set data: 04.
- 8) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 9) Select page: 0, address: 01, and set data: 00.




Fig. 5-3-5.

2. PLL fo Adjustment (RP-228 Board)

Mode	E-E
Measurement Point Measuring Instrument	Displayed data of page: 3, address: 04
Adjustment Page	С
Adjustment Address	3D, 3C
Specified Value	Displayed data is "FD" to "FF", "00" to "03" ("FF", "00" are center values)

Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: 3, address: 01, set data: 05, and press the PAUSE button of the adjusting remote commander.
- 3) Select page: 3, address: 36, and set data: 04.
- 4) Select page: 3, address: 04, and check that the average value D₀₄ of the displayed data is "FD" to "FF" or "00" to "03". If outside this range, select page: C, address: 3C, change the data, and check again.

[If Do4 is "80" to "FC"]

Select page: C, address: 3C, and decrease the data. (As the data is to be rewritten, press the PAUSE button of the adjusting remote commander)

[If Do4 is "04" to "7F"]

Select page: C, address: 3C, and increase the data. (As the data is to be rewritten, press the PAUSE button of the adjusting remote commander)

- 5) Select page: 3, address: 36, and set data: 05.
- 6) Select page: 3, address: 04, and check that the average value D₀₄ of displayed data is "FD" to "FF" or "00" to "03". If outside this range, select page: C, address: 3D, change the data, and check again.

[If Do4 is "80" to "FC"]

Select page: C, address: 3D, and decrease the data. (As the data is to be rewritten, press the PAUSE button of the adjusting remote commander)

[If Do4 is "04" to "7F"]

Select page: C, address: 3D, and increase the data. (As the data is to be rewritten, press the PAUSE button of the adjusting remote commander)

- 7) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 8) Select page: 3, address: 36, and set data: 02.
- 9) Select page: 0, address: 01, and set data: 00.

3. CLK DELAY Adjustment (RP-228 Board)

Mode	Recording/playback
Signal	Color bar
Measurement Point	CH1: Pin [®] of CN775 (C1ERP) CH2: Pin [®] of CN775 (JSWP)
Measuring Instrument	Oscilloscope Trigger source: CH2
Adjustment Page	С
Adjustment Address	47

Adjusting method:

- 1) Record color bar signal for two minutes on any tape.
- Select page: 0, address: 01, and set data: 01.
- Write the following data in page: C, address: 40 to 43, 47, 4B,

To write the data, press the PAUSE button of the adjusting remote commander each time data is set.

Page: C, address: 40, data: C0

Page: C, address: 41, data: C0

Page: C, address: 42, data: 90

Page: C, address: 43, data: 90

Page: C, address: 47, data: C8

Page: C, address: 4B, data: 80

Page: C. address: 5A, data: 00

4) Playback the part recorded with the color bar.

- 5) Select page: C, address: 47, increase the data, and read the data D1 when the CH1 pulse is set to the whole audio and
- 6) Select page: C, address: 47, decrease the data, and read the data D2 when the CH1 pulse is set to the whole audio and
- 7) Obtain the average value of D1 and D2, and take it as D3.
- 8) Select page: C, address: 47, set data: D₃, and press the PAUSE button of the adjusting remote commander.
- Select page: C, address: 4B, set data: 0E, and press the PAUSE button of the adjusting remote commander.
- 10) Select page: C, address: 5A, set data: 8C, and press the PAUSE button of the adjusting remote commander.
- 11) Select page: 0, address: 01, and set data: 00.
- 12) After completing the adjusting, perform "5. AEQ Adjustment".

When the CH1 pulse is not set. CH2 EVEN ch When the CH1 pulse is set. CH₁ CH₂ EVEN ch 3.33 msec

Fig. 5-3-6.

4. AGC Center Level Adjustment (RP-228 Board)

Mode	Recording/playback
Signal	Color bar
Measurement Point	CH1: Pin [®] of CN775 (C1ERP) CH2: Pin [®] of CN775 (JSWP)
Measuring Instrument	Oscilloscope Trigger source: CH2
Adjustment Page	С
Adjustment Address	44

Adjusting method:

- 1) Record color bar signal for two minutes on any tape.
- Select page: 0, address: 01, and set data: 01.
- Write the following data in page: C, addresses: 40 to 44, 4B, 5A.

To write the data, press the PAUSE button of the adjusting remote commander each time data is set.

Page: C, address: 40, data: C0

Page: C, address: 41, data: C0

Page: C, address: 42, data: 90

Page: C, address: 43, data: 90

Page: C, address: 44, data: 90

Page: C, address: 4B, data: 80

Page: C, address: 5A, data: 00

- 4) Playback the part recorded with the color bar signal.
- Select page: C, address: 44, increase the data, and read the data D1 when the CH1 pulse is set to the whole audio and
- 6) Select page: C, address: 44, decrease data, and read the data D2 when the CH1 pulse is set to the whole audio and video areas.
- Obtain the average value of D₁ and D₂, and take it as D₃.
- Select page: C, address: 44, set data: D3, and press the PAUSE button of the adjusting remote commander.
- Select page: C, address: 4B, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 10) Select page: C, address: 5A, set data: 8C, and press the PAUSE button of the adjusting remote commander.
- 11) Select page: 0, address: 01, and set data: 00.
- 12) After completing the adjusting, perform "5. AEQ Adjustment".




Fig. 5-3-7.

5. AEQ Adjustment (RP-228 Board)

Mode	Recording/playback
Signal	Arbitrary
Measurement Point	Pin ® of CN775 (RF MONITOR) (Note 1)
Measuring Instrument	Oscilloscope
Adjustment Page	С
Adjustment Address	40, 41, 42, 43, 5A

Note 1: Connect a 75 Ω resistor between Pin (3) and (7) (GND) of CN 775.

75 Ω resistor (Parts code: 1-247-804-11)

Note 2: Use the DVM60ME tape or equivalents.

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.

2) Select page: C, address: 4B, set data: 80, and press the PAUSE button of the adjusting remote commander.

3) Write data in page: C, addresses: 40 to 43, and 5A as shown in the following table.

To write the data, press the PAUSE button of the adjusting remote commander each time data is set.

Address	Data
40	C0
41	C0
42	90
43	90
5A	00

- 4) Record color bar signal for one minute from the tape top.
- 5) Rewind the tape, and play back the part recorded.
- 6) When the RF output stabilizes, select page: 3, address: 01, and set data: 07, and press the PAUSE button of the adjusting remote commander.
- About 20 to 30 seconds after pressing the PAUSE button, select page: 3, address: 02, and check that the data changes from "07" to "00".
- 8) Select page: 3, address: 03, and check that the data is the following value.

When "00": Normal

When "01": EVENch is faulty When "02": ODDch is faulty

When "03": EVENch and ODDch are faulty

Perform the following procedure only when "00" is displayed.

9) Select page: 3, address: 04 to 07, read the data, and take the values as Do4, Do5, Do6, and Do7.

- 10) Select page: C, address: 40, set data: Do4, and press the PAUSE button of the adjusting remote commander.
- 11) Select page: C, address: 42, set data: Dos, and press the PAUSE button of the adjusting remote commander.
- 12) Select page: C, address: 41, set data: Do6, and press the PAUSE button of the adjusting remote commander.
- 13) Select page: C, address: 43, set data: Do7, and press the PAUSE button of the adjusting remote commander.
- 14) Select page: C, address: 5A, set data: 8C, and press the PAUSE button of the adjusting remote commander.
- 15) Select page: C, address: 4B, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 16) Select page: 0, address: 01, and set data: 00.

6. PLL Capture Range Adjustment (RP-228 Board)

Mode	Recording/Playback
Signal	Color bar
Measurement Point	CH1: Pin [®] of CN775 (C1ERP) CH2: Pin [®] of CN775 (JSWP)
Measuring Instrument	Oscilloscope Trigger source: CH2
Adjustment Page	С
Adjustment Address	46

Adjusting method:

- 1) Record color bar signal for two minutes on any tape.
- 2) Select page: 0, address: 01, and set data: 01.
- 3) Write the following data in page: C, addresses: 4B and 5A.
 To write the data, press the PAUSE button of the adjusting remote commander each time data is set.

Page: C, address: 4B, data: 80


Page: C, address: 5A, data: 00

- 4) Playback the part recorded with the color bar signal.
- 5) Select page: C, address: 46, set data: 80, and press the PAUSE button of the adjusting remote commander.
- 6) Select page: C, address: 46, set the data to "60", and check that the pulse is not set at the audio area head of the ERRP waveform's ODDch of the oscilloscope (CH1).
- 7) Select page: C, address: 46, set the data to "A0", and check that the pulse is not set at the audio area head of the C1ERP waveform's ODDch of the oscilloscope (CH1). After confirming steps 6) and 7), select page: C, address: 46.

set data: 80 again and proceed to step 12).

- 8) If the pulse is set in steps 6) and 7), select page: C, address: 46, increase the data from "80", and read the data D1 when the pulse is set at the audio area head of CH1.
- Select page: C, address: 46, decrease the data from "80", and read the data D₂ when the pulse is set at the audio area head of CH1.
- 10) Obtain the average value of D1 and D2, and take it as D3.
- 11) Select page: C, address: 46, set data: D₃, and press the PAUSE button of the adjusting remote commander.
- 12) Select page: C, address: 4B, set data: 00, and press the PAUSE button of the adjusting remote commander.
- 13) Select page: C, address: 5A, set data: 8C, and press the PAUSE button of the adjusting remote commander.
- 14) Select page: 0, address: 01, and set data: 00.

When the pulse is not set at the audio area head.



When the pulse is set at the audio area head.




Fig. 5-3-8.

7. IC774 41.85 MHz VCO Check (RP-228 Board)

Mode	E-E
Signal	Arbitrary
Measurement Point	Page: 3, address: 39 on displayed data of
Measuring Instrument	adjusting remote commander
Adjustment Value	"37" to "C9" (0.6 to 2.2 Vdc)

Checking method:

1) Select page: 3, address: 39, and check that the displayed data is "37" to "C9".

3-5-2. JC-19 Board Adjustments

A/D Converter Reference Voltage Adjustment 1 (JC-19 Board)

Mode	E-E
Signal	Arbitrary
Measurement Point	Pin (5) of IC013 (CL061)
Measuring Instrument	Digital voltmeter
Adjusting Element	RV001
Specified Value	$A = 2.83 \pm 0.01 \text{ Vdc}$

Adjusting method:

1) Set the VRT voltage (A) to the specified value using RV001.

2. A/D Converter Reference Voltage Adjustment 2 (JC-19 Board)

Mode	E-E
Signal	Arbitrary
Measurement Point	Pin ③ of IC013 (CL062)
Measuring Instrument	Digital voltmeter
Adjusting Element	RV002
Specified Value	$A = 0.96 \pm 0.01 \text{ Vdc}$

Adjusting method:

1) Set the VBT voltage (A) to the specified value using RV002.

3. Y Signal Clamp Reference Voltage Adjustment (JC-19 Board)

Mode	E-E
Signal	Color bar
Measurement Point	Pin (8) of IC011 (CL054)
Measuring Instrument	Digital voltmeter
Adjusting Element	RV011
Specified Value	$A = 1.150 \pm 0.005 \text{ Vdc}$

Connection: Connect a jumper wire between Pin ⑥ of IC018 (CL150) and GND.

Adjusting method:

1) Set the Y signal clamp reference voltage (A) to the specified value using RV011.

4. CR Signal Clamp Reference Voltage Adjustment (JC-19 Board)

Mode	E-E
Signal	Color bar
Measurement Point	Pin (8) of IC010 (CL052)
Measuring Instrument	Digital voltmeter
Adjusting Element	RV010
Specified Value	$A = 1.900 \pm 0.005 \text{Vdc}$

Connection: Connect a jumper wire between Pin **(6)** of IC018 (CL150) and GND.

Adjusting method:

1) Set the CR signal clamp reference voltage (A) to the specified value using RV010.

5. CB Signal Clamp Reference Voltage Adjustment (JC-19 Board)

Mode	E-E
Signal	Color bar
Measurement Point	Pin ® of IC009 (CL053)
Measuring Instrument	Digital voltmeter
Adjusting Element	RV012
Specified Value	$A = 1.900 \pm 0.005 \text{Vdc}$

Connection: Connect a jumper wire between Pin (a) of IC018 (CL150) and GND.

Adjusting method:

1) Set the CB signal clamp reference voltage (A) to the specified value using RV012.

6. Playback Y Signal Level Adjustment (JC-19 Board)

Mode	Recording
Signal	DV input (Note 1)
Measurement Point	Pin ^(a) of CN104 or pin ^(a) of CN102 on VA-102 board
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	36
Specified Value	$A = 0.43 \pm 0.04 \text{ V (NTSC)}$ $A = 0.41 \pm 0.04 \text{ V (PAL)}$

Note 1: Generate color bar signal with NTSC: DCR-VX1000/PAL: DCR-VX1000E and enter it to the DV terminal. (How to generate color bars: Connect the adjusting remote commander to the NTSC: DCR-VX1000/PAL: DCR-VX1000E, select page: 5, address: 02, and set data: 09. After adjustment, be sure to return the data to "00")

Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: D, address: 36, change data, and adjust the Y signal level (A) to the specified value.
- 3) Select page: 0, address: 01, and set data: 00.




Fig. 5-3-9.

7. Playback CR Signal Level Adjustment (JC-19 Board)

Mode	Recording
Signal	DV input (Note 1)
Measurement Point	Pin ⁽¹⁾ of CN104 or pin ⁽²⁾ of CN102 on VA-102 board
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	34
Specified Value	$A = 540 \pm 10 \text{ mV}$

Note 1: Generate color bar signal with NTSC: DCR-VX1000/PAL: DCR-VX1000E and enter it to the DV terminal. (How to generate color bars: Connect the adjusting remote commander to the NTSC: DCR-VX1000/PAL: DCR-VX1000E, select page: 5, address: 02, and set data: 09. After adjustment, be sure to return the data to "00")

Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: D, address: 34, change data, and adjust the CR signal level (A) to the specified value.
- 3) Select page: 0, address: 01, and set data: 00.




Fig. 5-3-10.

8. Playback CB Signal Level Adjustment (JC-19 Board)


Mode	Recording
Signal	DV input (Note 1)
Measurement Point	Pin ② of CN104 or pin ③ of CN102 on VA-102 board
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	35
Specified Value	$A = 390 \pm 10 \text{ mV}$

Note 1: Generate color bar signal with NTSC: DCR-VX1000/PAL: DCR-VX1000E and enter it to the DV terminal. (How to generate color bars: Connect the adjusting remote commander to the NTSC: DCR-VX1000/PAL: DCR-VX1000E, select page: 5, address: 02, and set data: 09. After adjustment, be sure to return the data to "00")

Adjusting method:

- 1) Select page: 0, address: 01, and set data: 00.
- 2) Select page: D, address: 35, change data, and adjust the CB signal level (A) to the specified value.
- 3) Select page: 0, address: 01, and set data: 00.

For NTSC model



For PAL model




Fig. 5-3-11.

9. IC422 27MHz XTAL fo Adjustment (JC-19 Board)

Mode	Playback
Signal	Arbitrary tape
Measurement Point	Pin @ of IC442 (CL479)
Measuring Instrument	Frequency counter
Adjustment Page	D
Adjustment Address	33
Specified Value	$f = 13500000 \pm 100 \text{ Hz}$

Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: D, address: 33, change data, and adjust the clock frequency (f) to the specified value.
- 3) Press the PAUSE button on the adjusting remote commander.
- 4) Select page: 0, address: 01, and set data: 00.

10. AFC Preliminary Adjustment (JC-19 Board)

Mode	Recording
Signal	Color bar
Measurement Point	Pin (9) of IC205 (CL214)
Measuring Instrument	Digital voltmeter
Adjusting Element	CT201
Specified Value	$A = 1.9 \pm 0.5 \text{ Vdc}$

Adjusting method:

1) Set the DC voltage (A) to the specified value using CT201.

11. AFC Picture Frame Adjustment (JC-19 Board)

Mode	Recording
Signal	Color bar (Video input) (Note 1)
Measurement Point	CH1: Pin ② of IC017 (CL051) CH2: Pin ② of IC205 (CL222)
Measuring Instrument	Oscilloscope
Adjusting Element	RV201
Specified Value	$T = 110 \pm 10 \text{ nsec}$

Note 1: Set "VIDEO" mode with the INPUT SELECT button on the front panel.

Adjusting method:

1) Set the time difference (T) between the H SYNC falling and AFH rising to the specified value using RV201.




Fig. 5-3-12.

12. AFC Adjustment (JC-19 Board)

Mode	Recording	
Signal	Color bar	
Measurement Point	Pin (9) of IC205 (CL214)	
Measuring Instrument	Digital voltmeter	
Adjusting Element	CT201	
Specified Value	$A = 1.80 \pm 0.05 \text{Vdc}$	

Adjusting method:

1) Set the DC voltage (A) to the specified value using CT201.

3-5-3. VA-102 Board Adjustments

1. AGC Adjustment (VA-102 Board)


Mode	E-E
Signal	Color bar (VIDEO input) (Note 1)
Measurement Point	Pin 19 of IC205 (CL220)
Measuring Instrument	Oscilloscope
Adjustment Element	RV202
Specified Value	A = 1.428 ± 0.02 V (NTSC) A = 1.400 ± 0.02 V (PAL)

Note 1: Set "VIDEO" mode with the INPUT SELECT button on the front panel.


Adjusting method:

1) Set the Y signal level (A) to the specified value using RV202.

For NTSC model



For PAL model



2. Analog E-E VIDEO Signal Output Level Adjustment (VA-102 Board)

Mode	E-E
Signal	Color bar (S VIDEO input) (Note 1)
Measurement Point	Pin (9) of IC401 (CL434)
Measuring Instrument	Oscilloscope
Adjustment Element	RV401, RV404
Specified Value	A = 0.714 ± 0.01 V (NTSC) A = 0.700 ± 0.01 V (PAL) B = 280 ± 10 mV (NTSC) B = 300 ± 10 mV (PAL)

Note 1: Set "S VIDEO" mode with the INPUT SELECT button on the front panel.


Note 2: Terminate the video output terminal using a 75 Ω resistor.

75 Ω resistor (Parts code: 1-247-804-11)

Adjusting method:

- 1) Set the Y signal level (A) to the specified value using RV401.
- 2) Set the burst signal level (B) to the specified value using RV404.

For NTSC model






Fig. 5-3-14.

3. Analog E-E Y Signal Output Level Check (VA-102 Board)

Mode	E-E
Signal	Color bar (S VIDEO input) (Note 1)
Measurement Point	Pin ③ of CN401 (CL436)
Measuring Instrument	Oscilloscope
Specified Value	A = 0.714 ± 0.02 V (NTSC) A = 0.700 ± 0.02 V (PAL)

Note 1: Set "S VIDEO" mode with the INPUT SELECT button on the front panel.


Note 2: Terminate the Y signal terminal of the S video output terminal using a 75 Ω resistor.

75 Ω resistor (Parts code: 1-247-804-11)

Checking method:

1) Check that the Y signal level (A) is the specified value.

For NTSC model



For PAL model




Fig. 5-3-15.

4. Analog E-E Chroma Signal Output Level Check (VA-102 Board)

Mode	E-E
Signal	Color bar (S VIDEO input) (Note 1)
Measurement Point	Pin ① of IC401 (CL435)
Measuring Instrument	Oscilloscope
Specified Value	$A = 286 \pm 20 \text{ mV (NTSC)}$ $A = 300 \pm 20 \text{ mV (PAL)}$


Note 1: Set "S VIDEO" mode with the INPUT SELECT button on the front panel.

Note 2: Terminate the Chroma signal terminal of the S video output terminal using a 75 Ω resistor. 75 Ω resistor (Parts code: 1-247-804-11)

Checking method:

1) Check that the burst signal level (A) is the specified value.

For NTSC model






Fig. 5-3-16.

Decoder VXO Freerunning Frequency Adjustment (VA-102 Board)

Mode	E-E
Signal	Color bar (S VIDEO input) (Note 2) (Chroma signal OFF)
Measurement Point	TP201 (CL210)
Measuring Instrument	Frequency coutner
Adjustment Element	CT201
Specified Value	f = 3579545 ± 30 Hz (NTSC) f = 4433618 ± 20 Hz (PAL)

Note 1: Connect the frequency counter via high input impedance equipment such as an oscilloscope.

Note 2: Set "S VIDEO" mode with the INPUT SELECT button on the front panel.

Adjusting method:

 Set the VXO OSC frequency (f) to the specified value using CT201.

6. Video Input Y/C Separation Adjustment (VA-102 Board)

(1) Y Signal Output Level Adjustment

Mode	E-E
Signal	Color bar (VIDEO input) (Note 1)
Measurement Point	Pin ① of IC202 (CL202)
Measuring Instrument	Oscilloscope
Adjustment Element	RV203
Specified Value	A= 0.714 ± 0.01 V (NTSC) A= 0.700 ± 0.01 V (PAL)

Note 1: Set "VIDEO" mode with the INPUT SELECT button on the front panel.


Note 2: Terminate the video output terminal using a 75 Ω resistor.

75 Ω resistor (Parts code: 1-247-804-11)

Adjusting method:

1) Set the Y signal level (A) to the specified value using RV203.

For NTSC model






Fig. 5-3-17.

(2) Chroma Signal Output Level Adjustment

Mode	E-E
Signal	Color bar (VIDEO input) (Note 1)
Measurement Point	Emitter of Q202 (CL203)
Measuring Instrument	Oscilloscope
Adjustment Element	RV201
Specified Value	A = 286 ± 10 mV (NTSC) A = 300 ± 10 mV (PAL)

Note 1: Set "VIDEO" mode with the INPUT SELECT button on the front panel.


Note 2: Terminate the video output terminal using a 75 Ω resistor.

75 Ω resistor (Parts code: 1-247-804-11)

Adjusting method:

1) Set the burst signal level (A) to the specified value using RV201.

For NTSC model



For PAL model




Fig. 5-3-18.

7. Decoder HUE Adjustment (VA-102 Board)


Mode	E-E
Signal	Color bar (S VIDEO input) (Note 1)
Measurement Point	Pin ® of IC102 (CL144)
Measuring Instrument	Oscilloscope
Adjustment Element	RV207
Specified Value	A = B = C

Note 1: Set data: 00 to page: 5, address: 38

Note 2: Set "S VIDEO" mode with the INPUT SELECT button on the front panel.

Adjusting method:

1) Set the amplitude (A), (B), (C) to the same level using RV207.






Fig. 5-3-19.

8. REC Y Level Adjustment (VA-102 Board)


Mode	E-E
Signal	Color bar (VIDEO input) (Note 1)
Measurement Point	Pin 1 of IC102 (CL142)
Measuring Instrument	Oscilloscope
Adjustment Element	RV205
Specified Value	$A = 1.55 \pm 0.02 \text{ V}$

Note 1: Set "VIDEO" mode with the INPUT SELECT button on the front panel.

Adjusting method:

1) Set the Y signal level (A) to the specified value using RV205.

For NTSC model



For PAL model




Fig. 5-3-20.

9. REC CR Level Adjustment (VA-102 Board)

Mode	E-E
Signal	Color bar (VIDEO input) (Note 1)
Measurement Point	Pin (10) of IC102 (CL143)
Measuring Instrument	Oscilloscope
Adjustment Element	RV204
Specified Value	$A = 1.25 \pm 0.02 \text{ V (NTSC)}$ $A = 1.20 \pm 0.02 \text{ V (PAL)}$

Note 1: Set "VIDEO" mode with the INPUT SELECT button on the front panel.

Adjusting method:

1) Set the CR signal level (A) to the specified value using RV204.




Fig. 5-3-21.

10. REC CB Level Adjustment (VA-102 Board)

Mode	E-E
Signal	Color bar (VIDEO input) (Note 1)
Measurement Point	Pin (8) of IC102 (CL144)
Measuring Instrument	Oscilloscope
Adjustment Element	RV206
Specified Value	$A = 1.20 \pm 0.02 \text{ V}$

Note 1: Set "VIDEO" mode with the INPUT SELECT button on the front panel.

Adjusting method:

1) Set the CB signal level (A) to the specified value using RV206.




Fig. 5-3-22.

11. Encoder Freerunning Frequency Adjustment (VA-102 Board)

Mode	E-E
Signal	Color bar (S VIDEO input) (Note 2)
Measurement Point	TP401 (CL426)
Measuring Instrument	Frequency coutner
Adjustment Element	CT401
Specified Value	f = 14318182 ± 100Hz (NTSC) f = 17734475 ± 100 Hz (PAL)

Note 1: Connect the frequency counter via high input impedance equipment such as an oscilloscope.

Note 2: Set "S VIDEO" mode with the INPUT SELECT button on the front panel.

Adjusting method:

 Set the oscillation frequency (f) to the specified value using CT401.

Measurement Point




Fig. 5-3-23.

12. Playback Y Level Check (VA-102 Board)

Mode	Recording
Signal	DV input (Note 1)
Measurement Point	Pin (1) of CN401 (CL436)
Measuring Instrument	Oscilloscope
Specified Value	$A = 0.83 \pm 0.02 \text{ V (NTSC)}$ $A = 0.825 \pm 0.02 \text{ V (PAL)}$

Note 1: Generate color bar signal with NTSC: DCR-VX1000/PAL: DCR-VX1000E and enter it to the DV terminal. (How to generate color bars: Connect the adjusting remote commander to the NTSC: DCR-VX1000/PAL: DCR-VX1000E, and set data: 09 to page: 5, address: 02. After adjustment, be sure to return the data to "00".)

Note 2: Perform this check after confirming that the specified value in the following adjustment of the JC-19 board has been satisfied.

1. Playback Y Signal Level Adjustment.

Checking method:

1) Check that the white (75%) signal level (A) is the specified value.




Fig. 5-3-24.

13. Playback Chroma Level Adjustment (VA-102 Board)

Mode	Recording
Signal	DV input (Note 1)
Measurement Point	Pin ① of CN401 (CL435)
Measuring Instrument	Oscilloscope
Adjustment Element	RV406
Specified Value	$A = 670 \pm 10 \text{ mV (NTSC)}$ $A = 660 \pm 10 \text{ mV (PAL)}$

- Note 1: Generate color bar signal with NTSC: DCR-VX1000/PAL: DCR-VX1000E and enter it to the DV terminal. (How to generate color bars: Connect the adjusting remote commander to the NTSC: DCR-VX1000/PAL: DCR-VX1000E, and set data: 09 to page: 5, address: 02. After adjustment, be sure to return the data to "00".)
- **Note 2:** Perform this adjustment after confirming that the specified value in the following adjustment of the JC-19 board has been satisfied.
 - 1. Playback CR Signal Level Adjustment.
 - 2. Playback CB Signal Level Adjustment.

Adjusting method:

1) Set the red signal level (A) to the specified value using RV406.




Fig. 5-3-25.

14. Playback Burst Level Adjustment (VA-102 Board) (PAL model only)

Mode	Recording	
Signal	DV input (Note 1)	
Measurement Point	Pin ① of CN401 (CL435)	**
Measuring Instrument	Oscilloscope	
Adjustment Element	RV402	
Specified Value	$A = 300 \pm 10 \text{ mV (PAL)}$	

- Note 1: Generate color bar signal with NTSC: DCR-VX1000/PAL: DCR-VX1000E and enter it to the DV terminal. (How to generate color bars: Connect the adjusting remote commander to the NTSC: DCR-VX1000/PAL: DCR-VX1000E, and set data: 09 to page: 5, address: 02. After adjustment, be sure to return the data to "00".)
- Note 2: Perform this adjustment after confirming that the specified value in the following adjustment of the JC-19 board has been satisfied.
 - 1. Playback CR Signal Level Adjustment.
 - 2. Playback CB Signal Level Adjustment.

Adjusting method:

1) Set the burst signal level (A) to the specified value using RV402.




Fig. 5-3-26.

3-5-4. General Adjustments

1. Y Output Level Adjustment (JC-19 Board)

Mode	E-E
Signal	Color bar (DV input) (Note 1)
Measurement Point	Video output terminal
Measuring Instrument	Oscilloscope
Adjustment Element	page: D, address: 36
Specified Value	$A = 0.83 \pm 0.01 \text{ V (NTSC)}$ $A = 0.823 \pm 0.01 \text{ V (PAL)}$

Note 1: Generate color bar signal with NTSC: DCR-VX1000/PAL: DCR-VX1000E and enter it to the DV terminal. (How to generate color bars: Connect the adjusting remote commander to the NTSC: DCR-VX1000/PAL: DCR-VX1000E, and set data: 09 to page: 5, address: 02. After adjustment, be sure to return the data to "00".

Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: D, address: 36, change the data, adjust the Y signal level (A) to the specified value.
- 1) Select page: 0, address: 01, and set data: 00.




Fig. 5-3-27.

2. Encoder R-Y Input Level Adjustment (JC-19 Board)

Mode	E-E
Signal	Color bar (DV input) (Note 1)
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Adjustment Element	page: D, address: 34
Specified Value	Phase: 104 ± 2° Gain: 95 ± 5%

Note 1: Generate color bar signal with NTSC: DCR-VX1000/PAL: DCR-VX1000E and enter it to the DV terminal. (How to generate color bars: Connect the adjusting remote commander to the NTSC: DCR-VX1000/PAL: DCR-VX1000E, and set data: 09 to page: 5, address:02. After adjustment, be sure to return the data to "00".

Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Adjust the burst luminance point to the specified position using the PHASE and GAIN knobs of the vectorscope.
- Select page: D, address: 34, change the data, adjust a red luminance point to the specified position.
- 4) Select page: 0, address: 01, and set data: 00.

For NTSC model

⊞: FOR ENCODER R-Y INPUT LEVEL ADJUSTMENT




Fig. 5-3-28.

For PAL model

⊞: FOR ENCODER R-Y INPUT LEVEL ADJUSTMENT




Fig. 5-3-29.

3. Encoder B-Y Input Level Adjustment (JC-19 Board)

Mode	E-E
Signal	Color bar (DV input) (Note 1)
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Adjustment Element	page: D, address: 35
Specified Value	Phase: 348 ± 2° Gain: 66 ± 5%

Note 1: Generate color bar signal with NTSC: DCR-VX1000/PAL: DCR-VX1000E and enter it to the DV terminal. (How to generate color bars: Connect the adjusting remote commander to the NTSC: DCR-VX1000/PAL: DCR-VX1000E, and set data: 09 to page: 5, address:02. After adjustment, be sure to return the data to "00".

Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- Adjust the burst luminance point to the specified position using the PHASE and GAIN knobs of the vectorscope.
- Select page: D, address: 35, change the data, adjust a blue luminance point to the specified position (inside of thick frame).
- 4) Select page: 0, address: 01, and set data: 00.

4. Decoder HUE Input Adjustment (JC-19 Board)

Mode	E-E
Signal	Color bar (S VIDEO input) (Note 1)
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Adjustment Element	RV207
Specified Value	Phase: 104 ± 1° Gain: 95 ± 5%

Note 1: Set "S VIDEO" mode with the INPUT SELECT button on the front panel.

Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: 2, address: 10, and set data: 20.
- Adjust the burst luminance point to the specified position using the PHASE and GAIN knobs of the vectorscope.
- 4) Adjust RV107 so that a red luminance point comes to the specified position (inside of thick frame). At this time, confirm that other color luminance points are inside each phase specified frame (± 2).
- 5) Select page: 2, address: 10, and set data: 00.
- 4) Select page: 0, address: 01, and set data: 00.

Note: When a red luminance point and a blue luminance point are not at the specified positions, adjust RV204 and RV206 so that they come to the specified positions respectively.

For NTSC model

E: FOR DECODER HUE INPUT ADJUSTMENT

R-Y

Burst

B: FOR ENCODER

Fig. 5-3-30.

For PAL model

Burst

G

C

FOR ENCODER

B-Y INPUT LEVEL

ADJUSTMENT

Fig. 5-3-31.

B-Y INPUT LEVEL

ADJUSTMENT

5. Battery Down Adjustment and Confirmation

Mode	Stop
Signal	Any
Test point	Displayed data on page 5, address 2A (LCD display of the adjusting remote commander)
Measuring Instrument	Adjusting remote commander
Adjustment page	E
Adjustment address	1D, 1E, 1F

Note 1: Make sure that the BEEP on the Menu screen is set to "ON".

Connection of Equipment:

Connect a regulated power supply and a digital voltmeter to the DC IN terminal.




Fig. 5-3-32.

Adjusting Method:

- 1) Adjust the output voltage of regulated power supply so that a digital voltmeter displays 11.0 ± 0.05 V.
- 2) Select page: 5, address: 2A, and read displayed data on the adjuting remote commander, and assume it as Do.
- 3) Select page: E, address: 1D, set data: Do, and press the PAUSE button on the adjusting remote commander.
- 4) Convert "Do" read in 2) to decimal notation, and obtain Do'.
- 5) Calculate D₁', D₂' using the following equations (decimal notation calculation).

$$D_1' = D_0' - 6$$

$$D_2' = D_0' - 12$$

- 6) Convert D₁' to hexadecimal notation, and obtain D₁.
- 7) Select page: E, address: 1E, set data: D₁, and press the PAUSE button on the adjusting remote commander.
- 8) Convert D2' to hexadecimal notation, and obtain D2.
- 9) Select page: E, address: 1F, set data: D2, and press the PAUSE button on the adjusting remote commander.
- 10) Confirm the display and operation of the fluorescent display tube, when the voltage input from DC IN terminal is lowered from 12 V.

Input of DC 12 V : Normal operation

Input of DC 10.8 V: Beep sounds and "dc Lo" is displayed.

Input of DC 10.3 V: Beep sounds and the standby mode is ac-

tivated after 2 seconds.

11) Further lower the voltage, and check the voltage when STBY

indicator (red LED) turns off. Specification: The power relay must turns off when Vdc = 9.0 V - 9.5 V.

12) On the contrary, raise the voltage, and check the voltage when STBY indicator (red LED) turns on.

Specification: The power relay must turns on when Vdc = 10.5 V - 11.0 V.

3-5-5. BIST Check

Playback System Check (JC-19, RP-228 Boards)

- Connect the adjusting remote commander to the LANC terminal, and turn the HOLD switch ON.
- 2) Playback the BIST check tape.

IC411(D1) Playback System Check

- 3) Select page: 4, address: 11, set data: 04, and press the PAUSE button.
- 4) Select page: 4, address: 11, set data: 00, and press the PAUSE button.
- Select page: 4, address: 13, set data: 03, and press the PAUSE button.
 (Data automatically returns to "00")
- 6) If IC411 (D1) → IC401 (U1) playback system is normal, the following data are displayed on page: 4, addresses: 14, 15.

Page	Address	Data
4	15	E5
4	14	- 11

7) If IC411(D1) → IC701 (IND1) playback system is normal, the following data are displayed on page: 4, addresses: 16, 17.

Page	Address	Data
4	17	C0 or BA
4	16	6E or 04

8) If IC411(D1) → IC805 (A1) playback system is normal, the following data are displayed on page: 4, addresses: 18, 19.

Page	Address	Data
4	19	33 or B2
4	18	59 or 19

IC805 (A1) Playback System Check

- 9) Select page: 4, address: 11, set data: 10, and press the PAUSE button.
- 10) Select page: 4, address: 11, set data: 00, and press the PAUSE button.
- 11) Select page: 4, address: 13, set data: 04, and press the PAUSE button.
 - (Data automatically returns to "00")
- 12) If IC805 (A1) playback system is normal, the following data are displayed on page: 4, addresses: 14, 15.

Page	Address	Data
: 4	15	7B
4	14	B5

IC401 (U1) Playback System Check

- 13) Select page: 4, address: 11, set data: 08, and press the PAUSE button.
- 14) Select page: 4, address: 42, set data: 01, and press the PAUSE button.
- 15) Select page: 4, address: 13, set data: 07, and press the PAUSE button.
 - (Data automatically returns to "00")
- 16) Select page: 4, address: 42, set data: 00, and press the PAUSE button.
- 17) Select page: 4, address: 11, set data: 00, and press the PAUSE button.

18) If IC401 (U1) → IC200 (S1) playback system is normal, the following data are displayed on page: 4, addresses: 14, 15.

Page	Address	Data	
4	15	1E	
4	14	F2	

19) If IC411 (D1) → IC401 (U1) playback system is normal, the following data are displayed on page: 4, addresses: 16, 17.

Page	Address	Data	
4	17	D1	
4	16	61	

20) Perform "Record System Check" successively.

2. Record System Check

Note: Perform "Record System Check" successively (with BIST check tape in playback status)

1) Enter the following data.

Note: Press the PAUSE button each time the data is set.

Page	Address	Data
4	41	01
4	0F	02
4	0E	01
4	40	01
4	0F	0A
4	40	00
4	40	01
4	0F	0E
4	40	00
4	40	01
4	0F	8E
4	40	00

- With the HOLD switch on adjusting remote commander turned ON, eject the BIST check tape, and insert a record tape instead.
- 3) Set the REC mode.

IC401 (U1) Record System Check

- 4) Select page: 4, address: 11, set data: 08, and press the PAUSE button.
- Select page: 4, address: 42, set data: 01, and press the PAUSE button.
- Select page: 4, address: 13, set data: 07, and press the PAUSE button.
 (Data automatically returns to "00".)
- 7) Select page: 4, address: 42, set data: 00, and press the PAUSE
- button.
- Select page: 4, address: 11, set data: 00, and press the PAUSE button.
- If IC401 (U1) → IC411 (D1) record system is normal, the following data are displayed on page: 4, addresses: 16, 17.

Page	Address	Data
4	17	. 05
4	16	80

IC411 (D1) Record System Check

- 10) Select page: 3, address: 01, set data: 0D, and press the PAUSE button.
- Select page: 4, address: 1C, set data: FF, and press the PAUSE button.
- 12) Select page: 4, address: 11, set data: 04, , and press the PAUSE button.
- 13) Select page: 4, address: 11, set data: 00, and press the PAUSE button
- 14) Select page: 4, address: 13, set data: 03, and press the PAUSE button.(Data automatically returns to "00")
- 15) If IC401 (U1) → IC411 (D1) record system is normal, the following data are displayed on page: 4, addresses: 14, 15.

Page	Address	Data
4	15	05
4	14	80

16) If IC411 (D1) → IC701 (IND1) record system is normal, the following data are displayed on page: 4, addresses: 16, 17.

	Page	Address	Data
	. 4	17	E6
i	4	16	BC

17) If IC805 (A1) → IC411 (D1) record system is normal, the following data are displayed on page: 4, addresses: 18, 19.

Page	Address	Data
4	19	76
4	18	В9

18) If IC411 (D1) → IC774 (DX) record system is normal, the following data are displayed on page: 4, addresses: 1A, 1B.

Page	Address	Data
4	1 B	4E
4	1 A	11

3-6. AUDIO SYSTEM ADJUSTMENTS

Unless spesified otherwise, set the switches as follows. AUDIO NODE (Menu display) Fs48k INPUT SELECTVIDEO AUDIO MONITOR CH-1/2 REC LEVEL L, R Center

Note 1: Set AUDIO MODE at the SET UP menu of the menu

Connection of Equipment




Fig. 5-3-33.

1. Playback Level/Indicator Check

Mode	Playback
Signal	Audio check reference tape
Measurement point	Audio output terminal (Left and Right)
Measuring Instrument	Audio level meter and frequency counter
Specified Value	32 kHz mode: 1 kHz signal should be output 48 kHz mode: 1 kHz signal level should be +6 ± 2 dBv (+8.2 ± 2 dBs) 44.1 kHz mode EMP ON: 7.35 kHz signal level is -6 ± 1 dB for 1 kHz signal level in 48 kHz mode 44.1 kHz mode EMP ON: 7.35 kHz signal level is 0 ± 1 dB for 1 kHz signal level in 48 kHz mode NS AUDIO lamp should be lit

Note: 0 dBv = 1 Vrms0 dBs = 0.775 Vrms

Checking method:

1) Check that the playback signal level satisfies the specified value.

2. E-E Level Check

Mode	E-E (LINE 1 input)					
a	Audio: 1 kHz -6 dBv (-3.8 dBs) Signal Audio input terminal (Left and Right)					
Signal	Video: Color bar signal Video input terminal					
Measurement point	Audio output terminal (Left and Right)					
Measuring Instrument	Audio level meter					
Specified Value	$-6 \pm 3 \text{ dBv } (-3.8 \pm 3 \text{ dBs})$					

Checking method:

- 1) Check that the 1 kHz signal level satisfies the specified value.
- 2) Check that the number in the segment of the level meter (fluorescent display tube) that is lit is between 8 and 12 for both the L and R channels.

3. Recording/Playback Check (Audio Lock Mode)

Mode	Recording/Playback (LINE input)				
Signal	Audio: no signal				
	Video: Color bar Video input terminal				
Measurement point	Display data of page: 5, address: 00				
Measuring Instrument	of the adjusting remote commander				
Specified Value	① After playback pause, the changes in the data after 5 frames have been sent continuously must be in the following order. "D4"→"D6"→"D6"→"D6"→"D6"→"D6" →"D4" (NTSC) "D8"→"D8"→"D8"→"D8"→"D8" →"D8" (PAL) ② NS AUDIO lamp should be lit.				


Note 1: Check that the AUDIO MODE (menu screen) is Fs48k. Note 2: Send the frames using front panel button.

Checking method:


- 1) With no audio signal being input, record the color bar signal for about 1 minute.
- 2) Playback the recorded part, and set the playback pause mode.
- 3) Select page: 5, address: 00 using the adjusting remote com-
- 4) Send the frames, so that the display data for page: 5, address: 00 is D4. (NTSC)
- 5) Send 5 frames continuously, and check that the display data of page: 5, address: 00 changes in the order specified.
- 6) Exit the playback pause mode, playback the recorded part, and check that the NS AUDIO lamp (front panel) is off.

3-7. ARRANGEMENT DIAGRAM FOR ADJUSTMENT PARTS


RP-228 BOARD (SIDE A)




RP-228 BOARD (SIDE B)




POWER BLOCK (U-2)



JC-19 BOARD (SIDE A)





C-19 BOARD (SIDE A)

CN411 CN104 CN103 1 30


5 8 RV001⊕⊕ RV002

> ⊕ RV201


C-19 BOARD (SIDE B)

2 20 CN503 1 19 CL052■8 7 14 1 1 C010 CL054■8 7 14 1 IC011 CL222 IC2.





VA-102 BOARD (SIDE B)



SECTION 6 REPAIR PARTS LIST

6-1. EXPLODED VIEWS

NOTE:

- -XX and -X mean standardized parts, so they may have some difference from the original one.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list and accessories are given in the last of the electrical parts list.

The components identified by mark \triangle or dotted line with mark \triangle are critical for eafety


critical for safety.

Replace only with part number specified.

Les composants identifiés par une marque \triangle sont critiquens pour la sécurité.


sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

6-1-1. OVERALL ASSEMBLY




Ref. No.	Part No.	<u>Description</u>	<u>Remark</u>	Ref. No.	Part No.	Description	Remark
1	X-3950-023-1	PANEL ASSY, FRONT (DSR-20MD)		* 7	X-3948-056-1	HINGE (R) ASSY, DOOR	
1	X-3950-022-1	PANEL ASSY (P), FRONT (DSR-20MD)P)	8		SCREW, M3 CASE	
2	X-3950-025-1	DOOR ASSY (DSR-20MD)		* 9	3-987-158-01	CASE, UPPER	
2	X-3950-024-1	DOOR ASSY (P) (DSR-20MDP)		10	3-987-171-01	FOOT (FF-004)	
3	3-950-280-01	MAGNET		11	3-970-608-41	SUMITITE (B3), +BV	
4	3-956-976-11	KNOB, ROTARY	•	12	1-475-693-11	REMOTE COMMANDER (RMT-DS20)	
5	4-942-567-01	EMBLEM (NO.4), SONY		13		LID, BATTERY CASE (for RMT-DSR20)	
* 6	X-3948-057-1	HINGE (L) ASSY, DOOR				,	

6-1-2. CHASSIS ASSEMBLY



Ref. No.	Part No.	<u>Description</u>	<u>Remark</u>	Ref. No.	Part No.	Description	Remark
* 51	A-7074-111-A	FR-136 BOARD, COMPLETE		63	3-975-291-01	SCREW (4X6)	
52	3-970-608-41	SUMITITE (B3), +BV		* 64	3-987-157-31		
* 53	A-7073-471-A	HP-100 BOARD, COMPLETE		65	1-958-841-11	HARNESS (DP-73)	
* 54	A-7067-251-A	VA-102 BOARD, COMPLETE (DSR-2	OMDP)	66	3-945-562-01		
* 54	A-7067-250-A	VA-102 BOARD, COMPLETE (DSR-2	OMD)	 ∆ 67	1-958-585-11	HARNESS (AC-227)	
			11.4	ř		, ,	
55	1-782-823-11	CABLE, FLAT (FVH-4)		- 68	1-958-059-11	HARNESS (VP-72)	
56		CABLE, FLAT (FVF-8)		* 69	A-7073-576-A	HG-1 BOARD, COMPLETE	
57	1-782-824-11	CABLE, FLAT (FVJ-7)		71	3-964-010-01	SCREW M2	
1 ∆ 58	1-468-441-11	POWER BLOCK (U-1/U-2) (DSR-20A	/ID)	* 72	3-050-330-01	BRACKET, HG-1	
 ∆ 58	1-468-442-11	POWER BLOCK (U-1/U-2) (DSR-20N	(IDP)	CN001	1-958-813-11	HARNESS (DH-50)	
			·			•	
* 59		RS-78 BOARD, COMPLETE		CN002	1-565-388-21	CONNECTOR, D-SUB 9P (REMOTE RS	-2320)
60	1-782-822-11	CABLE, FLAT (FVR-9)	.	J901		CONNECTOR (WITH DC SW) 4P	,
* 61	A-7073-470-A	RE-32 BOARD, COMPLETE		M905	1-698-534-31		
62	1-782-826-11	CABLE, FLAT (FVR-10)					

6-1-3. MD BLOCK ASSEMBLY



Ref. No.	Part No.	Description	<u>Remark</u>	Ref. No.	Part No.	Description	Remark
101	1-776-148-11	CABLE, FLAT (FCM-11) 15P		* 110	A-7067-130-A	JC-19 BOARD, COMPLETE (DSR-20)	MD)
102	1-776-145-11	CABLE, FLAT (FCM-8) 16P		* 111	3-987-133-01	SUPPORT, JC	.*
* 103	A-7067-127-A	CM-56 BOARD, COMPLETE (DSR-20	MDP)	112	3-056-130-01	SCREW (M3), STEP	
* 103	A-7067-131-A	CM-56 BOARD, COMPLETE (DSR-20	MD)	113	1-958-288-11	HARNESS (CM-130)	
* 104	3-987-138-01	FRAME, MD	·	.114	1-776-151-11	CABLE, FLAT (FCM-12) 14P	
105	1-764-137-11	CONNECTOR, TRANSLATION 15P		115	1-776-147-11	CABLE, FLAT (FCM-10) 15P	
* 106	A-7067-128-A	RP-228 BOARD, COMPLETE (DSR-2	OMDP)	116	1-776-146-11	CABLE, FLAT (FCM-9) 9P	
* 106	A-7067-132-A	RP-228 BOARD, COMPLETE (DSR-2	OMD)	117	1-958-057-11	HARNESS (CP-79)	
107	1-776-149-11	CABLE, FLEXIBLE FLAT 30P	•	118	1-958-061-11	HARNESS (VJ-103)	
108	1-783-376-11	CABLE, FLEXIBLE FLAT (FFC-245)		119			
109	3-732-817-01	SCREW (2X4.5), TAPPING		120	1-958-060-11	HARNESS (VJ-102)	
* 110	A-7067-126-A	JC-19 BOARD, COMPLETE (DSR-20)	MDP)	121		FILTER, CLÀMP (FÉRRITE CORE)	

6-1-4. FL CASETTE COMPARTMENT ASSEMBLY

not supplied

1

2

3


4

(5)

NOTE FOR INSTALLATION

➤: Place for grease (SG-055G: 7-651-000-09)

☐: Take note of the position and specified direction.




Ref. No.	Part No.	Description		<u>Remark</u>	Ref. No.	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
701	A-7092-644-A	FL BLOCK ASSY		(5-2)	708	3-967-816-01	BELT, ROLLER	(5-38)
702	A-7092-647-A	SLOAT BLOCK ASSY, C		(5-41)	709	3-947-503-01	SCREW (M1.4X2.5)	` ,
703	3-967-604-01	SPRING (DB), TENSION	(A): 5-40/	®: 5-41)	710	3-967-591-01	GEAR (B)	(5-40)
704	3-967-655-01	DOOR, C	•	(5-40)	711	3-967-590-01	GEAR (A)	(5-40)
705	3-967-613-01	SPRING (HS), TENSION C	OIL	(5-41)	712	3-967-653-01	OPENER, LID	(5-39)
706	3-967-777-01	ARM, DAMPER		(5-40)	713	3-967-592-01	WORM, C	(5-40)
707	X-3945-780-1	SHAFT ASSY, ROLLER		(5-38)	714	3-967-636-01	SPRING, SHIFT PLATE	(5-41)

6-1-5. MECHANISM CHASSIS ASSEMBLY (1) (TOP SIDE VIEW (1))

NOTE FOR INSTALLATION

PH:: Phase adjustment
: Place for grease (SG-055G: 7-651-000-09)




Ref. No.	Part No.	<u>Description</u>	Ref. page No.	Ref. No.	Part No.	<u>Description</u>	Ref. page No.
751	X-3945-801-1	BASE ASSY, TG3/4	(5-31)	765	3-967-751-01	COVER. LM	(5-15)
752	3-967-740-01	SPRING, TG3 LOCK	(5-26, 5-33)	766	3-967-767-01	WHEEL, LM WORM	(5-15)
753	X-3947-441-1	ROLLER ASSY, TG3	(5-26)	767	3-967-768-01	GEAR, PINCH DRIVING	(5-15)
754	3-703-816-74	SCRWE (M1.4X4.5), SPECIAL	HEAD	768	X-3945-803-1	BASE ASSY, TG5/6	(5-33)
755	A-7044-015-A	DRUM ASSY (DEH-08B-R)	(5-14)	769	3-967-741-01	SPRING, TG6 LOCK	(5-26, 5-33)
756	1-770-363-11	ELASTIC CONNECTOR	(5-14)	770	X-3945-810-1	ARM ASSY, PINCH	(5-16)
757	3-967-785-01	STOPPER, TAPE	(5-14)	771	3-967-645-01	SPRING (PINCH), TENSION COIL	, ,
758	3-967-728-01	SCREW (M2 X 5)		772	3-967-676-01	LIMITER, PINCH	(5-16)
759	3-967-817-01	BASE, DRUM	(5-14)	773	3-967-769-01	GEAR, PINCH CAM	(5-16)
760	A-7040-449-A	SCREW ASSY	(5-14)	774	3-967-679-01	RETAINER, PINCH	(5-16)
761	3-954-285-01	SCREW (M1.4X0.2)		775	3-967-795-03	ARM, HC	(5-16)
762	X-3945-798-1	ARM ASSY, TC	(5-15)	776	X-3945-802-1	ROLLER ASSY, TG6	(5-26)
763	3-967-675-01	HOLDER, LM	(5-15)	M901	X-3944-897-2	FPC ASSY, MOTOR	(5-14)
764	3-732-817-01	SCREW (2X4.5), TAPPING		M903	X-3945-784-1	MOTOR ASSY, LM (LOADING)	(5-15)

6-1-6. MECHANISM CHASSIS ASSEMBLY (2) (TOP SIDE VIEW (2))

NOTE FOR INSTALLATION

PH:: Phase adjustment: Take note of the position and specified direction.




Ref. No.	Part No.	Description	Ref. page No.	Ref. No.	Part No.	Description Ref.	page No.
801	3-967-809-01	RETAINER, TG2	(5-19)	810	3-967-764-01	ARM, TG2 SELECTION	(5-18)
802	3-967-715-01	SPRING, TG2 PLATE	(5-19)	811	3-967-807-01	HOOK, TG2 SPRING	(5-18)
803	3-728-148-11	SCREW (M1.4X2.5), SPECIAL	_ HEAD	812	3-967-724-01	ADJUSTOR, SPRING (5-18, (A): 5-9/	®: 5-10)
804	3-967-714-01	MAGNET, ET (A)	: 5-19/®: 5-520)	813	3-967-810-01	RETAINER, TG7	(5-20)
805	X-3945-792-1	BAND ASSY, S TENSION REG	ULATOR (5-19)	814	X-3945-806-1	ARM ASSY, TG7	(5-20)
806	X-3945-805-1	ARM ASSY, TG2	(5-19)	815	3-967-694-01	SPRING, TG7 PLATE	(5-20)
807	3-967-726-01	SPRING (TG2), TENSION COI	L	816	X-3945-793-1	BAND ASSY, T TENSION REGULATOR	(5-20)
			A: 5-9/B:5-10)	817	X-3945-783-1	ARM ASSY, TG7 LOAD	(5-20)
808	3-967-685-01	,	(5-18)	818	3-967-808-01	HOOK, TG7 SPRING	(5-18)
809		ARM ASSY, TG2 LOAD	(5-19)				

6-1-7. MECHANISM CHASSIS ASSEMBLY (3) (TOP SIDE VIEW (3))

NOTE FOR INSTALLATION

PH-: Phase adjustment : Place for grease (SG-055G: 7-651-000-09) : Take note of the position and specified direction.




Ref. No.	Part No.	<u>Description</u>	Ref. page No.	Ref. No.	Part No.	Description	Ref. page No.
851 852 853 854 855	1-658-990-11 3-318-201-11 3-967-684-01 3-967-692-01 X-3945-807-1	SPRING, PLATE GUARD, GOOSENECK	PING ((A): 5-23/ (B): 5-24) (5-17)	861 862 863 864 865	3-967-775-01 3-947-503-01	BRAKE, S SPRING, S BRAKE RATCHET, T SCREW (M1.4X2.5) BASE ASSY, TG18	(5-25) (5-25) (5-25)
856 857 858 859 860	3-967-784-01 3-967-683-01 X-3945-814-1 3-967-680-01	ARM, RL SPRING, RL PRESS PLATE ASSY, S REEL	(5-17) (5-17) (5-23) (5-17)	866 867 CN901 S901 S902	3-967-725-01 X-3945-815-1	HOLDER, T REEL PLATE ASSY, T REEL CONNECTOR 4P	(5-22) (5-24) (5-35) (5-35) (5-17)

6-1-8. MECHANISM CHASSIS ASSEMBLY (4) (BOTTOM SIDE VIEW (1))

NOTE FOR INSTALLATION

PH-: Phase adjustment

: Place for grease (SG-055G: 7-651-000-09)




Ref. No.	Part No.	Description	Ref. page No.	Ref. No.	Part No.	Description	Ref. page No.
901	3-967-678-01	GEAR, T CAM	(5-28)	914	3-967-746-01	SPRING, TG3/4 LIMITER	(5-31)
902	3-967-756-01	GEAR, TG7 CAM	(5-28)	915	X-3945-794-1	ARM ASSY, TG3/4	(5-31)
903	3-967-763-01	ARM, TG7 SELECTION	(5-28)	916	3-967-792-01	GEAR. TG5/6	(5-33)
904	3-967-677-01	SLIDER, M	(5-28)	917	3-967-748-01	SPRING, TG5/6 LIMITER	(5-33)
905	3-669-465-01	WASHER (1.5), STOPPER		918	X-3945-795-1	· · · · · · · · · · · · · · · · · · ·	(5-33)
906	3-967-829-01	ARM, FL SELECTION	(5-28)	919	3-967-753-01	ARM, M SLIDER	(5-28)
907	3-967-828-01	GEAR, FL JOINT	(5-26)	920	3-967-819-01	CAM, MAIN	(5-29)
908	X-3945-813-1	ARM ASSY, FL JOINT	(5-27)	921	3-967-765-01	GEAR. TC	(5-27)
909	3-967-830-01	GEAR, FL RELAY	(5-27)	922	3-967-766-01	GEAR, RELAY	(5-27)
910	3-967-755-01	RETAINER, GL ARM	(5-28)	923	3-967-633-01	SPRING (TG2SL), TENSION COIL	(5-29)
911	3-947-503-01	SCREW (M1.4X2.5)		924	X-3945-781-1	ARM ASSY, TG2 SL	(5-29)
912	3-967-754-01	ARM, GL	(5-28)	M902	8-835-545-01	MOTOR, DC SCD11A/J-N (CAPSTA	
913	3-967-790-01	GEAR, TG3/4	(5-31)	S001		SWITCH, ROTARY (MODE)	(5-27)

6-1-9. MECHANISM CHASSIS ASSEMBLY (5) (BOTTOM SIDE VIEW (2))

NOTE FOR INSTALLATION

(PH-): Phase adjustment



Ref. No.	Part No.	<u>Description</u>	Ref. page No.	Ref. No.	Part No.	Description	Ref. page No.
* 951	A-7040-431-A	CHASSIS BLOCK ASSY, MECHA		958	3-967-682-01	SPRING, MIC PRESS	(5-34)
		(including MD-	63/64/65 board)	959	3-669-465-01	WASHER (1.5), STOPPER	
952	3-967-690-01	HOLDER, MIC	(5-35)	960	3-967-681-01	GEAR, RACK JOINT	(5-35)
953	X-3945-789-1	ARM ASSY, RS	(5-34)	961	3-947-503-01	SCREW (M1.4X2.5)	` ,
954	3-967-667-01	TENSION COIL SPRING	(5-34)	962	3-967-689-01	HOLDER, RACK	(5-35)
955	X-3945-788-1	LINK ASSY, PLATE	(5-37)			•	
				963	3-967-771-01	RACK (SC)	(5-35)
956	X-3945-787-1	GEAR ASSY, RS	(5-34)	964	3-967-770-01	RACK (LC)	(5-35)
957	3-967-783-01	LEVER, MIC	(5-34)	M904	8-835-537-01	MOTOR, DC SRD11A/J-N (REEL)	(5-34)

CM-56

6-2. ELECTRICAL PARTS LIST

NOTE:

- · Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- RESISTORS All resistors are in ohms. METAL: Metal-film resistor. METAL OXIDE: Metal oxide-film resistor. F: nonflammable
- SEMICONDUCTORS In each case, u: µ, for example: uA.: µA.. uPA.. : µPA.. uPB..: µPB.. uPC.. : µPC.. uPD. .. μ PD. .
- **CAPACITORS** uF: μF
- COILS uH: μH

The components identified by mark △ or dotted line with mark △ are critical for safety.

Replace only with part number specified.

Les composants identifiés par une marque A sont critiquens pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	<u>Description</u>		•	<u>Remark</u>	Ref. No.	Part No.	<u>Description</u>			Remark
*	A-7067-131-A	CM-56 BOARD, 0	OMPLETE (DSR-20	MD)	C054	1-127-530-11	ELECT	22uF	20%	20V
*		CM-56 BOARD, C				C055	1-163-017-00	CERAMIC CHIP	0.0047uF	5%	50V
	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	******			,	C056		CERAMIC CHIP	0.1uF	10%	25V
			(Re	f.No. 4.0	00 Series)						
			`		,	C058	1-127-530-11	ELECT	22uF	20%	20V
		< CAPACITOR >				C063	1-164-336-11	CERAMIC CHIP	0.33uF		25V
						C066	1-163-235-11	CERAMIC CHIP	22PF	5%	50V
C001	1-163-121-00	CERAMIC CHIP	150PF	5%	50V	C067	1-163-235-11	CERAMIC CHIP	22PF	5%	50V
C004		CERAMIC CHIP	150PF	5%	50V	C068	1-163-031-11	CERAMIC CHIP	0.01uF		50V
C005	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V.	1					
C006	1-124-779-00	ELECT CHIP	10uF	20%	16V	C073	1-163-019-00	CERAMIC CHIP	0.0068uF	10%	50V
C007	1-165-319-11	CERAMIC CHIP	0.1uF		50V	C075	1-163-235-11	CERAMIC CHIP	22PF	5%	50V
						C076	1-163-235-11	CERAMIC CHIP	22PF	5%	50V
C009	1-126-206-11	ELECT CHIP	100uF	20%	6.3V	C078	1-124-779-00	ELECT CHIP	10uF	20%	16V
C011	1-163-037-11	CERAMIC CHIP	0.022uF	10%	25V	C079	1-163-009-11	CERAMIC CHIP	0.001uF	10%	50V
C017	1-164-161-11	CERAMIC CHIP	0.0022uF	10%	100V					2.14%	
C018	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V	C080	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C019		CERAMIC CHIP	0.01uF	10%	50V	C081	1-165-319-11	CERAMIC CHIP	0.1uF		50V
						C082	1-163-031-11	CERAMIC CHIP	0.01uF		50V
C020	1-124-779-00	ELECT CHIP	10uF	20%	16V	C083	1-127-530-11	ELECT	22uF	20%	20V
C021	1-165-319-11	CERAMIC CHIP	0.1uF		50V	C086	1-163-031-11	CERAMIC CHIP	0.01uF		50V
C022	1-124-779-00	ELECT CHIP	10uF	20%	16V					•	
C024	1-163-227-11	CERAMIC CHIP	10PF	0.5PF	50V	C087	1-127-530-11	ELECT	22uF	20%	20V
C025	1-124-779-00		10uF	20%	16V	C088	1-126-193-11	ELECT	1uF	20%	50V
	, ,_,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					C090	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
C026	1-165-319-11	CERAMIC CHIP	0.1uF		50V	C091	1-163-031-11	CERAMIC CHIP	0.01uF		50V
C027	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V	C092	1-126-205-11	ELECT CHIP	47uF	20%	6.3V
C028	1-163-227-11	CERAMIC CHIP	10PF	0.5PF	50V						
C029	1-165-319-11	CERAMIC CHIP	0.1uF		50V	C093	1-164-004-11	CERAMIC CHIP	0.1 u F	10%	25V
C030	1-163-031-11	CERAMIC CHIP	0.01uF		50V	C094	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
						C095	1-163-031-11	CERAMIC CHIP	0.01uF		50V
C031	1-165-319-11	CERAMIC CHIP	0.1uF		50V	C096	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C032	1-126-193-11	ELECT	1uF	20%	50V	C099	1-163-019-00	CERAMIC CHIP	0.0068uF	10%	50V
C034		CERAMIC CHIP	0.01uF	10%	50V	{	•				
C035	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V	C101	1-163-031-11	CERAMIC CHIP	0.01uF		50V
C036		CERAMIC CHIP	0.1uF		50V	C102	1-163-031-11	CERAMIC CHIP	0.01uF		50V
						C103	1-126-204-11	ELECT CHIP	47uF	20%	16V
C038	1-163-031-11	CERAMIC CHIP	0.01uF		50V	C104	1-163-009-11	CERAMIC CHIP	0.001uF	10%	50V
C039	1-124-778-00	ELECT CHIP	22uF	20%	6.3V	C105	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C040		CERAMIC CHIP	0.1uF	10%	25V						
C041	1-163-035-00	CERAMIC CHIP	0.047uF		50V	C106	1-163-031-11	CERAMIC CHIP	0.01uF		50V
C042		CERAMIC CHIP	180PF	5%	50V	C107	1-165-319-11	CERAMIC CHIP	0.1uF		50V
						C108	1-163-035-00	CERAMIC CHIP	0.047uF		50V
C046	1-165-319-11	CERAMIC CHIP	0.1uF		50V	C111	1-163-031-11	CERAMIC CHIP	0.01uF		50V
C047		CERAMIC CHIP	0.1uF	10%	25V	C112	1-165-319-11	CERAMIC CHIP	0.1uF		50V
C048		CERAMIC CHIP	0.1uF	10%	25V			1 No. 1			
C049		CERAMIC CHIP	0.1uF	10%	25V	C113	1-163-020-00	CERAMIC CHIP	0.0082uF	10%	50V
C051		CERAMIC CHIP	0.1uF		50V	C115		CERAMIC CHIP	0.0082uF	10%	50V
			tere in the			C117	1-163-020-00	CERAMIC CHIP	0.0082uF	10%	50V
C052	1-126-193-11	ELECT	1uF	20%	50V	C118	1-163-237-11	CERAMIC CHIP	27PF	5%	50V
C053	1-126-397-11		33uF	20%	25V	C119	1-163-009-11	CERAMIC CHIP	0.001uF	10%	50V
	. Ve.1										

											L.`	
	Ref. No.	Part No.	Description			<u>Remark</u>	Ref. No.	Part No.	<u>Description</u>			Remark
							IC014		IC BA10393F-I			<u> </u>
	C120	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V	10014	0-709-010-70	IC BATUSSST-I	C2		
	C121		CERAMIC CHIP	0.1uF		50V	IC016	8-759-510-71	IC BA10358F-I	F2		
	C122		CERAMIC CHIP	0.0068uF	10%	50V	IC017		IC TC74HC405			
	C123	1-124-779-00	ELECT CHIP	10uF	20%	16V	IC018		' IC uPC339G2-			
	C126	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V	IC019		IC BA10358F-I		•	
							IC021		! IC CXA1793N-			
	C128		CERAMIC CHIP	0.1uF	10%	25V						
	C129		CERAMIC CHIP	0.1uF	10%	25V	IC022		IC LB1897D			
	C133		CERAMIC CHIP	0.01uF		50V	IC501		IC P030RV11			
	C504		CERAMIC CHIP	0.1uF	10%	25V	IC503	8-759-339-61	IC LB1897D			
	C505	1-104-004-11	CERAMIC CHIP	0.1uF	10%	25V			0011			
	C506	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V			< COIL >			
	C508	1-126-205-11		47uF	20%	6.3V	L003	1-412-282-41	INDLICTOR	470uH		
	C509		CERAMIC CHIP	0.47uF	10%	16V	L004	1-414-398-11		10uH		
	C510		CERAMIC CHIP	0.01uF	1070	50V	L005	1-414-398-11		10uH		
	C511	1-126-205-11		47uF	20%	6.3V	L006	1-414-398-11		10uH		
						0.01	L007	1-414-402-11		47uH		
	C512	1-126-193-11	ELECT	1uF	20%	50V				.,		
	C513	1-164-161-11	CERAMIC CHIP	0.0022uF	10%	100V	L008	1-424-522-21	INDUCTOR	10uH		
	C514		CERAMIC CHIP	0.01uF		50V	L010	1-424-522-21	INDUCTOR	10uH		
	C515	1-126-206-11	ELECT CHIP	100uF	20%	6.3V	L011	1-409-535-41	INDUCTOR	100uH		
							L013	1-424-524-21	INDUCTOR	47uH		
			< CONNECTOR >				L014	1-414-402-11	INDUCTOR	47uH		
	CNOOL	1 770 000 11	CONNECTOR FF	VEDO 40D								
,	CN001 * CN002		CONNECTOR, FFC PIN, CONNECTOR				L501	1-414-402-11		47uH		
	CN002		CONNECTOR, FFC		30D		L502	1-414-402-11	INDUCTOR	47uH		
\$	* CN004		PIN, CONNECTOR						< IC LINK >			
	CN005		CONNECTOR, FFC						< IO LINK >			
							⚠PS001	1-532-840-21	LINK, IC (1.25A)	(DSR-20	MDP)	
	* CN006		HOUSING, CONNI								•	
*	CN007		HOUSING, CONNE						< TRANSISTOR:	> , ,		
	CN008	1-//0-69/-11	CONNECTOR, FFC	/FPC 14P			0004	0.700.040.00	TD 411010707			
			< DIODE >				Q001 Q002		TRANSISTOR		A-QRS-T	Х
			CDIODE				Q003		TRANSISTOR TRANSISTOR	UN2213		
	D001	8-719-026-23	DIODE MA786-T	X			Q003		TRANSISTOR	MSD60 UN2211		
	D002		DIODE RD10M-T				Q008		TRANSISTOR	MSD60		
	D004		DIODE SB10-05F				4000	0 720 010 20	110110101011	MODOO) III I.,	
	D011		DIODE MA786-T				Q009	8-729-010-25	TRANSISTOR	MSD60	1-RT1	
	D012		DIODE MA786-T				Q012		TRANSISTOR		2-Y (TE10	61.)
							Q014		TRANSISTOR	UN2213		
	D501		DIODE SB10-05F				Q500		TRANSISTOR		A-QRS-T	Χ
	D502	8-719-108-24	DIODE MA151A-	TX			Q501	8-729-216-22	TRANSISTOR	2SB709	A-QRS-T	Χ
			-									
			< FUSE >				Q502	8-729-208-96			2-Y (TE16	6L)
/	∆ F001	1-532-777-21	FUSE MICRO			1	Q503 Q504	8-729-421-19		UN2213		
-	21001	1 002 777 27		JDARY) (1.2	25A) (DS	R-20MD)	Q30 4	8-729-421-19	INAMOIOTUN	UN2213	-1X	
			, (0-00)		, (50	11 201115)			< RESISTOR >			
			< FILTER >									
			Ded ar eas				R001	1-216-057-00		2.2K	5%	1/10W
	FL001		FILTER, BAND PAS				R002	1-216-065-91		4.7K	5%	1/10W
	FL002	1-233-350-21	FILTER, BAND PAS	SS		İ	R003	1-216-015-00		39	5%	1/10W
							R005	1-216-057-00		2.2K	5%	1/10W
			< IC >				R006	1-216-089-91	RES, CHIP	47K	5%	1/10W
	IC001	8-759-062-66	IC TC7S66F (TE8	5R)		ļ	DOOO	1-016 040 04	DEC CUID	11/	ro/	4/40144
	1C002		IC TC74HC08AF			1	R009 R010	1-216-049-91 1-216-089-91	•	1K 47K	5% 5%	1/10W
	IC003		IC CXP912032-07				R011	1-216-089-91		47K 47K	5% 5%	1/10W 1/10W
	IC005		IC CXA8044Q-T4			ĺ	R012	1-216-089-91		47K	5% 5%	1/10W
	IC006		IC uPC339G2-E2				R015	1-216-295-91		0	J /U	17 10 44
	ا مانخلامها	20. may 20. ma	.1 -11									
			IC TC74VHC125F				R016	1-216-089-91		47K	5%	1/10W
			IC BA6219BFP-Y-				R017	1-216-295-91		0		
			IC CXA8010M-E1 IC MB3775PF-G-I			j	R018	1-216-089-91		47K	5%	1/10W
	10012	0-100-0 4 0-11	TO MIDOLIGIES	אם ביחמור.		1	R019	1-216-295-91	onuki	0		

The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque ▲ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

CM-56

Ref. No.	Part No.	<u>Description</u>			<u>Remark</u>	Ref. No.	Part No.	<u>Description</u>			<u>Remark</u>
R020	1-216-093-91	RES, CHIP	68K	5%	1/10W	R109	1-216-081-00	METAL CHIP	22K	5%	1/10W
R021	1-216-089-91		47K	5%	1/10W	R110	1-216-073-00		10K	5%	1/10W
R026	1-216-049-91	,	1K	5%	1/10W	R111	1-216-049-91	•	1K	5%	1/10W
R027 R028	1-216-089-91 1-216-049-91		47K	5%	1/10W	R112	1-216-081-00		22K	5%	1/10W
R029	1-216-049-91	•	1K 1K	5% 5%	1/10W	R113	1-216-049-91	•	1K	5%	1/10W
11023	1-210-043-31	neo, Unir	, 1 K	5%	1/10W	R114	1-216-065-91	RES, CHIP	4.7K	5%	1/10W
R030	1-216-049-91	RES, CHIP	1K	5%	1/10W	R115	1-216-043-91	RES, CHIP	560	5%	1/10W
R032	1-216-049-91	RES, CHIP	1K	5%	1/10W	R116	1-216-057-00	,	2.2K	5%	1/10W
R033	1-216-049-91		1K	5%	1/10W	R117	1-216-043-91		560	5%	1/10W
R035	1-216-025-91		100	5%	1/10W	R118	1-216-057-00		2.2K	5%	1/10W
R036	1-216-025-91	RES, CHIP	100	5%	1/10W	R119	1-216-073-00		10K	5%	1/10W
Dooo	1 010 075 00	MATTAL OLUB	4014								
R039			12K	5%	1/10W	R120	1-216-073-00	METAL CHIP	10K	5%	1/10W
R040 R046	1-216-069-00	METAL CHIP	6.8K	5%	1/10W	R121	1-219-107-91		1.5	5%	1/8W
R050	1-216-069-00 1-216-077-91	METAL CHIP RES, CHIP	6.8K	5%	1/10W	R122	1-219-107-91		1.5	5%	1/8W
R051		•	15K 10K	5% 5%	1/10W 1/10W	R125 R126	1-219-107-91	•	1.5	5%	1/8W
11001	1 210 070 00	WEIAL OIII	TOK	J /0	171044	N120	1-216-049-91	RES, URIP	1K	5%	1/10W
R052	1-216-089-91	RES. CHIP	47K	5%	1/10W	R127	1-216-049-91	RES, CHIP	1K	5%	1/10W
R053	1-216-049-91		1K	5%	1/10W	R128	1-216-049-91		1K	5%	1/10W
R054	1-216-295-91		0			R129	1-216-049-91	•	1K	5%	1/10W
R055	1-216-049-91	RES, CHIP	1K	5%	1/10W	R130	1-216-025-91	,	100	5%	1/10W
R059	1-216-043-91	RES, CHIP	560	5%	1/10W	R131	1-216-025-91		100	5%	1/10W
R060	1-216-049-91	•	1K	5%	1/10W	R132	1-216-025-91	,	100	5%	1/10W
R061	1-216-049-91		1K	5%	1/10W	R133	1-216-075-00	METAL CHIP	12K	5%	1/10W
R063	1-216-049-91	•	1K	5%	1/10W	R134	1-216-072-00		9.1K	5%	1/10W
R064 R066	1-216-049-91		1K	5%	1/10W	R136	1-216-049-91	RES, CHIP	1K	5%	1/10W
nooo	1-216-025-91	neo, unir	100	5%	1/10W	R137	1-216-049-91	RES, CHIP	1K	5%	1/10W
R067	1-216-073-00	METAL CHIP	10K	5%	1/10W	R138	1-216-049-91	RES, CHIP	1K	5%	1/10W
R069	1-216-085-00		33K	5%	1/10W	R143	1-216-073-00	METAL CHIP	10K	5%	1/10W
R070	1-216-073-00		10K	5%	1/10W	R146			0	0 70	171000
R071	1-216-025-91	RES, CHIP	100	5%	1/10W	R148	1-216-017-91		47	5%	1/10W
R075	1-216-049-91	RES, CHIP	1K	5%	1/10W	R153	1-216-295-91	•	0		.,
R076	1-216-057-00		2.2K	5%	1/10W	R154		SHORT	0		
R077		RES, CHIP	100	5%	1/10W	R155	1-216-295-91		0		
R078	1-216-049-91		1K	5%	1/10W	R158	1-216-121-91		1M	5%	1/10W
R079	1-216-073-00		10K	5%	1/10W	R161	1-216-295-91		0		
R080	1-216-025-91	RES, UNIP	100	5%	1/10W	R164	1-216-672-11	METAL CHIP	7.5K	0.5%	1/10W
R081	1-216-049-91	RES, CHIP	1K	5%	1/10W	R165	1-216-017-91	RES CHIP	47	5%	1/10W
R082		METAL CHIP	10K	5%	1/10W	R167	1-216-017-91		47	5%	1/10W
R083	1-216-089-91		47K	5%	1/10W	R168	1-216-055-00		1.8K	5%	1/10W
R084	1-216-025-91		100	5%	1/10W	R169	1-216-055-00		1.8K	5%	1/10W
R085	1-216-049-91	RES, CHIP	1K	5%	1/10W	R171	1-216-059-00		2.7K	5%	1/10W
R086		RES, CHIP	1K	5%	1/10W	R176	1-216-033-00		220	5%	1/10W
R087		RES, CHIP	1K	5%	1/10W	R182		RES, CHIP	1M	5%	1/10W
R088	1-216-049-91		1K	5%	1/10W	R193	1-216-079-00		18K	5%	1/10W
R089	1-216-049-91	•	1K	5%	1/10W	R194	1-216-057-00		2.2K	5%	1/10W
R090	1-216-081-00	METAL CHIP	22K	5%	1/10W	R195	1-216-079-00	METAL CHIP	18K	5%	1/10W
R091	1-216-081-00	METAL CHIP	22K	5%	1/10W	R196	1-216-057-00	METAL CHID	2.2K	5%	1/10W
R092	1-216-089-91		47K	5%	1/10W	R201	1-216-073-00		10K	5%	1/10W
R093	1-216-049-91		1K	5%	1/10W	R203	1-216-121-91		1M	5%	1/10W
R094	1-216-671-11		6.8K	0.5%	1/10W	R206	1-216-073-00		10K	5%	1/10W
R095	1-216-645-11		560	0.5%	1/10W	R207	1-216-073-00		10K	5%	1/10W
_										• -	
R096	1-216-651-11	4.5	1K	0.5%	1/10W	R208	1-216-045-00		680	5%	1/10W
R097	1-216-073-00		1,0K	5%	1/10W	R209	1-216-045-00		680	5%	1/10W
R098	1-216-121-91		1M	5%	1/10W	R211		METAL CHIP	6.8K	0.5%	1/10W
R099	1-216-105-91		220K	5%	1/10W		1-216-645-11		560	0.5%	1/10W
R102	1-216-089-91	nco, UHIP	47K	5%	1/10W	R213	1-216-651-11	WE IAL CHIP	1K	0.5%	1/10W
R103	1-216-089-91	RES. CHIP	47K	5%	1/10W	R214	1-216-073-00	METAL CHID	10K	5%	1/10W
R104	1-216-295-91		0	J 70	1, 1000	R215	1-216-105-91		220K	5% 5%	1/10W
R107	1-216-089-91		47K	5%	1/10W	R216	1-216-081-00		22K	5%	1/10W
R108	1-216-295-91		0			R217	1-216-073-00		10K	5%	1/10W

CM-56		FP-406	FR-136
0111 00	ĺ	11 700	1 11 100

Ref. No.	Part No.	Description			<u>Remark</u>	Ref. No.	Part No.	Description			<u>Remark</u>
			001/	E0/	-				101/	E0/	
R218	1-216-081-00	WETAL CHIP	22K	5%	1/10W	R550	1-216-073-00	WEIAL OHIP	10K	5%	1/10W
R220	1-216-043-91	DEC CHID	560	5%	1/10W	R551	1-216-089-91	DEG CHID	47K	5%	1/10W
R221	1-216-043-91		2.2K	5%	1/10W	R552	1-216-089-91		47K	5%	1/10W
R225	1-216-037-00		0	3 /0	17 1 0 4 4	R553	1-216-073-00		10K	5%	1/10W
R227	1-216-293-91		2.2K	5%	1/10W	R554	1-216-073-00		10K	5%	1/10W
									10K	5%	1/10W
R228	1-216-043-91	neo, unir	560	5%	1/10W	R555	1-216-073-00	WE IAL OHP	IUK	376	1/1000
Doon	1 216 040 00	METAL CHID	910	5%	1/10W	R556	1-216-025-91	DEC CUID	100	5%	1/10W
R229 R230	1-216-048-00						1-216-025-91			5% 5%	1/10W
	1-216-071-00		8.2K	5%	1/10W	R560			4.7K		1/10W
R231	1-216-048-00		910	5%	1/10W	R561	1-216-049-91		1K	5%	
R232	1-216-071-00		8.2K	5%	1/10W	R562	1-216-049-91		1K	5%	1/10W
R233	1-216-089-91	RES, CHIP	47K	5%	1/10W	R563	1-216-049-91	RES, CHIP	1K	5%	1/10W
D004	1:010.075.00	METAL OLUD	401/	E0/	4.4004	DECA	1 010 040 01	DEC OUD	41/	E0/	1/400
R234	1-216-075-00		12K	5%	1/10W	R564	1-216-049-91		1K	5%	1/10W
R235	1-216-072-00		9.1K	5%	1/10W	R565	1-216-049-91		1K	5%	1/10W
R241	1-216-073-00		10K	5%	1/10W	R566	1-216-049-91		1K	5%	1/10W
R244	1-216-077-91		15K	5%	1/10W	R567	1-216-017-91	•	47	5%	1/10W
R245	1-217-671-11	METAL CHIP	1	5%	1/10W	R568	1-216-017-91	RES, CHIP	47	5%	1/10W
R247	1-216-073-00		10K	5%	1/10W	R569	1-216-017-91		47	5%	1/10W
R248	1-217-671-11		1	5%	1/10W	R570	1-216-017-91	•	47	5%	1/10W
R249	1-217-671-11		1	5%	1/10W	R572	1-216-295-91		0		
R250	1-217-671-11		1	5%	1/10W	R573	1-216-049-91		1K	5%	1/10W
R253	1-216-073-00	METAL CHIP	10K	5%	1/10W	R574	1-216-049-91	RES, CHIP	1K	5%	1/10W
R256	1-216-075-00	METAL CHIP	12K	5%	1/10W	R575	1-216-049-91		1K	5%	1/10W
R257	1-216-079-00	METAL CHIP	18K	5%	1/10W	R901	1-216-295-91		0 (DSR-20		
R259	1-216-295-91	SHORT	0			R902	1-216-295-91	SHORT	0 (DSR-20	OMDP)	
R262	1-216-093-91	RES, CHIP	68K	5%	1/10W						
R268	1-216-097-91	RES, CHIP	100K	5%	1/10W]		< VIBRATOR >			
R270	1-216-073-00	METAL CHIP	10K	5%	1/10W	X001	1-760-655-21	VIBRATOR, CRYS	TAL (20MF	łz)	
R271	1-216-073-00	METAL CHIP	10K	5%	1/10W						
R274	1-216-073-00	METAL CHIP	10K	5%	1/10W						
R275	1-216-099-00	METAL CHIP	120K	5%	1/10W			FP-406 BOARD (F	Ref No. 5,00	00 Series)
R283	1-216-089-91	RES, CHIP	47K	5%	1/10W			*****			•
R284	1-216-025-91	RES, CHIP	100	5%	1/10W		1-658-990-11	FP-406 FLEXIBLE	BOARD		
R285	1-216-025-91		100	5%	1/10W	1	3-318-201-11	SCREW (B) (1.4X	3), TAPPIN	G	
R286	1-216-049-91	RES, CHIP	1K	5%	1/10W			HOLDER, MIC			
R290	1-216-055-00	METAL CHIP	1.8K	5%	1/10W		3-970-665-01	CLEANER, MIC			
R506	1-216-049-91	RES, CHIP	1K	5%	1/10W			,			
								< CONNECTOR >			
R516	1-216-295-91	SHORT	0			ļ					
R517	1-216-665-11		3.9K	0.5%	1/10W	CN901	1-770-312-21	CONNECTOR 4P			
R518	1-216-655-11		1.5K	0.5%	1/10W	ļ					
R519	1-216-089-91		47K	5%	1/10W			< SWITCH >			
R520	1-216-089-91		47K	5%	1/10W						
		,		• .•		S901	1-762-551-11	SWITCH, PUSH (REC PROOF	=)	
R521	1-216-089-91	RES. CHIP	47K	5%	1/10W	S902		SWITCH, PUSH (,	
R524	1-216-089-91		47K	5%	1/10W				,		
R525	1-216-025-91		100	5%	1/10W						
R526	1-216-025-91		100	5%	1/10W	*	A-7074-111-A	FR-136 BOARD, 0	OMPLETE		
R528	1-216-295-91		0		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		7. 707 1 111 A	******			
11020	1 210 200 01	Onom			·					f No. 5 O	00 Series)
R529	1-219-107-91	RES CHIP	1.5	5%	1/8W	·			(110	1.140. 0,0	00 001103)
R530	1-219-107-91		1.5	5%	1/8W	*	3-087-166-01	HOLDER, INDICAT	TION THRE		
R531	1-219-107-91		1.5	5%	1/8W	•	3-307-100-01	HOLDEN, INDION	HON TODE		
	1-216-089-91	•	47K	5%	1/10W	·		, DI 177ED .			
R535			47K 0	376	1/1000			< BUZZER >			
R536	1-216-295-91	SHUNI	U			D7101	1 500 104 11	DUZZED DIEZOEI	COTDIC		
DE07	1-016 005 04	CHUDT	0			BZ101	1-029-104-11	BUZZER, PIEZOEI	CUINIU		
R537	1-216-295-91		0					- CADACITOD -			
R538	1-216-295-91		-	E0/	4/40144			< CAPACITOR >			
R541	1-216-073-00		10K	5% 5%	1/10W	0400	1 110 000 14	TANTAL HAA OUUS	22	000/	101/
R542	1-216-073-00		10K	5%	1/10W	C109		TANTALUM CHIP		20%	10V
R543	1-216-025-91	neo, unip	100	5%	1/10W	C110		CERAMIC CHIP	0.1uF		25V
DE45	1 010 005 03	DEC OUR	A 717	En/	1/10/4/	C111		CERAMIC CHIP	0.1uF	000/	25V
R545	1-216-065-91		4.7K	5%	1/10W	C112		TANTALUM CHIP		20%	10V
R546	1-216-073-00		10K	5%	1/10W	C113	1-113-082-11	TANTALUM CHIP	JJUF	20%	10V
R547	1-216-025-91	' - '	100	5%	1/10W	0444	1 104 150 44	CEDAMIC CUID	0.4		0511
R549	1-216-065-91	neo, UMIP	4.7K	5%	1/10W	C114	1-104-156-11	CERAMIC CHIP	0.1uF		25V

FR-136

Ref. N	^	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
C11			CERAMIC CHIP	1000PF	5%	50V	1101.110.	<u>raitivo.</u>	Description			Homan
C11		1-104-337-11		220uF	20%	10V	R103	1-216-842-11	METAL CHIP	56K	5%	1/16W
C11			CERAMIC CHIP	1000PF	5%	50V	R105	1-216-811-11		150	5%	1/16W
C11			CERAMIC CHIP	1000PF	5%	50V	R106	1-216-841-11		47K	5%	1/16W
	-						R107	1-216-841-11	METAL CHIP	47K	5%	1/16W
			< CONNECTOR >				R108	1-216-841-11	METAL CHIP	47K	5%	1/16W
CN ⁻	104	1-774-770-11	CONNECTOR, FFC	C/FPC 30P			R109	1-216-841-11	METAL CHIP	47K	5%	1/16W
							R110	1-216-841-11		47K	5%	1/16W
			< DIODE >				R111	1-216-841-11		47K	5%	1/16W
			D1000 11111111				R112	1-216-841-11		47K	5%	1/16W
D10			DIODE MA151W		11	•	R113	1-216-841-11	WEIAL CHIP	47K	5%	1/16W
D10			DIODE CL-200Y-				R114	1-216-837-11	METAL CHIP	22K	5%	1/16W
D11			DIODE CL-200Y				R115	1-216-837-11		22K	5%	1/16W
D11			DIODE CL-200Y		02,		R116	1-216-817-11		470	5%	1/16W
5.,	•						R119	1-216-797-11		10	5%	1/16W
D11	2	8-719-066-82	DIODE CL-200Y	G-C-TU (PL	AY)		R120	1-216-797-11	METAL CHIP	10	5%	1/16W
D11			DIODE CL-155U		I/STAND	BY)						
D11			DIODE RD6.2M-				R121	1-216-797-11		10	5%	1/16W
D11			DIODE RD6.2M-				R122	1-216-797-11		10	5%	1/16W
D11	6	8-719-106-08	DIODE RD6.2M-	T1B2			R123	1-216-841-11		47K	5%	1/16W
			D1000 01 0001	0 711 (0714			R124	1-216-837-11		22K	5%	1/16W
D11	17	8-719-061-58	DIODE CL-200Y	-G-TU (REV	/)		R125	1-216-833-91	HES, CHIP	10K	5%	1/16W
			< FERRITE BEAD	>			R126	1-216-833-91	RES. CHIP	10K	5%	1/16W
							R129	1-216-837-11		22K	5%	1/16W
FB1	01	1-414-445-11	FERRITE	0uH			R130	1-216-833-91	RES, CHIP	10K	5%	1/16W
FB1	02	1-414-445-11	FERRITE	0uH			R131	1-216-833-91	RES, CHIP	10K	5%	1/16W
FB1	03	1-414-445-11		0uH			R138	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
FB1		1-414-445-11		0uH								
FB1	05	1-414-445-11	FERRITE	0uH			R139	1-216-837-11		22K	5%	1/16W
							R140	1-216-833-91		10K	5%	1/16W
FB1		1-414-445-11		0uH			R141	1-216-829-11		4.7K	5%	1/16W 1/16W
FB1		1-414-445-11		OuH			R142	1-216-827-11		3.3K 2.2K	5% 5%	1/16W
FB1 FB1		1-414-445-11 1-414-445-11		OuH OuH			R143	1-216-825-11	WEIAL UNIF	2.ZN	J 70	1/1000
FB1		1-414-445-11		OuH			R144	1-216-845-11	METAL CHIP	100K	5%	1/16W
	10	1 414 440 11	I CHAILE	oui!			R145	1-216-797-11		10	5%	1/16W
FB1	11	1-414-445-11	FERRITE	0uH			R146	1-216-797-11		10	5%	1/16W
FB1			INDUCTOR CHIP	0uH			R147	1-216-797-11	METAL CHIP	10	5%	1/16W
FB1	13		INDUCTOR CHIP				R148	1-216-797-11	METAL CHIP	10	5%	1/16W
FB1	14	1-414-229-11	INDUCTOR CHIP	0uH			l					
FB1	15	1-414-229-11	INDUCTOR CHIP	0uH			R149	1-216-821-11		1K	5%	1/16W
							R151	1-216-811-11		150	5%	1/16W
FB1			INDUCTOR CHIP				R152	1-216-811-11		150	5%	1/16W
FB1			INDUCTOR CHIP				R153	1-216-811-11		150	5%	1/16W
FB1	18	1-414-445-11	FERRIIE	OuH			R154	1-216-811-11	WEIAL CHIP	150	5%	1/16W
			< IC >				R155	1-216-811-11	METAL CHIP	150	5%	1/16W
							R156	1-216-811-11	METAL CHIP	150	5%	1/16W
IC1	03	8-759-056-81	IC M66312FP-T	1								
IC1			IC uPD16311GC	-AB6					< SWITCH >			
IC1	05	8-749-923-29	IC RS-20E-T				0101	1 700 000 01	CAUTOU TACTU	(DECET)		
			TI LIODEOOFNE	INDIATOR			S101		SWITCH, TACTILE		AOTE)	
			< FLUORESCENT	INDICATOR	{ >		S102		SWITCH, SLIDE (SWITCH, SLIDE (MOTE)	
NID.	104	1 517 760 11	TUBE, FLUORESC	ENT INDIC	ATOD		S104 S105		SWITCH, SLIDE (MITOR)	
ND.	101	1-517-709-11	TUBE, FLUUNESU	CINT INDIO	AIUN		S103		SWITCH, TACTILE			
			< TRANSISTOR >				0.00	. 702 000 21	011,7011, 1110112		,	
							\$107		SWITCH, SLIDE (
Q10)1	8-729-424-18		UN2113-T			S108		SWITCH, TACTILE			
Q10		8-729-421-19		UN2213-T			S109	1-692-838-21	SWITCH, TACTILE			ם מבסבייי
Q10		8-729-421-19		UN2213-T				1 000 000 01	OWNED TACK		•	R RESET)
Q10		8-729-421-19		UN2213-T			S111		SWITCH, TACTILE			
Q10	10	8-729-421-19	HUIGIGNAHI	UN2213-T	^		S112	1-092-030-21	SWITCH, TACTILE	. (אטפטבת	F(UEAA)	
Q10	17	8-729-421-19	TRANSISTOR	UN2213-T	χ		S113	1-692-838-21	SWITCH, TACTILE	(RUBBER	(PLAY)	
Q11		8-729-421-19		UN2213-T		•	S114		SWITCH, TACTILE			
O. I	. •	5 7 25 7 21 10			- •		S115		SWITCH, TACTILE)
			< RESISTOR >				S116	1-692-838-21	SWITCH, TACTILE	(RUBBER		
							\$117		SWITCH, TACTILE		•	

FR-136 HG-1 HP-100

							L.				00
Ref. No.	Part No.	Description			<u>Remark</u>	Ref. No.	Part No.	Description			Remark
						*	A-7073-471-A	HP-100 BOARD,	COMPLETE		
S118 S119		SWITCH, TACTII SWITCH, TACTII						*********		.t N E O	
S119		SWITCH, TACTI							(Re	it.No. 5,0	00 Series)
S121	1-692-838-21	SWITCH, TACTI	LE (RUBBÉF		R)			< CAPACITOR >			
S122	1-692-838-21	SWITCH, TACTI	LE (RUBBER	R) (DUP)		0004	4 400 004 44	EL FOT OLUB			
79						C001	1-128-004-11	CERAMIC CHIP	10uF 0.1uF	20%	16V 16V
*	A-7073-576-A	HG-1 BOARD, C				C003		CERAMIC CHIP	0.1uF		16V
		*****				C004	1-128-004-11	ELECT CHIP	10uF	20%	16V
			(Re	ef.No. 8,0	000 Series)	C005	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
		< CAPACITOR >				C006	1-164-360-11	CERAMIC CHIP	0.1uF		16V
				- 1, 1		C007		CERAMIC CHIP	47PF	5%	50V
C001		CERAMIC CHIP	0.0015uF	5%	50V	C008	1-128-004-11		10uF	20%	16V
C002 C003	1-103-038-91	CERAMIC CHIP	0.1uF 10uF	20%	25V 16V	C009 C010		CERAMIC CHIP	0.022uF 0.022uF	10% 10%	25V 25V
C004	1-124-259-11		4.7uF	20%	35V	0010	1-104-221-11	CENAIMIC CHIP	U.UZZUF	1.070	201
C005	1-126-157-11	ELECT	10uF	20%	16V	C011	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V
		< CONNECTOR >	•					< CONNECTOR >	,		
CN001	1-958-813-11	HARNESS (DH-5	50)			CN001	1-566-528-11	CONNECTOR, FP	C (ZIF) 12P		
CN002	1-506-489-11	PIN, CONNECTO	R 10P					< DIODE >	,		
		< DIODE >									
D001	0 710 100 00	DIODE DOLEM	T400			D001	8-719-421-59	DIODE MA3075	WA- (TX)		
D001 D002		DIODE RD15M- DIODE RD15M-				D002 D003		DIODE MA3075			
D003	8-719-800-76	DIODE 1SS123	-T1			D004		DIODE MA3075			
D004		DIODE 1SS123				D005	8-719-421-59	DIODE MA3075	WA- (TX)		
D005	8-719-022-76	DIODE RD30M-	-T1B			Door	0.740.404.50	DIODE 1440075	1446 (77.6)		
D006	8-719-022-76	DIODE RD30M-	-T1B			D006 D007	8-719-421-59 8-719-421-59	DIODE MA3075 DIODE MA3075	WA- (1X) WΔ- (TX)		
						D008		DIODE MA3075			
		< 10 >				D009	8-719-421-59	DIODE MA3075	WA- (TX)		
IC001	8-759-248-87	IC MM1256XF-I	RE			D010	8-719-421-59	DIODE MA3075	WA- (TX)		
IC002		IC TL431CPSR	DL			D011	8-719-421-59	DIODE MA3075	WA- (TX)		*
						D012	8-719-421-59	DIODE MA3075	WA- (TX)		
		< TRANSISTOR >	>					< FERRITE BEAD	>		
Q001	8-729-120-28		2801623-								
Q002 Q003	8-729-120-28 8-729-120-28		2SC1623-			FB001 FB002	1-500-241-22		OuH		
Q003	8-729-014-91		2SD2185S			FB002	1-500-241-22 1-500-241-22		OuH OuH		
							. 000 2 11 22		ouri		
		< RESISTOR >						< IC >			
R001 R002	1-208-830-11 1-208-830-11		100K	0.5%	1/10W	IC001	8-759-369-73	IC NJM4556AM	-A-TE2		
R003	1-208-830-11		100K 100K	0.5% 0.5%	1/10W 1/10W			< JACK >			
R004	1-208-848-11		560K	0.5%	1/10W			< JAUN >			
R005	1-208-830-11	METAL CHIP	100K	0.5%	1/10W	J001	1-569-809-11	JACK (SMALL TY	PE) (PHONE	S)	
R007	1-208-830-11		100K	0.5%	1/10W			< RESISTOR >			
R008 R009	1-208-814-91		22K	0.5%	1/10W	5004	4 040 000 04	DEC. 0445			
R010	1-208-806-11 1-208-822-11		10K 47K	0.5% 0.5%	1/10W 1/10W	R001 R002	1-216-833-91 1-216-821-11				1/16W
R011	1-208-822-11		47K	0.5%	1/10W	R003	1-216-821-11				1/16W 1/16W
						R004	1-216-833-91	RES, CHIP	10K	5%	1/16W
R012	1-216-208-00		2.7K	5%	1/8W	R005	1-216-835-11	METAL CHIP	15K		1/16W
R013 R014	1-216-208-00 1-208-795-11		2.7K 3.6K	5% 0.5%	1/8W 1/10W	R006	1-216-831-11	METAL CUID	6.8K	F0/.	1/16/1/
R015	1-216-208-00		2.7K	5%	1/10W	R007	1-216-831-11				1/16W 1/16W
R016	1-216-208-00		2.7K	5%	1/8W	R008	1-216-835-11	METAL CHIP	15K	5%	1/16W
		< RELAY >					1-216-821-11				1/16W
		NILLAI >				R010	1-216-821-11	IVIETAL UMIP	1K	5%	1/16W
RY001	1-755-259-11	RELAY					1-216-809-11				1/16W
						R012	1-216-809-11	METAL CHIP	100	5%	1/16W

HP-100 JC-19

										**			
Ref. No.	Part No.	<u>Description</u>			<u>Remark</u>	Re	f. No.	Part No.	<u>Description</u>			<u>Remark</u>	
		< VARIABLE RES	SISTOR >			(C162	1-162-974-11	CERAMIC CHIP	0.01uF		50V	
D) 1004		550					C163		CERAMIC CHIP	0.01uF		50V	
RV001 RV002	1-238-612-11 1-238-744-11	RES, VAR, CARB RES, VAR, CARB				'	C164	1-162-974-11	CERAMIC CHIP	0.01uF		50V	
RV002		RES, VAR, CARB				١,	C165	1-162-974-11	CERAMIC CHIP	0.01uF		50V	
	. 200	7120, 7711, 071110	011, 0011 (1	THEO EE	V.L.)	1	C166	1-162-974-11		0.01uF		50V	
							C167	1-162-974-11	CERAMIC CHIP	0.01uF		50V	
*		JC-19 BOARD, C					C168	1-162-974-11		0.01uF		50V	
*	A-7067-126-A	JC-19 BOARD, C		(DSR-20I	VIDP)	'	C170	1-162-974-11	CERAMIC CHIP	0.01uF		50V	
				ef.No. 2.0	000 Series)	١,	C171	1-162-974-11	CERAMIC CHIP	0.01uF		50V	
			ν.,	-,·			C172	1-162-974-11		0.01uF		50V	
	7-685-132-19	SCREW +P 2.6X	5 TYPE2 NO	ON-SLIT		1	C173	1-110-569-11	TANTALUM CHIP		20%	6.3V	
		< CAPACITOR >					C174	1-110-569-11			20%	6.3V	
		< GAPAGITUM >				'	C175	1-110-509-11	TANTALUM CHIP	4/ur	20%	6.3V	
C101	1-104-847-11	TANTALUM CHIP	22uF	20%	4V		C179	1-135-259-11	TANTALUM CHIP	10uF	20%	6.3V	
C102	1-104-847-11	TANTALUM CHIP		20%	4V		C180		CERAMIC CHIP	0.01uF		50V	
C103 C107	1-104-847-11			20%	4V	1	C181		CERAMIC CHIP	33PF	5%	50V	
C107		TANTALUM CHIP TANTALUM CHIP		20% 20%	20V 20V		C182 C183		TANTALUM CHIP TANTALUM CHIP		20% 20%	6.3V 6.3V	
0100	1 100 171 21	WINTERN OTH	Tui	2070	200	`	0100	1-100-209-11	IANTALON OTH	1001	20 /6	0.57	
C109	1-135-177-21	TANTALUM CHIP		20%	20V	(C184	1-162-974-11	CERAMIC CHIP	0.01uF		50V	
C110	1-135-259-11	TANTALUM CHIP		20%	6.3V		C185	1-162-974-11	CERAMIC CHIP	0.01uF		50V	
C111 C112	1-135-259-11 1-135-259-11	TANTALUM CHIP		20% 20%	6.3V 6.3V		C186 C187	1-104-847-11	TANTALUM CHIP		20%	4V	
C116		CERAMIC CHIP	0.01uF	20%	50V		2201	1-104-847-11 1-162-970-11	CERAMIC CHIP	22uF 0.01uF	20% 10%	4V 25V	
									02.0.000	0.0141	1070	201	
C117	1-162-974-11	CERAMIC CHIP	0.01uF		50V	1	0202	1-164-357-11	CERAMIC CHIP	1000PF	5%	50V	
C118 C119	1-162-974-11 1-162-915-11	CERAMIC CHIP	0.01uF 10PF	0.5PF	50V 50V	1	0203 0204	1-162-970-11 1-162-970-11	CERAMIC CHIP	0.01uF 0.01uF	10%	25V 25V	
C120		CERAMIC CHIP	10PF	0.5PF	50V		020 4 0205	1-162-970-11	CERAMIC CHIP	0.01uF 0.01uF	10% 10%	25V 25V	
C121		CERAMIC CHIP	10PF	0.5PF	50V		206		CERAMIC CHIP	0.01uF	10%	25V	
0.00						١.							
C122 C123	1-162-974-11 1-162-974-11	CERAMIC CHIP	0.01uF 0.01uF		50V 50V		C207 C208	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C124	1-162-974-11	CERAMIC CHIP	0.01uF		50V 50V	t i	200 209	1-162-970-11 1-162-970-11	CERAMIC CHIP	0.01uF 0.01uF	10% 10%	25V 25V	
C125		CERAMIC CHIP	0.01uF		50V		2210	1-135-259-11	TANTALUM CHIP	10uF	20%	6.3V	
C127	1-135-259-11	TANTALUM CHIP	10uF	20%	6.3V	C	211	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V	
C128	1-162-974-11	CERAMIC CHIP	0.01uF		50V	, ا	212	1 104 047 11	TANTALUM CHIP	00"	000/	417	
C129		TANTALUM CHIP		20%	6.3V		214	1-104-847-11	CERAMIC CHIP	22uF 82PF	20% 5%	4V 50V	
C130		CERAMIC CHIP	0.01uF		50V		215		CERAMIC CHIP	390PF	5%	50V	
C131		CERAMIC CHIP	0.01uF		50V		216		CERAMIC CHIP	0.01uF		50V	
C132	1-135-259-11	TANTALUM CHIP	10uF	20%	6.3V	C	217	1-135-259-11	TANTALUM CHIP	10uF	20%	6.3V	
C133	1-162-974-11	CERAMIC CHIP	0.01uF		50V	C	218	1-162-974-11	CERAMIC CHIP	0.01uF		50V	
C135		CERAMIC CHIP	0.01uF		50V		219		TANTALUM CHIP		20%	6.3V	
C136		CERAMIC CHIP	0.01uF		50V		220		TANTALUM CHIP		20%	6.3V	
C137 C138		CERAMIC CHIP CERAMIC CHIP	0.01uF 0.01uF		50V 50V		221		CERAMIC CHIP TANTALUM CHIP	0.01uF	10%	25V	
0100	1-102-374-11	OLIMANIO GITIF	0.0141		J0V	·	1223	1-133-177-21	TANTALUW CHIP	TUF	20%	20V	
C139		TANTALUM CHIP		20%	6.3V	C	224	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C141		TANTALUM CHIP		20%	6.3V		225		TANTALUM CHIP		20%	20V	
C143 C148		TANTALUM CHIP CERAMIC CHIP	10uF 0.01uF	20%	6.3V 50V		226		CERAMIC CHIP	0.0047uF	10%	50V	
C149		CERAMIC CHIP	0.01uF		50V 50V		227 229		CERAMIC CHIP TANTALUM CHIP	0.0033uF 3.3uF	10% 20%	50V 16V	
	, ,,,,					·	,	. 101 012 11	Will Will Coll Coll	0.001	2070	101	
C150		CERAMIC CHIP	0.01uF		50V		231		CERAMIC CHIP	470PF	5%	50V	
C151 C152		TANTALUM CHIP		20%	6.3V		233 234		CERAMIC CHIP	2PF	0.25PF		
C152		TANTALUM CHIP		20% 20%	6.3V 6.3V		238		CERAMIC CHIP CERAMIC CHIP	0.01uF 0.01uF		50V 50V	
C154		TANTALUM CHIP		20%	6.3V		241		CERAMIC CHIP	0.001uF	10%	50V	
C155		TANTAL UM CHIP		20%	6.3V				CERAMIC CHIP	0.1uF	E0/	16V	
C156 C157		TANTALUM CHIP		20% 20%	6.3V 6.3V			1-162-917-11 1-162-974-11		15PF 0.01uF	5%	50V 50V	
C158		TANTALUM CHIP		20%	6.3V			1-162-974-11		0.01uF		50V 50V	
C159		TANTALUM CHIP		20%	6.3V			1-162-974-11		0.01uF		50V	
0160	1_160_074_44	CEDAMIC CUID	0.01		501/		0.40	1 110 500 44	TANITAL UNA CUUC	47 	000/	417	
C160 C161	1-162-974-11 1-162-974-11		0.01uF 0.01uF		50V 50V			1-110-569-11 1-162-970-11	TANTALUM CHIP	4/uF 0.01uF	20% 10%	4V 25V	
		91111	J 1 W1		,	-		0.0 11	2_12 avii 0 01 III	515,1 UI	1 0 /0		

											L	
Re	f. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
				0.015	1.00/	25V	C521	1 160 070 11	CERAMIC CHIP	0.01uF	10%	25V
	C252	1-162-970-11	CERAMIC CHIP CERAMIC CHIP	0.01uF 0.01uF	10% 10%	25V 25V	C521		CERAMIC CHIP	0.01uF	10 /6	16V
	C253 C254	1-162-970-11		0.01uF	10%	25V	C523		TANTALUM CHIP		20%	10V
	0204	1-102-970-11	GENAINIO GIIII	0.0141	1070	201	0020	1 104 001 11	MINIMEDIA OTTI	· ·	2070	101
	C255	1-164-357-11	CERAMIC CHIP	1000PF	5%	50V	C524	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
	C256		CERAMIC CHIP	0.01uF		50V	C701		TANTALUM CHIP	10uF	20%	6.3V
	C257		CERAMIC CHIP	1000PF	5%	50V	C702		CERAMIC CHIP	0.1uF		16V
	C258	1-162-964-11		0.001uF	10%	50V	C703	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C259	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	C704	1-135-259-11	TANTALUM CHIP	10uF	20%	6.3V
												4014
	C260		TANTALUM CHIP		20%	16V	C705	1-164-360-11		0.1uF		16V
	C261		CERAMIC CHIP	0.033uF	10%	16V	C706		CERAMIC CHIP	0.1uF		16V 16V
	C262		CERAMIC CHIP	0.22uF 0.1uF	10%	16V 16V	C707 C708		CERAMIC CHIP	0.1uF 0.1uF		16V
	C401 C402		CERAMIC CHIP	0.1uF	10 /0	16V	C709		CERAMIC CHIP	0.1uF		16V
	0402	1-104-300-11	CENAIMIC CITI	o. rui		104	0700	1 104 000 11	OLITAWIO OTTI	0.741		
	C403	1-164-360-11	CERAMIC CHIP	0.1uF		16V	C710	1-104-847-11	TANTALUM CHIP	22uF	20%	4V
	C404	1-162-970-11		0.01uF	10%	25V	C711	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C405	1-162-970-11		0.01uF	10%	25V	C712	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
	C406	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V	C713	1-164-230-11	CERAMIC CHIP	220PF	5%	50V
	C407	1-135-259-11	TANTALUM CHIP	10uF	20%	6.3V	C714	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
									0554440 01115	0000	En/	501
	C408	1-135-259-11			20%	6.3V	C715	1-162-919-11		22PF	5%	50V
	C410		CERAMIC CHIP	0.01uF	10%	25V	C801		CERAMIC CHIP	0.01uF	5%	50V 50V
	C412	1-162-970-11		0.01uF 0.01uF	10% 10%	25V 25V	C802 C803		CERAMIC CHIP CERAMIC CHIP	47PF 10PF	0.5PF	50V 50V
	C413 C421	1-162-970-11	CERAMIC CHIP TANTALUM CHIP		20%	6.3V	C804		CERAMIC CHIP	10PF	0.5PF	50V
	0421	1-111-200-11	MINIALUM CITIF	10001	20 /0	0.00	0004	1-102-515-11	CETIANITO OTTI	1011	0.511	001
	C422	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C807	1-164-357-11	CERAMIC CHIP	1000PF	5%	50V
	C423	1-162-964-11		0.001uF	10%	50V	C809	1-162-974-11	CERAMIC CHIP	0.01uF		50V
	C424	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C810	1-110-569-11	TANTALUM CHIP	47uF	20%	6.3V
	C425	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V	C811		CERAMIC CHIP	47PF	5%	50V
	C426	1-164-505-11	CERAMIC CHIP	2.2uF		16V	C812	1-110-569-11	TANTALUM CHIP	47uF	20%	6.3V
							2010		0504440 0440	0.04 =		501
	C427	1-162-964-11		0.001uF	10%	50V	C813	1-162-974-11		0.01uF		50V
	C428	1-164-360-11		0.1uF		16V	C814		CERAMIC CHIP CERAMIC CHIP	0.01uF 0.01uF	10%	50V 25V
	C429		CERAMIC CHIP	0.1uF 0.001uF	10%	16V 50V	C815 C816		CERAMIC CHIP	0.01uF	1076	50V
	C430 C431		CERAMIC CHIP	0.001uF	10%	25V	C831	1-135-259-11			20%	6.3V
	0401	1 102-370-11	OLITAWIO OTIII	0.0141	1070	201	0001	1 100 200 11	, av , Loui om	1001	2070	0.01
	C432	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C832	1-135-259-11	TANTALUM CHIP	10uF	20%	6.3V
	C433	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C833	1-110-569-11	TANTALUM CHIP	47uF	20%	6.3V
	C434	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C834	1-135-151-21	TANTALUM CHIP	4.7uF	20%	4V
	C435		CERAMIC CHIP	0.047uF	10%	16V	C835	1-135-151-21			20%	4V
	C436	1-164-505-11	CERAMIC CHIP	2.2uF		16V	C837	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
			0504440 0440	4 =	400/	4017	0000	4 405 050 44	TABITAL UNA OLUD	40	000/	0.017
	C437	1-109-982-11		1uF	10%	10V	C838	1-135-259-11			20%	6.3V
	C438	1-109-982-11	CERAMIC CHIP CERAMIC CHIP	1uF 10PF	10% 0.5PF	10V 50V	C839 C840	1-162-923-11 1-135-259-11		47PF	5% 20%	50V 6.3V
	C439 C440		CERAMIC CHIP	10PF	0.5PF	50V 50V	C843	1-162-923-11		47PF	5%	50V
	C441		CERAMIC CHIP	0.01uF	10%	25V	C844	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
	0441	1 102,070 11	OLI II III II OI III	0.0141	1070		0011	02 020	02.0			•••
	C442	1-135-259-11	TANTALUM CHIP	10uF	20%	6.3V	C845	1-104-847-11	TANTALUM CHIP	22uF	20%	4V
	C501		CERAMIC CHIP	0.01uF	10%	25V	C846	1-104-847-11	TANTALUM CHIP	22uF	20%	4V
	C502		CERAMIC CHIP	0.01uF	10%	25V	C847	1-164-676-11	CERAMIC CHIP	2200PF	5%	16V
	C503		TANTALUM CHIP	10uF	20%	10V	C848	1-164-676-11		2200PF	5%	16V
	C504	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C849	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V
				0.04.5	400/	051	0050	4 404 000 44		00005	F0/	501
	C505	1-162-970-11		0.01uF	10%	25V	C850		CERAMIC CHIP	390PF	5%	50V
	C506	1-162-970-11	CERAMIC CHIP TANTALUM CHIP	0.01uF	10% 20%	25V 6.3V	C851 C852	1-164-392-11	CERAMIC CHIP CERAMIC CHIP	390PF 0.1uF	5%	50V 16V
	C511 C512	1-135-259-11	CERAMIC CHIP	0.1 u F	2076	16V	C853	1-104-300-11			20%	6.3V
	C513	1-164-227-11		0.022uF	10%	25V	C854	1-135-149-21			20%	10V
	5010	1 104 551-11	SELECTION OF THE	0.0EEUI	. 5 / 5	·	1 30,5				,,	
	C514	1-164-360-11	CERAMIC CHIP	0.1uF		16V	C855	1-163-009-11	CERAMIC CHIP	0.001uF	10%	50V
	C515	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C856		CERAMIC CHIP	0.001uF	10%	50V
	C516	1-104-847-11			20%	4V	C857		CERAMIC CHIP	0.1uF		16V
	C517		CERAMIC CHIP	0.01uF	10%	25V	C859		CERAMIC CHIP	0.1uF		16V
	C518	1-162-917-11	CERAMIC CHIP	15PF	5%	50V	C860	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V
	0540	1 160 070 11	CEDAMIC CLUB	0.015	10%	25V	C861	1_164 260 44	CERAMIC CHIP	0.1uF		16V
	C519 C520	1-162-970-11	CERAMIC CHIP	0.01uF 22PF	10% 5%	50V	C862		TANTALUM CHIP		20%	4V
	UJZU	1-102-212-11	VEHANIO CITIE		J /0	00 V	, 0002	1 100-101-21	TAREALOW OF IT	T. / UI	EU /U	-T V

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	<u>Description</u>	<u>Remark</u>
C863	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V	D501		DIODE MA111-TX	
C864	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	D503	8-719-421-27	DIODE. MA728-TX	
C865	1-110-569-11	TANTALUM CHIP	47uF	20%	6.3V	D504		DIODE MA111-TX	
						D901	8-719-073-01	DIODE MA111-TX	
C901		CERAMIC CHIP	0.01uF	10%	25V	D000	0.740.055.06	DIODE 1/1470TI 1 0	
C902		CERAMIC CHIP	0.1uF 0.1uF		16V 16V	D902 D903		DIODE KV1470TL1-3 DIODE MA111-TX	
C903 C904		CERAMIC CHIP TANTALUM CHIP	10uF	20%	6.3V	D903		DIODE MA111-TX	
C905		CERAMIC CHIP	0.1uF	2070	16V	5510	0 7 13 070 01	DIODE WATTI IX	
0300	1 104 000 11	OZNAMIO OM	0.101					< FERRITE BEAD >	
C906	1-110-569-11	TANTALUM CHIP	47uF	20%	6.3V				
C907		CERAMIC CHIP	0.1uF		16V	FB401	1-543-955-22		
C908	1-164-360-11	CERAMIC CHIP	0.1uF		16V	FB402	1-543-955-22	FERRITE OuH	
C909		TANTALUM CHIP		20%	6.3V				
C910	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V			< FILTER >	
0011	1 104 000 11	OFFI AMIC CUID	0.1		161/	E1101	1 000 045 01	EUTED I OW DASS /5 50	(/ U_7)
C911 C912		CERAMIC CHIP	0.1uF 0.1uF	10%	16V .16V	FL101 FL102		FILTER, LOW PASS (5.5) FILTER, LOW PASS (5.5)	
C914		CERAMIC CHIP	0.0022uF	10%	50V	FL102		FILTER, LOW PASS (5.5)	
C915		CERAMIC CHIP	0.002241	10%	25V	12,00	7 200 010 21	1.121211, 2011 1 1100 (0.01	
C916		CERAMIC CHIP	47PF	5%	50V			< IC >	
C917	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V	IC009		IC BA10324AFV-E2	
C919		CERAMIC CHIP	1000PF	5%	50V	IC010		IC BA10324AFV-E2	
C920		CERAMIC CHIP	1000PF	5%	50V	IC011		IC BA10324AFV-E2	
C921		CERAMIC CHIP	1000PF	5%	50V	IC012		IC BA10324AFV-E2	
C922	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V	IC013	8-759-510-71	IC BA10358F-E2	
0004	1 104 000 11	OED ASSIG OURD	0.45		16/1	1C014	0 750 250 51	IC NJM431M (TE2)	
C924 C926		CERAMIC CHIP CERAMIC CHIP	0.1uF 0.01uF	10%	16V 25V	IC014		IC CXD2300Q-T4	
C927		CERAMIC CHIP	3PF	0.25PF		IC016		IC CXD2300Q-T4	
C929		CERAMIC CHIP	1000PF	5%	50V	IC017		IC CXD2300Q-T4	
C930		CERAMIC CHIP	1000F	5%	50V	IC018		IC TC74HC4066AFT (EL	_)
0000				• / •		,		, , , , , , , , , , , , , , , , , , ,	,
C931	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	IC019		IC S-81322HG-KW-T1	
C932	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	IC200		IC CXD3100R	
C933		CERAMIC CHIP	1000PF	5%	50V	IC205		IC CXD2193AR-ER	Section 2000
C934		CERAMIC CHIP	100PF	5%	50V	IC206		IC TC7S08FU (TE85R)	
C935	1-164-360-11	CERAMIC CHIP	0.1uF		16V	IC207	8-759-368-81	IC TK11630UTL	
0000		OED ANNO OLUD	40005	F0/	501/	10000	0.750.500.07	IO TOTAL/LICEOSAET /EI	1
C936		CERAMIC CHIP	100PF	5%	50V 50V	IC209 IC210		IC TC74VHC123AFT (EL IC TC7SET08FU (TE85F	
C937		CERAMIC CHIP	1000PF 1000PF	5%	50V			IC TC74HC221AF (EL)	
C940		CERAMIC CHIP CERAMIC CHIP	1000FF	5% 10%	10V	10211	9-759-239-30 9-750-089-55	IC TC7W00FU (TE12R)	
C941 C942		CERAMIC CHIP	0.1uF	10%	16V	IC213		IC TC74HC4053AFT (EL	
0342	1-107-020-31	OLIVAIMIO OTIJI	0.141	1070	100	102.10	0 700 020 02	10 101 1110 100010 1 (22	•
		< CONNECTOR >				IC214	8-759-491-31	IC TC74VHCT00AF (EL)	1
						IC401		IC CXD3103R	
CN101	1-506-474-11	PIN, CONNECTOR	R 9P			IC402	8-759-328-28	IC ZA4024	
CN103	1-774-666-11	CONNECTOR, FFC	C/FPC 30P			IC403	8-759-328-28		
CN104		CONNECTOR, FFC				IC410	8-759-433-17	IC uPD482445LG4-B10	-9MH-E2-HDC
CN411		CONNECTOR, FFC				10444	0 770 505 00	10 PD000040D 004 I	MI
CN412	1-750-345-11	CONNECTOR, FFC	J/EPC (ZIF)	30P		IC411		IC uPD82094GD-001-L	NL
	4 004 504 44	DIN CONNECTOR		(O8 8D) OF	,	IC421		IC CXP912032-074R	
* CN501	1-691-591-11	PIN, CONNECTOR	(1.5MM) ((SIVID) 81	,	1C422	8-752-378-75	IC CXD3106R IC S579174PZ-TEB	
		CONNECTOR, BO		IAND ZUF	,	IC501 IC502		IC AK6440AM-E2	
* CN701 * CN831		PIN, CONNECTOR PIN, CONNECTOR		(CMD) SE	,	10302	0-708-440-80	IC ARUTTUAINI-LZ	
CNOST	1-001-001-11	I IIV, OCIVIVECTOR	. (יסואוט) טו		10503	8-759-058-58	IC TC7S04FU (TE85R)	
		< TRIMMER >				IC504		IC MB88146APFV-G-BN	ID-ER
						IC510	8-759-431-95	IC S-81230SGUP-DQB-	T1
CT201	1-141-423-61	CAP, ADJ 20PF (A	NFC)			IC511	8-759-512-69	IC S-81350HG-KD-T1	
						IC701	8-759-430-56	IC CXD2194AR	
		< DIODE >				10700	0.750.400.00	IO TODALLIMATET	
D001	0.740.044.00	DIODE 1011 1707	1.00			10702		IC TSB11LV01PT-TEB	
D201		DIODE KV1470T				IC703		IC HD6433837TB55X IC CXD2705AQ	
D421		DIODE KV1470T				IC801 IC802		IC TLV431ACDBV2	
D422		DIODE KV1470T DIODE HSM88W				IC802		IC TC74ACT08FS (EL)	
D423 D424		DIODE HSWIGHT				10004	0 100-400-00	10 1014A010010 (EL)	
DTCT	0.710.000-00	DIODE KVITIOI	_, 0			IC805	8-752-379-31	IC CXD3107R	
D425	8-719-055-86	DIODE KV1470T	L1-3			IC807		IC TC74LCX08FT (EL)	

										·	
	Ref. No.	Part No.	Description	E	Remark	Ref. No.	Part No.	Description			Remark
	IC831		IC NJM2115V	-		Q030		TRANSISTOR	2SC3326	N-TE85L-	
	10832	8-759-358-47	IC NJM2115V	(TE2)							
	IC833	8-759-358-47	IC NJM2115V	(TE2)		Q031		TRANSISTOR		N-TE85L-	
	IC835	8-750-358-47	IC NJM2115V	(TE2)		Q032 Q033		TRANSISTOR TRANSISTOR		A-T106-R A-T106-R	
	IC836		IC NJM2115V			Q034		TRANSISTOR		A-1106-R A-T106-R	
	IC837		IC AK4520A-V			Q035		TRANSISTOR	2SC4081		
	IC838		IC TK15125MT								
	IC840	8-759-358-47	IC NJM2115V	(TE2)		Q036		TRANSISTOR	2SC4081		
	IC841	0 750 404 00	IC TOTECERE	TEGED)		Q037		TRANSISTOR	2SC4081		
	IC901	8-759-523-97	IC TC75S56F (IC TC74VHC12	1 E00H) 3AFT (FL)		Q039 Q040		TRANSISTOR TRANSISTOR	2SA1576 2SC4081	A-T106-R	
,	IC902		IC TC74VHC74			Q040 Q041		TRANSISTOR		A-T106-R	
	IC903		IC TC7W74FU						20/110/10	,, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
	IC904	8-759-429-28	IC CXD8630R			0042		TRANSISTOR	2SC4081		
	ICODE	0 750 500 07	IC T074V/3040	0 A ET /EL \		Q043		TRANSISTOR		A-T106-R	
	IC906 IC907		IC TC74VHC12 IC TC7S86FU (Q044 Q045		TRANSISTOR TRANSISTOR	2804081		
	IC908		IC TC7W08FU			Q048		TRANSISTOR	UN5213-	A-T106-R TX	
	IC909		IC TC74VHC74			40.0	0 120 102 12	110.000.0101	0110210	· · ·	
	IC911	8-759-327-04	IC CXD2913Q	, ,		Q050		TRANSISTOR	2SC4081	T106R	
	1004.4	0 750 405 40	10 71110001001			Q051		TRANSISTOR	XP6501-1		
	IC914 IC915		IC TLV2231CDI			Q052		TRANSISTOR	2SC4081		
	IC916		IC TC7S08FU (Q053 Q200		TRANSISTOR TRANSISTOR	XP6501-7 2SC4081		
	,,,,,	0 100 000 02	10 10100010 (120011)		W200	0-129-900-99	MANOISTON	2304001	IIUUN	
			< COIL >			Q201		TRANSISTOR	2SA1576	A-T106-R	
	1044					Q501		TRANSISTOR	2SC4081		
	L011 L012	1-414-398-11 1-414-398-11		10uH		Q502		TRANSISTOR	2SC4081		
	L012	1-414-398-11		10uH 10uH		Q504 Q505		TRANSISTOR TRANSISTOR	UN5113-		
	L014	1-414-398-11		10uH		QUUU	0-125-421-10	INANOIOIUN	XP4401-1	ΛE	
	L015	1-414-398-11	INDUCTOR	10uH		Q506	8-729-101-07	TRANSISTOR	2SB798-T	1-DLDK	
						Q801	8-729-905-35		2SC4081		
	L016	1-414-398-11		10uH		Q832		TRANSISTOR	UN5111-1		
	L017 L018	1-414-398-11 1-414-398-11		10uH 10uH	,	Q902 Q903	8-729-905-35 8-729-402-42		2SC40817		
	L102	1-414-398-11		10uH		สลดอ	0-729-402-42	INANSISTUR	UN5213-1	Ι λ	
	L200	1-414-398-11		10uH		Q910	8-729-015-76	TRANSISTOR	UN5211-1	ΤX	
	1.000					Q911	8-729-015-76	TRANSISTOR	UN5211-7	X	
	L202 L203	1-410-390-11	INDUCTOR CHIP	56uH 10uH				PECIOTOR			
	L204	1-414-398-11		10uH				< RESISTOR >			
	L205		COIL, VARIABLE			R002	1-216-864-11	METAL CHIP	0	5%	1/16W
	L206	1-410-655-31	INDUCTOR CHIP	120uH		R003	1-414-760-21		0uH		.,
	1.404	4 444 000 44	MDHOTOD	40.11		R004	1-414-760-21		0uH		
	L401 L402	1-414-398-11 1-414-398-11		10uH 10uH		R005	1-414-760-21		OuH		
	L421		INDUCTOR CHIP			R009	1-414-760-21	rennile	0uH		
	L422		INDUCTOR CHIP			R010	1-216-864-11	METAL CHIP	0	5%	1/16W
	L423	1-414-398-11	INDUCTOR	10uH		R011	1-216-864-11	METAL CHIP	0		1/16W
	1.404	4 440 005 44	INDUSTRO SUID	00.41		R012	1-216-864-11	METAL CHIP	0		1/16W
	L424 L501	1-410-385-11 1-414-398-11		22uH 10uH		R013	1-216-864-11	METAL CHIP	0		1/16W
	L701		INDUCTOR CHIP			R014	1-216-864-11	METAL CHIP	0	5%	1/16W
	L702	1-414-398-11	INDUCTOR	10uH	ļ	R015	1-216-864-11	METAL CHIP	0	5%	1/16W
	L703		INDUCTOR CHIP	100uH		R016		METAL CHIP	0		1/16W
	1.004					R017		FERRITE	0uH		
	L801	1-410-369-11	INDUCTOR CHIP INDUCTOR CHIP			R018	1-414-760-21		0uH		
	L802 L901	1-410-301-11		10uH 10uH		R020	1-414-760-21	FERRIIE	0uH		
	L904	1-414-398-11		10uH		R021	1-414-760-21	FERRITE	0uH		
	L905		COIL, VARIABLE	•		R023	1-216-864-11		0	5%	1/16W
	1.00=	4 44 4 000 44	INDUCTOR	40.11		R030	1-414-760-21		OuH		
	L907	1-414-398-11	INDUCTOR	10uH		R033	1-216-864-11		0		1/16W
		4	< TRANSISTOR >		.	R034	1-216-864-11	WETAL CHIP	0	5%	1/16W
		<i>y</i> •				R035	1-216-864-11	METAL CHIP	0	5%	1/16W
	Q026	8-729-905-35		2SC4081T106R		R036		METAL CHIP	0		1/16W
	Q027	8-729-905-35		2SC4081T106R		R037	1-216-864-11	METAL CHIP	0		1/16W
	Q028 Q029	8-729-905-35 8-729-202-38		2SC4081T106R			1-414-760-21		0uH	F04	
	WUZ9	0-129-202-38	HUTGIGINAL	2SC3326N-TE85L-B		R039	1-216-864-11	WEIAL CHIP	0	5%	I/16W

R041 1-414-760-21 FERRITE 0 R042 1-414-760-21 FERRITE 0 R043 1-216-864-11 METAL CHIP 0 R044 1-414-760-21 FERRITE 0	uH 5%	Remark 1/16W	Ref. No. R147 R148 R149 R150	Part No. 1-216-821-11 1-216-830-11 1-216-824-11	Description METAL CHIP METAL CHIP METAL CHIP	1K 5.6K	5% 5%	<u>Remark</u> 1/16W 1/16W
R041 1-414-760-21 FERRITE 0 R042 1-414-760-21 FERRITE 0 R043 1-216-864-11 METAL CHIP 0 R044 1-414-760-21 FERRITE 0	uH uH 5% uH	1/16W	R148 R149 R150	1-216-830-11 1-216-824-11	METAL CHIP	5.6K		
R041 1-414-760-21 FERRITE 0 R042 1-414-760-21 FERRITE 0 R043 1-216-864-11 METAL CHIP 0 R044 1-414-760-21 FERRITE 0	uH uH 5% uH	1/16W	R148 R149 R150	1-216-830-11 1-216-824-11	METAL CHIP	5.6K		
R042 1-414-760-21 FERRITE 0 R043 1-216-864-11 METAL CHIP 0 R044 1-414-760-21 FERRITE 0	uH 5% uH 5%	1/16W	R148 R149 R150	1-216-830-11 1-216-824-11	METAL CHIP	5.6K		
R043 1-216-864-11 METAL CHIP 0 R044 1-414-760-21 FERRITE 0	5% uH 5%	1/16W	R150					
R044 1-414-760-21 FERRITE 0	uH 5%	1/16W	R150		IVIL IAL OUIL	1.8K	5%	1/16W
	5%			1-216-824-11	METAL CHIP	1.8K	5%	1/16W
Bole 1 012			R151	1-216-824-11		1.8K	5%	1/16W
DOAR A GLO SOLL AS STOLL SOLL SOLL SOLL SOLL SOLL SOLL SO								.,,,,,,
R045 1-216-864-11 METAL CHIP 0		1/16W	R152	1-216-835-11	METAL CHIP	15K	5%	1/16W
R046 1-216-864-11 METAL CHIP 0	5%	1/16W	R154	1-216-809-11	METAL CHIP	100	5%	1/16W
R047 1-216-864-11 METAL CHIP 0	5%	1/16W	R155	1-216-809-11	METAL CHIP	100	5%	1/16W
	ıH	.,,,,,,	R156	1-216-809-11	METAL CHIP	100	5%	1/16W
	ıH		R157	1-216-864-11	METAL CHIP	0	5%	1/16W
•			11107	1 210 004 11	WILIAL OTH		J /0	171044
R050 1-414-760-21 FERRITE 0	л Н		R159	1-216-805-11	METAL CHIP	47	5%	1/16W
	ıH		R160	1-216-821-11	METAL CHIP	1K	5%	1/16W
	ıH		R161	1-216-821-11	METAL CHIP	1K	5%	1/16W
	iH		R162	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
	ıH		R163	1-216-864-11	METAL CHIP	0	5%	1/16W
THE TOTAL TENENTS	411		11100	1-210-004-11	WIL TAL OTHE	U	370	1/1000
R056 1-414-760-21 FERRITE 01	ıH		R164	1-216-816-11	METAL CHIP	390	5%	1/16W
	iH		R165	1-216-864-11	METAL CHIP	0	5% 5%	1/16W
	2K 5%	1/16W	R166	1-216-829-11	METAL CHIP			
R060 1-216-818-11 METAL CHIP 56		1/16W	R167	1-216-823-11		4.7K	5%	1/16W
R061 1-216-817-11 METAL CHIP 47		1/16W	R168		METAL CHIP	1.5K	5%	1/16W
11001 1 210-017-11 WEIAE GIRF 47	0 3/6	1/1000	U 100	1-216-835-11	METAL CHIP	15K	5%	1/16W
R062 1-216-821-11 METAL CHIP 11	5%	1/16W	R169	1-216-832-11	METAL CHIP	0.01/	F0/	4 /4 014/
	2K 5%	1/16W	R170	1-216-864-11		8.2K	5%	1/16W
	2K 5%		R173		METAL CHIP	0	5%	1/16W
	2K 5%	1/16W 1/16W	1	1-216-821-11	METAL CHIP	. 1K	5%	1/16W
R067 1-216-818-11 METAL CHIP 56		1/16W	R174 R175	1-216-821-11	METAL CHIP	1K	5%	1/16W
11007 1-210-010-11 WEIAL GIRF 30	50 576	1/1000	N1/5	1-216-813-11	METAL CHIP	220	5%	1/16W
R068 1-216-817-11 METAL CHIP 47	0 5%	1/16W	D176	1 010 001 11	METAL CLUD	41/	E0/	4 14 0181
	2K 5%	1/16W	R176	1-216-821-11	METAL CHIP	1K	5%	1/16W
			R177	1-216-821-11	METAL CHIP	1K	5%	1/16W
		1/16W	R178	1-216-817-11	METAL CHIP	470	5%	1/16W
		1/16W	R182	1-216-821-11	METAL CHIP	1K	5%	1/16W
R113 1-216-829-11 METAL CHIP 4.	7K 5%	1/16W	R183	1-216-821-11	METAL CHIP	1K	5%	1/16W
DATE 1 040 007 44 METALOUD 00	u ėn	4 /4 0) 4 /	D404	101001711	AAETAL OLUB		=	
R115 1-216-837-11 METAL CHIP 22		1/16W	R184	1-216-817-11	METAL CHIP	470	5%	1/16W
R116 1-216-837-11 METAL CHIP 22		1/16W	R185		METAL CHIP	1K	5%	1/16W
R117 1-216-837-11 METAL CHIP 22		1/16W	R186	1-216-821-11	METAL CHIP	1K	5%	1/16W
R118 1-216-821-11 METAL CHIP 1k		1/16W	R187	1-216-817-11	METAL CHIP	470	5%	1/16W
R119 1-216-821-11 METAL CHIP 1k	5%	1/16W	R192	1-216-821-11	METAL CHIP	1K	5%	1/16W
D100 1 010 001 11 META: 01110 11		44011	2400					
R120 1-216-821-11 METAL CHIP 1k		1/16W	R199	1-216-821-11		1K	5%	1/16W
R121 1-216-864-11 METAL CHIP 0	5%	1/16W	R201	1-216-821-11	METAL CHIP	1K	5%	1/16W
R122 1-216-864-11 METAL CHIP 0	5%	1/16W	R203	1-216-864-11	METAL CHIP	0	5%	1/16W
R123 1-216-864-11 METAL CHIP 0	5%	1/16W	R204		METAL CHIP	3.3K	5%	1/16W
R124 1-216-833-91 RES, CHIP 10	K 5%	1/16W	R205	1-216-864-11	METAL CHIP	0	5%	1/16W
D405								
R125 1-216-833-91 RES, CHIP 10		1/16W	R206		METAL CHIP	0	5%	1/16W
R126 1-216-825-11 METAL CHIP 2.2		1/16W	R207		METAL CHIP	0	5%	1/16W
R127 1-216-832-11 METAL CHIP 8.2		1/16W	R208		METAL CHIP	3.3K	5%	1/16W
R128 1-216-809-11 METAL CHIP 10		1/16W	R209		METAL CHIP	0	5%	1/16W
R129 1-216-809-11 METAL CHIP 10	0 5%	1/16W	R210	1-216-864-11	METAL CHIP	0	5%	1/16W
B.00								
R130 1-216-809-11 METAL CHIP 10		1/16W	R211	1-216-833-91		10K	5%	1/16W
R131 1-216-827-11 METAL CHIP 3.3		1/16W	R212	1-216-864-11	METAL CHIP	0	5%	1/16W
R133 1-216-829-11 METAL CHIP 4.7		1/16W	R213	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R134 1-216-829-11 METAL CHIP 4.7		1/16W	R214	1-216-833-91	RES, CHIP	10K	5%	1/16W
R135 1-216-829-11 METAL CHIP 4.7	K 5%	1/16W	R215	1-216-840-11	METAL CHIP	39K	5%	1/16W
R136 1-216-830-11 METAL CHIP 5.6		1/16W	R216	1-216-864-11		0	5%	1/16W
R137 1-216-833-91 RES, CHIP 10		1/16W	R217	1-216-828-11	METAL CHIP	3.9K	5%	1/16W
R138 1-216-833-91 RES, CHIP 10		1/16W	R218	1-216-864-11		0	5%	1/16W
R139 1-216-821-11 METAL CHIP 1K		1/16W	R219	1-216-864-11	METAL CHIP	0	5%	1/16W
R140 1-216-829-11 METAL CHIP 4.7	K 5%	1/16W	R246	1-216-864-11		0 .	5%	1/16W
R141 1-216-829-11 METAL CHIP 4.7	K 5%	1/16W	R247	1-216-821-11	METAL CHIP	1K	5%	1/16W
R142 1-216-821-11 METAL CHIP 1K	5%	1/16W	R248	1-216-817-11		470	5%	1/16W
R143 1-216-835-11 METAL CHIP 15		1/16W	R249	1-216-817-11		470	5%	1/16W
R145 1-216-821-11 METAL CHIP 1K		1/16W	R250	1-216-821-11	METAL CHIP	1K	5%	1/16W
R146 1-216-821-11 METAL CHIP 1K	5%	1/16W	R256	1-216-833-91		10K	5%	1/16W

			•								
Ref. No.	Part No.	<u>Description</u>			<u>Remark</u>	Ref. No.	Part No.	Description			Remark
						R428	1-216-829-11	METAL CHID	4.7K	5%	1/16W
		METAL OLUB	0.01/	F0/	4.44.0344						1/16W
R259	1-216-832-11		8.2K	5%	1/16W	R429	1-216-845-11	WETAL CHIP	100K	5%	171044
R260	1-216-829-11		4.7K	5%	1/16W					=0.	4464
R261	1-216-814-11		270	5%	1/16W	R430	1-216-805-11		47	5%	1/16W
R262	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	R431	1-216-817-11	METAL CHIP	470	5%	1/16W
R264	1-216-833-91	RES, CHIP	10K	5%	1/16W	R432	1-216-845-11	METAL CHIP	100K	5%	1/16W
		•				R433	1-216-845-11	METAL CHIP	100K	5%	1/16W
R266	1-216-833-91	RES CHIP	10K	5%	1/16W	R434	1-216-805-11		47	5%	1/16W
	1-216-829-11		4.7K	5%	1/16W	11101	1 210 000 11		••	• 70	.,,,,,,
R268						DAGE	1-216-845-11	METAL CHIP	100K	5%	1/16W
R269	1-216-814-11		270	5%	1/16W	R435					
R270	1-216-829-11		4.7K	5%	1/16W	R437	1-216-864-11		0	5%	1/16W
R271	1-216-864-11	METAL CHIP	0	5%	1/16W	R438	1-216-864-11		0	5%	1/16W
						R439	1-216-864 -11	METAL CHIP	0 ·	5%	1/16W
R272	1-216-855-11	METAL CHIP	680K	5%	1/16W	R440	1-216-833-91	RES, CHIP	10K	5%	1/16W
R273	1-216-839-11		33K	5%	1/16W						
R274	1-216-864-11		0	5%	1/16W	R441	1-216-833-91	RES. CHIP	10K	5%	1/16W
				5%	1/16W	R442	1-216-815-11		330	5%	1/16W
R276	1-216-833-91		10K								1/16W
R277	1-216-839-11	METAL CHIP	33K	5%	1/16W	R443	1-216-805-11		47	5%	
						R444	1-216-829-11		4.7K	5%	1/16W
R278	1-216-864-11	METAL CHIP	0	5%	1/16W	R445	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R279	1-216-839-11	METAL CHIP	33K	5%	1/16W						
R280	1-216-833-91		10K	5%	1/16W	R446	1-216-845-11	METAL CHIP	100K	5%	1/16W
R281	1-216-821-11		1K	5%	1/16W	R447	1-216-845-11	METAL CHIP	100K	5%	1/16W
	1-216-839-11		33K	5%	1/16W	R448	1-216-845-11		100K	5%	1/16W
R282	1-210-039-11	WILLIAL CITIF	JJK	J /0	1/1044		1-216-821-11		1K	5%	1/16W
			_	=0/	4 (4 0) 14	R449					
R285	1-216-864-11		0	5%	1/16W	R450	1-216-857-11	METAL CHIP	1M	5%	1/16W
R286	1-216-833-91		10K	5%	1/16W						
R288	1-216-833-91	RES, CHIP	10K	5%	1/16W	R451	1-216-845-11	METAL CHIP	100K	5%	1/16W
R292	1-216-833-91		10K	5%	1/16W	R452	1-216-845-11	METAL CHIP	100K	5%	1/16W
R295	1-216-864-11		0	5%	1/16W	R453	1-216-845-11		100K	5%	1/16W
11230	1 2:0 004 11	ME ME OIII	Ū	0 70	17 1011	R454	1-216-845-11		100K	5%	1/16W
D067	4 040 004 44	METAL OLUD	0	E0/	1/1/01/1					5%	1/16W
R297	1-216-864-11		0	5%	1/16W	R455	1-216-845-11	METAL CHIP	100K	J /0	171000
R298	1-216-864-11		0	5%	1/16W						
R299	1-216-825-11	METAL CHIP	2.2K	5%	1/16W	R456	1-216-845-11		100K	5%	1/16W
R300	1-216-825-11	METAL CHIP	2.2K	5%	1/16W	R457	1-216-845-11	METAL CHIP	100K	5%	1/16W
R301	1-216-825-11		2.2K	5%	1/16W	R458	1-216-845-11	METAL CHIP	100K	5%	1/16W
1.001	. 2.0 020 //					R459	1-216-845-11		100K	5%	1/16W
R302	1-216-825-11	METAL CHID	2.2K	5%	1/16W	R460	1-216-845-11	and the second second	100K	5%	1/16W
						11400	1-210 040 11	WILLIAL OTH	10010	0 /0	171000
R303	1-216-821-11		1K	5%	1/16W	D 404	4 040 004 44	METAL OLUD	•	E0/	1/4014
R304	1-216-815-11		330	5%	1/16W	R461	1-216-864-11		0	5%	1/16W
R313	1-216-827-11	METAL CHIP	3.3K	5%	1/16W	R462	1-216-864-11		0	5%	1/16W
R314	1-216-815-11	METAL CHIP	330	5%	1/16W	R463	1-216-864-11	METAL CHIP	0	5%	1/16W
						R464	1-216-864-11	METAL CHIP	0	5%	1/16W
R315	1-216-815-11	METAL CHIP	330	5%	1/16W	R465	1-216-864-11	METAL CHIP	0	5%	1/16W
R318	1-216-295-91		0								
R319	1-218-864-11		5.1K	0.5%	1/16W	R466	1-216-864-11	METAL CHIP	0	5%	1/16W
פוטח	1-210-004-11	WE TAL OTTE	J.11K			1	1-216-864-11		0	5%	1/16W
				•	SR-20MD)	R467					
R319	1-218-865-11	METAL CHIP	5.6K	0.5%	1/16W	R468	1-216-864-11		0	5%	1/16W
				(DSI	R-20MDP)	R469	1-216-821-11		1K	5%	1/16W
R320	1-218-831-11	METAL CHIP	220	0.5%	1/16W	R470	1-216-821-11	METAL CHIP	1K	5%	1/16W
R321	1-218-851-11	METAL CHIP	1.5K	0.5%	1/16W	R471	1-216-821-11	METAL CHIP	1K	5%	1/16W
R322	1-218-831-11		220	0.5%	1/16W	R472	1-216-821-11		1K	5%	1/16W
R339	1-216-864-11		0	5%	1/16W	R502	1-216-809-11		100	5%	1/16W
										5%	1/16W
R340	1-216-841-11		47K	5%	1/16W	R503	1-216-809-11		100		
R341	1-216-841-11	METAL CHIP	47K	5%	1/16W	R504	1-216-864-11	METAL CHIP	0	5%	1/16W
R342	1-216-864-11	METAL CHIP	0	5%	1/16W	R505	1-216-809-11	METAL CHIP	100	5%	1/16W
R343	1-216-840-11	METAL CHIP	39K	5%	1/16W	R506	1-216-864-11	METAL CHIP	0	5%	1/16W
R344	1-216-821-11		1K	5%	1/16W	R507	1-216-809-11	METAL CHIP	100	5%	1/16W
R345	1-216-821-11		1K	5%	1/16W	R508	1-216-864-11		0	5%	1/16W
						1			10K	5%	1/16W
R346	1-216-833-91	neo, Unip	10K	5%	1/16W	R509	1-216-833-91	TILO, UTIL	IUN	J 70	1/1044
			46.4	0 =	4400		4 040 0011	MACTAL OLUM	0	E0/	4/4/0144
R347	1-218-871-11		10K	0.5%	1/16W	R510	1-216-864-11		0	5%	1/16W
R401	1-216-821-11	METAL CHIP	1K	5%	1/16W	R511	1-216-833-91		10K	5%	1/16W
R422	1-216-805-11		47	5%	1/16W	R512	1-216-809-11	METAL CHIP	100	5%	1/16W
R423	1-216-805-11		47	5%	1/16W	R513	1-216-809-11		100	5%	1/16W
R424	1-216-805-11		47	5%	1/16W	R514	1-216-809-11		100	5%	1/16W
11724	. 1 210 000-11	MENTE OTH	••	5 70	.,	1.014				5,5	.,
R425	1-216-833-91	BEC CHIB	10K	5%	1/16W	R515	1-216-809-11	METAL CHIP	100	5%	1/16W
						1	1-216-809-11		100		1/16W
R426	1-216-821-11		1K	5%	1/16W	R517			The second second second	5%	
R427	1-216-833-91	KES, CHIP	10K	5%	1/16W	I R518	1-216-809-11	WETAL UHIP	100	5%	1/16W

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
R524			1717								
R524	1-216-841-11 1-216-841-11		47K	5%	1/16W	R701	1-216-833-91	RES, CHIP	10K	5%	1/16W
NOZU	1-210-041-11	METAL CHIP	47K	5%	1/16W	R702	1-216-821-11	METAL CHIP	1K	5%	1/16W
R529	1-216-827-11	METAL CHID	3.3K	5%	1/16W	D702	1 010 057 11	METAL OUID	45.0	501	4 (4 6) 44
R530	1-216-827-11		3.3K	5%		R703	1-216-857-11	METAL CHIP	1M	5%	1/16W
R531	1-216-809-11		100	5% 5%	1/16W	R704	1-216-833-91	RES, CHIP	10K	5%	1/16W
R532	1-216-827-11				1/16W	R705	1-216-833-91	RES, CHIP	10K	5%	1/16W
R533			3.3K	5%	1/16W	R706	1-216-821-11		1K	5%	1/16W
กของ	1-216-809-11	METAL CHIP	100	5%	1/16W	R707	1-216-845-11	METAL CHIP	100K	5%	1/16W
R534	1-216-823-11	METAL CHIP	4 51/	E0/	4 (4 0)4/	D700	4 040 004 44		_		
R535			1.5K	5%	1/16W	R708	1-216-864-11	METAL CHIP	0	5%	1/16W
	1-216-830-11		5.6K	5%	1/16W	R709	1-216-845-11	METAL CHIP	100K	5%	1/16W
R536	1-216-829-11		4.7K	5%	1/16W	R710	1-216-845-11	METAL CHIP	100K	5%	1/16W
R537	1-216-841-11		47K	5%	1/16W	R711	1-216-833-91	RES, CHIP	10K	5%	1/16W
R538	1-216-841-11	METAL CHIP	47K	5%	1/16W	R712	1-216-833-91	RES, CHIP	10K	5%	1/16W
DEON	1 010 041 11	METAL CLUD	471/	F0/	4 (4 0)44	2740					
R539	1-216-841-11		47K	5%	1/16W	R713	1-216-845-11	METAL CHIP	100K	5%	1/16W
R540	1-216-841-11		47K	5%	1/16W	R714	1-216-833-91	RES, CHIP	10K	5%	1/16W
R541	1-216-841-11		47K	5%	1/16W	R715	1-216-845-11	METAL CHIP	100K	5%	1/16W
R542	1-216-841-11	METAL CHIP	47K	5%	1/16W	R717	1-218-873-11	METAL CHIP	12K	0.5%	1/16W
R543	1-216-821-11	WETAL CHIP	1K	5%	1/16W	R718	1-218-873-11	METAL CHIP	12K	0.5%	1/16W
DE 4.4	1 010 001 11	METAL OLUB			444						
R544	1-216-821-11	METAL CHIP	1K	5%	1/16W	R719	1-216-864-11	METAL CHIP	0	5%	1/16W
R545	1-216-821-11	METAL CHIP	1K	5%	1/16W	R720	1-218-871-11	METAL CHIP	10K	0.5%	1/16W
R546	1-216-791-11	METAL CHIP	3.3	5%	1/16W	R721	1-218-871-11	METAL CHIP	10K	0.5%	1/16W
R547	1-216-825-11	METAL CHIP	2.2K	5%	1/16W	R722	1-216-806-11	RES, CHIP	56	5%	1/16W
R548	1-216-821-11	METAL CHIP	1K	5%	1/16W	R723	1-216-806-11	RES, CHIP	56	5%	1/16W
DC 40	4 040 004 44	METAL OLUB	414								
R549	1-216-821-11	METAL CHIP	1K	5%	1/16W	R724	1-216-806-11	RES, CHIP	56	5%	1/16W
R550	1-216-841-11	METAL CHIP	47K	5%	1/16W	R725	1-216-806-11	RES, CHIP	56	5%	1/16W
R551	1-216-821-11	METAL CHIP	1K	5%	1/16W	R726		METAL CHIP	100K	5%	1/16W
R553	1-216-797-11	METAL CHIP	10	5%	1/16W	R727	1-216-864-11	METAL CHIP	0	5%	1/16W
R554	1-216-797-11	METAL CHIP	10	5%	1/16W	R801	1-216-833-91	RES, CHIP	10K	5%	1/16W
Dece	4 040 000 04	BEQ 0111B	4.514								
R555	1-216-833-91	RES, CHIP	10K	5%	1/16W	R802	1-216-845-11	METAL CHIP	100K	5%	1/16W
R556	1-216-833-91	RES, CHIP	10K	5%	1/16W	R803	1-216-809-11	METAL CHIP	100	5%	1/16W
R557		RES, CHIP	10K	5%	1/16W	R813		METAL CHIP	22K	5%	1/16W
R558	1-216-821-11	METAL CHIP	1K	5%	1/16W	R814	1-216-142-00		4.7	5%	1/8W
R559	1-216-821-11	METAL CHIP	1K	5%	1/16W	R818	1-216-845-11	METAL CHIP	100K	5%	1/16W
DEGG	4 040 004 44	METAL OLUB	414								
R560		METAL CHIP	1K	5%	1/16W	R819		METAL CHIP	22K	5%	1/16W
R561	1-216-821-11	METAL CHIP	1K	5%	1/16W	R821		METAL CHIP	4.7K	5%	1/16W
R562	1-216-821-11	METAL CHIP	1K	5%	1/16W	R822	1-216-845-11		100K	5%	1/16W
R563	1-216-821-11		1K.	5%	1/16W	R823	1-216-845-11		100K	5%	1/16W
R564	1-219-570-11	RES, CHIP	10M	5%	1/16W	R824	1-216-845-11	METAL CHIP	100K	5%	1/16W
DECE	4 040 004 44	METAL OLUB									
R565	1-216-864-11		0	5%	1/16W	R826	1-216-864-11		0	5%	1/16W
R566		METAL CHIP	1K	5%	1/16W	R829		METAL CHIP	0	5%	1/16W
R567	1-216-821-11		1K	5%	1/16W	R830	1-216-833-91		10K	5%	1/16W
R568		METAL CHIP	1K	5%	1/16W	R831	1-216-829-11		4.7K	5%	1/16W
R569	1-216-821-11	METAL CHIP	1K	5%	1/16W	R832	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
DE70	4 040 044 44										
R570		METAL CHIP	47K	5%	1/16W	R833	1-216-833-91		10K	5%	1/16W
R571		METAL CHIP	47K	5%	1/16W	R834	1-216-833-91		10K	5%	1/16W
R572		METAL CHIP	100K	5%	1/16W	R835	1-216-829-11		4.7K	5%	1/16W
R573	1-216-821-11		1K	5%	1/16W	R836	1-216-829-11		4.7K	5%	1/16W
R574	1-216-797-11	METAL CHIP	10	5%	1/16W	R837	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R575	1-216-821-11		1K	5%	1/16W	R838	1-216-809-11	METAL CHIP	100	5%	1/16W
R576		METAL CHIP	10	5%	1/16W	R839		METAL CHIP	5.6K	5%	1/16W
R577	1-216-797-11		10	5%	1/16W	R840	1-216-830-11		5.6K	5%	1/16W
R578		METAL CHIP	1K	5%	1/16W	R841	1-216-809-11		100	5%	1/16W
R579	1-216-841-11	METAL CHIP	47K	5%	1/16W	R842	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R580	1-216-833-91		10K	5%	1/16W	R843	1-216-809-11	METAL CHIP	100	5%	1/16W
R581		METAL CHIP	47K	5%	1/16W	R844	1-216-833-91		10K	5%	1/16W
R582	1-216-841-11		47K	5%	1/16W	R845	1-216-809-11		100	5%	1/16W
R583	1-216-841-11		47K	5%	1/16W	R847	1-216-833-91	RES, CHIP	10K	5%	1/16W
R584	1-216-841-11	METAL CHIP	47K	5%	1/16W	R850		METAL CHIP	9.1K	0.5%	1/16W
R585		METAL CHIP	47K	5%	1/16W	R852	1-216-809-11	METAL CHIP	100	5%	1/16W
R586	1-216-837-11		22K	5%	1/16W	R853	1-216-833-91 I	RES, CHIP	10K	5%	1/16W
R587	1-216-837-11	METAL CHIP	22K	5%	1/16W	R854	1-216-833-91	RES, CHIP	10K	5%	1/16W

										L.	
Ref. No.	Part No.	Description			<u>Remark</u>	Ref. No.	Part No.	Description			<u>Remark</u>
R855	1-218-870-11	METAL CHIP	9.1K	0.5%	1/16W	R952	1-216-821-11	METAL CHIP	1K	5%	1/16W
R856	1-216-829-11		4.7K	5%	1/16W	R953	1-216-821-11		1K	5%	
R857	1-216-809-11	METAL CHIP	100	5%	1/16W	R954	1-216-821-11	METAL CHIP	1K	5%	1/16W
R858	1-218-707-11	RES, CHIP	4.3K	5%	1/16W	R955	1-216-821-11		1K	5%	1/16W
R859	1-216-809-11		100	5%	1/16W	R956	1-216-821-11		1K	5%	1/16W
R860	1-218-707-11		4.3K	5%	1/16W	R957	1-216-842-11		56K	5%	1/16W
R861	1-216-829-11		4.7K	5%	1/16W	R958	1-216-845-11		100K	5%	1/16W
R863	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	R959	1-216-833-91	RES CHIP	10K	5%	1/16W
R866	1-216-829-11		4.7K	5%	1/16W	R960	1-216-841-11		47K	5%	1/16W
R867	1-216-809-11		100	5%	1/16W	R962	1-216-821-11		1K	5%	1/16W
R868	1-216-829-11		·4.7K	5%	1/16W	R964	1-216-838-11		27K		
R869	1-216-829-11		4.7K	5%	1/16W	R965	1-216-833-91		10K	5% 5%	1/16W 1/16W
R870	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	R966	1-216-833-91	DEC CHID	10K	5%	1/16W
R871	1-216-829-11		4.7K	5%	1/16W	1	1-216-833-91				
						R967			10K	5%	1/16W
R872	1-216-829-11		4.7K	5%	1/16W	R968	1-216-841-11		47K	5%	1/16W
R873	1-216-829-11		4.7K	5%	1/16W	R969	1-216-841-11		47K	5%	1/16W
R875	1-218-839-11	METAL CHIP	470	0.5%	1/16W	R970	1-216-833-91	RES, CHIP	10K	5%	1/16W
R876	1-218-839-11		470	0.5%	1/16W	R971	1-216-813-11		220	5%	1/16W
R877	1-218-839-11		470	0.5%	1/16W	R972	1-216-841-11		47K	5%	1/16W
R878	1-218-839-11		470	0.5%	1/16W	R973	1-216-864-11		0	5%	1/16W
R879	1-216-864-11	METAL CHIP	0	5%	1/16W	R974	1-216-838-11	METAL CHIP	27K	5%	1/16W
R880	1-216-815-11	METAL CHIP	330	5%	1/16W	R975	1-216-841-11	METAL CHIP	47K	5%	1/16W
R881	1-216-815-11	METAL CHIP	330	5%	1/16W	R976	1-216-845-11	METAL CHIP	100K	5%	1/16W
R885	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	R978	1-216-813-11	METAL CHIP	220	5%	1/16W
R886	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	R980	1-216-841-11		47K	5%	1/16W
R887	1-216-833-91	RES, CHIP	10K	5%	1/16W	R981	1-216-821-11		1K	5%	1/16W
R888	1-216-827-11		3.3K	5%	1/16W	R982	1-216-833-91		10K	5%	1/16W
R889	1-216-830-11	METAL CHIP	5.6K	5%	1/16W	R983	1-216-821-11	METAL CHIP	1K	5%	1/16W
R890	1-216-849-11		220K	5%	1/16W	R984	1-216-833-91		10K	5%	1/16W
R891	1-208-813-11		20K	0.5%	1/10W	R986	1-216-864-11		0	5%	1/16W
R893	1-216-833-91		10K	5%	1/16W	R987	1-216-864-11				
R894	1-216-809-11		100	5%	1/16W	R988	1-216-864-11		0 0	5% 5%	1/16W 1/16W
R895	1-216-833-91		10K	5%	1/16W	R989	1-216-864-11		0	5%	1/16W
R896	1-216-809-11		100	5%	1/16W	R990	1-216-813-11		220	5%	1/16W
R897	1-208-813-11		20K	0.5%	1/10W	R991	1-216-813-11		220	5%	1/16W
R899	1-216-864-11		0	5%	1/16W	R992	1-216-864-11		0	5%	1/16W
R903	1-216-864-11	METAL CHIP	0	5%	1/16W	RR001	1-216-864-11	METAL CHIP	0	5% (r	1/16W
R904	1-216-838-11		27K	5%	1/16W					(L	OSR-20MD)
R905	1-216-821-11	METAL CHIP	1K	5%	1/16W	RR002	1-216-864-11	METAL CHIP	0	5%	1/16W
R906	1-218-883-11	METAL CHIP	33K	0.5%	1/16W					(DS	SR-20MDP)
R907	1-216-821-11		1K	5%	1/16W			\/\ \B\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \		,	
R908	1-216-864-11	WIETAL CHIP	0	5%	1/16W			< VARIABLE RES	SISTUR >		
R909		METAL CHIP	0	5%	1/16W	RV001	1-238-855-11	RES, ADJ, CERM	ET 4.7K		
R913	1-216-821-11	METAL CHIP	1K	5%	1/16W				(A/	D CONV.	REF REG1)
R918	1-216-821-11		1K	5%	1/16W	RV002	1-238-855-11	RES, ADJ, CERM	ET 4.7K		,
R919 R920	1-216-864-11 1-218-871-11		0 10K	5% 0.5%	1/16W 1/16W	RV010	1_228_85/_11	RES, ADJ, CERM		D CONV.	REF REG2)
11320	1-210-071-11	WEIZE OITH	TOK	0.570	171000	NVOIO			(C	R CLAME	REF REG)
R921	1-218-875-11		15K	0.5%	1/16W	RV011	1-238-853-11	RES, ADJ, CERM	ET 1K (Y 0	CLAMP RI	EF REG)
R923	1-216-178-00	RES, CHIP	150	5%	1/8W	RV012	1-238-854-11	RES, ADJ, CERM	ET 2.2K		
R924	1-216-831-11		6.8K	5%	1/16W					B CLAMP	REF REG)
R926	1-216-857-11	METAL CHIP	1M	5%	1/16W				(-		
R936	1-216-845-11		100K	5%	1/16W	RV201	1-238-855-11	RES, ADJ, CERM			
R937	1-216-845-11	METAL CHID	100K	5%	1/16W				(AF	C PICTUR	RE FRAME)
								MDDATOR			
R938	1-216-847-11		150K	5%	1/16W			< VIBRATOR >			
R939	1-216-833-91		10K	5%	1/16W		J 700 07				
R941	1-216-864-11		0	5%	1/16W	X421		VIBRATOR, CRYS			
R943	1-216-864-11	METAL CHIP	0	5%	1/16W	X422		VIBRATOR, CRYS			
						X501		VIBRATOR, CERA			
R944	1-216-833-91		10K	5%	1/16W	X502		VIBRATOR, CRYS			
R950	1-216-821-11		1K	5%	1/16W	X701	1-767-399-11	VIBRATOR, CRYS	TAL (24.5	76MHz)	
R951	1-216-821-11	METAL CHIP	1K	5%	1/16W				•	•	

JC-19 MD-63 MD-64 MD-65 POWER BLOCK (U-1)												
Ref. No. X702 X801	Part No. 1-760-497-21	<u>Description</u> VIBRATOR, LITHIUM NIO VIBRATOR, CRYSTAL (49	BATE (6N	Remark MHz)	Ref. No.	<u>Part No.</u>	Description < CONNECTOR	>		<u>Remark</u>		
7.00.	1.07.770.21	VIDITATION, OTTOTAL (43	. 1 32 1011 12	,	CN002	1-770-692-11	CONNECTOR, F	FC/FPC 9F	ı			
	•	MD-63 BOARD (Ref No. 6	,000 Seri	ies)			< IC >		,			
C101		< CAPACITOR > ELECT CHIP 100uF	20%		IC003 IC004 IC005 IC006	8-719-820-44 8-759-510-71	IC PHOTO COL IC PHOTO COL IC BA10358F-I IC ELEMENT, I	JPLER TLF E2	P907-0 (S	ONY2)		
C102	1-163-031-11	CERAMIC CHIP 0.01uF		50V			< JUMPER RES	ISTOR >				
0.14.03	4 770 040 44	< CONNECTOR >	_		JR001	1-216-296-91		0				
CN101	1-//0-646-11	CONNECTOR, FFC/FPC 16	Р	•	JR002	1-216-296-91	SHORT	0				
		< DIODE >				*	< TRANSISTOR	>				
D101	8-719-989-52	DIODE GL4600S			Q001	8-729-012-46	PHOTO TRANSI	STOR PT4	600FS			
		< IC >					< RESISTOR >					
IC101 IC102 IC103 IC105	8-719-820-44 8-759-510-71	IC PHOTO COUPLER TLF IC PHOTO COUPLER TLF IC BA10358F-E2 IC ELEMENT, HALL THS1	907-0 (S	ONY2)	R002 R003 R004 R005 R007	1-216-069-00	METAL CHIP METAL CHIP	180 6.8K 22K 6.8K 22K	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		
		< JUMPER RESISTOR >			R008	1-216-047-91		820	5%	1/10W		
JR101 JR102	1-216-296-91 1-216-296-91						< VARIABLE RES		0 70	171000		
JR103 JR104 JR105	1-216-296-91 1-216-296-91 1-216-296-91	SHORT 0			RV001 RV002	1-238-858-11 1-238-862-11		NET 47K				
		< TRANSISTOR >					< SWITCH >					
Q102	8-729-012-46	PHOTO TRANSISTOR PT4	600FS		S002	1-762-558-11	SWITCH, PUSH	(C DOWN)				
		< RESISTOR >					MD-65 BOARD (Ref No. 5.0	OOO Series	-)		
R101 R102 R103 R107 R108	1-216-031-00 1-216-081-00 1-216-069-00 1-216-069-00 1-216-047-91	METAL CHIP 22K METAL CHIP 6.8K METAL CHIP 6.8K	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	CN201	1-766-830-21	<pre>********* < CONNECTOR > CONNECTOR, FFG</pre>	C/FPC (ZIF	i) 11P	>)		
R109	1-216-081-00	METAL CHIP 22K	5%	1/10W	CN202 CN203	1-774-771-11 1-564-001-11		R 2P				
		< VARIABLE RESISTOR >			CN204	1-750-620-11	CONNECTOR (MI	M8 MD)				
RV101 RV102		RES, ADJ, CERMET 47K RES, ADJ, CERMET 1M		-	JR201	1-216-296-91	< JUMPER RESIS	STOR >		•		
		< SWITCH >										
\$101	1-572-719-11	SWITCH, PUSH (1 KEY)			⚠ ⚠		POWER BLOCK (POWER BLOCK (U-1) (DSR				
· ·		MD-64 BOARD (Ref No. 7,0	100 Sarios	2)			**************************************		f No. 10,0	00 Series)		
		*********	.50 001108	"			< CAPACITOR >					
		< CAPACITOR >			▲ C1	1-104-705-11	FILM	0.1uF	20%	250V		
	1-126-206-11 1-163-031-11	ELECT CHIP 100uF CERAMIC CHIP 0.01uF	20%	6.3V 50V	∆ C1	1-104-706-11	FILM	0.22uF	20%	SR-20MD) 250V		
3302	. 100 001-11	OCCUPATION OF THE OCCUPATION OCCUPATION OF THE OCCUPATION		30V	△ C2 △ C3 △ C4	1-104-705-11 1-115-383-11 1-115-383-11	CERAMIC	0.1uF 0.001uF 0.001uF	(DSF 20% 10% 10%	R-20MDP) 250V 125V 125V		
					Tr.							

The components identified by mark ♠ or dotted line with mark ♠ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque A sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

POWER BLOCK (U-1)

											- ()
Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
						D5	8-719-110-72		noncepo		Homan
△ C5	1-115-383-11	CERAMIC	0.001uF	10%	125V	D6	8-719-110-72		D30ESB2 D30ESB2		
△ C6	1-104-705-11		0.1uF	20%	250V	"	0 7 10 110 72	DIODE III			
C7	1-115-383-11		0.001uF	10%	125V	D8	8-719-053-20	DIODE U	F4003P		
C8	1-115-383-11		0.001uF	10%	125V	D9	8-719-109-85		D5.1ESB2		
 ∆ C9	9-880-364-01	ELECT	470uF		200V	D10	8-719-510-37		5LC20U		
				(E	SR-20MD)	D11	8-719-109-97		D6.8ESB2		
∆ C9	1 117 100 11	EL EOT	4505	000/	400)/	D12	8-719-110-41	DIODE RI	D15ESB2		
212 09	1-117-188-11	ELECT	150uF	20%	400V			TDANOIO			
C10	9-880-365-01	FII M	0.01uF	(D3	R-20MDP) 630V			< TRANSIST	UK >		
C11	9-880-366-01		680PF (D	SR-20MI		Q1	8-729-037-96	TRANSISTO	B 25K2366 (D	SB-20M	ות
C11	9-880-424-01	CERAMIC	330PF (DS	SR-20MI	DP)	Q1	9-880-423-01	TRANSISTO	R 2SK2483 (D	SR-20M	DP)
C12	9-880-366-01	CERAMIC	680PF (D	SR-20MI	D)	Q3	8-729-281-53				
010	0.000.404.04	OFDANNO	00000 (0)								
C12 C13	9-880-424-01 1-107-929-11		330PF (DS					< RESISTOR	? >		
C14	1-107-929-11		10uF 10uF	20% 20%	100V 100V	∆R1	0.000.070.01	METAL OVE	NE 000K		DOD COME
C15	1-126-387-11		2.2uF	20%	100V 100V	∆R1	9-880-373-01 9-880-427-01	METAL OXID		1W (1W	DSR-20MD)
C16	9-880-367-01		0.1uF	2070	1001	45111	3-000-421-01	MILIAL OXIL)E 330K		SR-20MDP)
						R2	9-880-374-01	METAL OXID	E 82K		DSR-20MD)
C17	9-880-368-01		470PF			R2	9-880-428-01			2W `	
C18	9-880-369-01		0.15uF							([SR-20MDP)
C19 C20	9-880-370-01		0.033uF	000/	4001	R3	1-212-865-00	FUSEBLE	22	5%	1/4W F
C21	1-107-929-11 9-880-371-01		10uF 0.001uF	20%	100V	, n	1 047 070 11	OADDON	40016		
021	9-000-371-01	CENAINIC	0.00 Tur			R4 R5	1-247-879-11 1-215-884-11		100K E 47	5% 5%	1/4W
C22	9-880-371-01	CERAMIC	0.001uF			R6	1-215-880-11			5%	2W 2W
C25	9-880-371-01		0.001uF (E	SR-20N	/ID)	R7	9-880-375-01				DSR-20MD)
C25	9-880-426-01		0.001uF (I			R7	9-880-650-01			2W \	or Lows,
C26	9-880-371-01		0.001uF (I							(D	SR-20MDP)
C26	9-880-426-01	CERAMIC	0.001uF ([DSR-20N	/IDP)	D0	0.000.000.01		_		
C27	1-111-066-11	FLECT	820uF	20%	25V	R8 R8	9-880-376-01			•	OSR-20MD)
C28	1-111-066-11		820uF	20%	25V 25V	no	9-880-429-01	METAL OXID	E 0.47	5W	CD GOMEDO
C29	9-880-367-01		0.1uF	2070	201	R9	1-216-377-11	METAL OXID	E 4.7	5%	SR-20MDP) 2W
C31	9-880-367-01	FILM	0.1uF			R10	1-215-462-00		5.1K	1%	1/4W
C32	9-880-367-01	FILM	0.1uF			R11	1-249-411-11		330	5%	1/4W
		COMMITTOE						19.21		• (DSR-20MD)
		< CONNECTOR >				R11	1 040 417 11	OADDON	412	=0/	
* CN1	1-580-230-31	PIN, CONNECTOR	R (FOR BOAL	RD) 2P		nii	1-249-417-11	CARBON	1K	5%	1/4W
* CN3	9-880-386-01	BOARD IN HARNI	ESS 4P	110, 21		R12	1-215-383-00	METAL	27	. 1%	SR-20MDP) 1/4W
						R13	1-215-385-00	METAL	33	1%	1/4W 1/4W
		< FUSE >				R14	1-249-430-11		12K	5%	1/4W
						R16	1-215-884-11	METAL OXID	E 47	5%	2W
 ∆ F1		FUSE (3.15A/125									
Δ F1 Δ F2	9-002-0/0-01	FUSE (T1.6AL/25 FUSE (3.15A/125	00V) (DSR-2	ZUMDP)		R18	1-247-847-11		4.7K	5%	1/4W
Δ F2		FUSE (3.15A/125				R19 R20	1-247-847-11 1-247-839-11		4.7K	5%	1/4W
·	0 002 070 07	100E (11.0AE/20	00) (0011-2	ZOWIDI)		R21	1-247-639-11		2.2K 1K	5% 5%	1/4W 1/4W
		< COIL >				R22	1-247-843-11		3.3K	5%	1/4W
								0,	0.010	0 /0	17444
∆L1		INDUCTOR 6mH (İ	R23	1-249-399-11		33	5%	1/4W
∆L1		INDUCTOR 15mH				R24	1-215-425-00		1.5K	1%	1/4W
∆L2 ∆L2		INDUCTOR 5.6ml INDUCTOR 22mH				R25	1-215-425-00		1.5K	1%	1/4W
L3	9-880-381-01		(DOM-ZUIVII	JP)	}	R26 R27	1-215-433-00		3.3K	1%	1/4W
	5 555 551 51					nZ/	1-249-417-11	CAUDUN	1K	5%	1/4W
L4	9-880-382-01	INDUCTOR			ĺ	R28	9-880-375-01	METAL OXIDI	18K	מו אופ	SR-20MD)
L5	9-880-382-01	INDUCTOR				R28	9-880-650-01				SR-20MD)
L6	9-880-383-01	INDUCTOR				R29	9-880-651-01			2W (B	
		~ DIODE ~			İ			< VARIABLE F	RESISTOR >		
	100	< DIODE >				RV1	0_880_977.01	DEC MAD O	ADDONION		
. △ .D1	8-719-500-58	DIODE D3SBA6	0			11 V I	9-880-377-01	TEO, VAAM, U	AUBON 3K		
D4	8-719-979-63		(DSR-20MD)) 							
D4	8-719-053-19	DIODE UF40070	323 (DSR-2	OMDP)	ļ						

The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque ∆ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

POWER BLOCK (U-1) POWER BLOCK (U-2)

A_TI	Ref. No.	Part No.	<u>Description</u>			Remark	Ref. No.	Part No.	<u>Description</u>			Remark
## A-T1 9-885-000-13 TRANSFORMER, POWER (DSR-20MDP) C44 1-117-154-11 ELECT 33µ			< TRANSFORME	:R >			C41	9-880-399-01	FILM	0.047uF		
C45							l .				000/	
This 9-880-384-01 THERMISTOR 8	2011	3-003-000-13	INANGFUNIMEN	, FUVVEN (L	Jon-Zuivi	DP)	1				20%	167
THI 9-880-384-01 THERMISTOR 8 **CIC>**** **CIC>*** **CIC>**** *CIC>**** **CIC>**** **CIC>**** **CIC>**** **CIC>**** **CIC>*** **CIC>**** **CIC>**** **CIC>**** **CIC>**** **CIC>**** **CIC>*** **CIC>**** **CAPACITOR >**** **CRIT IN-15-780-11** **CRIT IN-15-780-11** **CIC II-15-780-11** **CAPACITOR >**** **COAPACITOR >**** **COAPACITOR STANCE AT A A TUFF TOW 10V 10V 10V 10V 10V 10V 10V 10V 10V 10V			< THERMISTOR	>			3					
C C C C C C C C C C C C C	TH1	9-880-384-01	THERMISTOR	8	٠.		C47	1-117-154-11	ELECT	33uF	20%	16V
21 9-885-000-09 IC FA5316P A.729 8-749-924-80 PHOTO COUPLER PS2561L1-LV C54 9-880-400-01 ELECT 330uf 25V C54 9-880-400-01 ELECT 580uf 10V C54 9-880-400-01 ELECT 580uf 10V C55 9-880-400-01 ELECT 580uf 10V C56 1-115-566-11 C574MIC 4.7uf 10% 10V C58 9-880-399-01 FILM 0.047uf 0.0022uf C56 1-115-566-11 C574MIC 4.7uf 10% 10V C58 9-880-399-01 FILM 0.047uf 0.07uf 0.07				-			C48				20%	16V
271 9-988-00-09 C FA5316P C24 22 8-749-924-80 PHOTO COUPLER PS25611-1-V C54 9-880-460-01 ELECT 330uF 25V C54 9-880-460-01 ELECT 330uF 25V C54 9-880-460-01 ELECT 680uF 10V C55 9-880-460-01 ELECT 680uF 10V C55 9-880-460-01 ELECT 680uF 10V C55 9-880-460-01 ELECT 180uF 50V C57 9-880-460-01 ELECT 180uF 50V C57 9-880-460-01 ELECT 180uF 50V C57 9-880-460-01 ELECT 180uF 50V C57 9-880-460-01 ELECT 10% 10V C56 1-115-767-11 ELECT 220uF 20% 25V C58 1-115-566-11 C57 0-880-400-01 ELECT 10% 10V C50 9-880-399-01 ELECT 330uF 25V C64 1-115-566-11 C57 0-880-400-01 ELECT 10% 10V C50 9-880-399-01 ELECT 330uF 25V C64 1-115-566-11 C57 0-880-400-01 ELECT 10% 10V C50 9-880-399-01 ELECT 330uF 25V C64 1-115-566-11 C57 0-880-400-01 ELECT 10% 10V C50 9-880-400-01 ELECT 330uF 25V C64 1-115-566-11 C57 0-880-400-01 ELECT 10% 10V C50 9-880-400-01 ELECT 330uF 25V C64 1-115-566-11 C57 0-880-400-01 ELECT 10% 10V C50 C50 0-880-400-01 ELECT 10% 10V C50 C50 0-880-400-01 ELECT 10% 10V C50 C50 0-880-400-01 ELECT 10% 10V C50 C50 0-880-400-01 ELECT 10% 10V C50 C50 0-880-400-01 ELECT 10% 10V C50 C50 0-880-400-01 ELECT 10% 10V C50 C50 0-880-400-01 ELECT 10% 10V C50 C50 0-880-400-01 ELECT 10% 10V C50 0-880-400-01 ELECT			< IC >				1					
## 8-749-924-80 PHOTO COUPLER PS25611-1-V ## 1-466-441-11 POWER BLOCK (U-2) (DSR-20MD) ## 1-468-442-11 POWER BLOCK (U-2) (DSR-20MD) ## 2-468-401-11 FLECT 20UF 20% 25V C64 1-115-566-11 CERAMIC 4.7 UF 10% 10V ## 1-115-767-11 ELECT 30UF 20% 25V C64 1-115-566-11 CERAMIC 4.7 UF 10% 10V ## 1-115-767-11 ELECT 30UF 20% 25V C66 1-115-566-11 CERAMIC 4.7 UF 10% 10V ## 1-115-767-11 ELECT 30UF 20% 25V C66 1-115-566-11 CERAMIC 4.7 UF 10% 10V ## 1-115-767-11 ELECT 30UF 20% 25V C69 1-115-566-11 CERAMIC 4.7 UF 10% 10V ## 1-115-767-11 ELECT 30UF 20% 25V C70 1-115-566-11 CERAMIC 4.7 UF 10% 10V ## 1-115-767-11 ELECT 30UF 20% 25V C70 1-115-566-11 CERAMIC 4.7 UF 10% 10V ## 1-115-767-11 ELECT 40UF 20% 10V ## 1-115-767-11 ELECT 40UF 20% 10V ## 1-115-767-11 ELECT 40UF 20% 10V ## 2-404-11 ELECT 40UF 20% 10V ## 1-115-767-11 ELECT 40UF 20% 10V ## 2-404-11 ELECT 40UF 20% 10V ## 2	Z1	9-885-000-09	IC FA531	6P			1					25V
Δ 1-468-441-11 POWER BLOCK (U-2) (DSR-20MD) 1-468-441-11 POWER BLOCK (U-2) (DSR-20MD) (Ref No. 20,000 Series) (Ref N							C54	9-880-406-01	ELECT	680uF		10V
1-468-441-11 POWER BLOCK (U-2) (DSR-20MD)	ZIX Z.3	0-749-924-00	PHOTO COUPLE	n P323011	_1-1-V		C55	9-880-407-01	CERAMIC	0.0022uF		
A 1-468-442-1 POWER BLOCK (U-2) (DSR-20MOP)		1 100 111 11					C56	1-115-730-11	ELECT	180uF	20%	
(Ref No. 20,000 Series) (Ref No. 20,000 Serie												50V
C60		1 100 112 11			ZOWIDI)							
CAPACITOR > C61 1-115-666-11 CERAMIC 4.7uF 10% 10V C7 1-115-781-11 ELECT 220uF 20% 25V C63 1-115-666-11 CERAMIC 4.7uF 10% 10V C64 9-880-399-01 FILM 0.047uF C7 9-880-399-01 FILM 0.047uF C7 1-115-787-11 ELECT 330uF 25V C68 1-115-666-11 CERAMIC 4.7uF 10% 10V C7 1-115-787-11 ELECT 320uF 20% 25V C68 1-115-666-11 CERAMIC 4.7uF 10% 10V C7 1-115-787-11 ELECT 320uF 20% 25V C69 1-115-666-11 CERAMIC 4.7uF 10% 10V C7 1-115-787-11 ELECT 320uF 20% 25V C70 1-115-666-11 CERAMIC 4.7uF 10% 10V C7 1-115-787-11 ELECT 320uF 20% 25V C70 1-115-666-11 CERAMIC 4.7uF 10% 10V C7 1-115-787-11 ELECT 320uF 20% 25V C70 1-115-666-11 CERAMIC 4.7uF 10% 10V C7 1-115-787-11 ELECT 320uF 20% 25V C70 1-115-666-11 CERAMIC 4.7uF 10% 10V C70 1-115-787-11 ELECT 320uF 20% 25V C71 1-115-666-11 CERAMIC 4.7uF 10% 10V C70 1-115-787-11 ELECT 320uF 20% 25V C71 1-115-666-11 CERAMIC 4.7uF 10% 10V C70 1-115-787-11 ELECT 320uF 20% 25V C71 1-115-666-11 CERAMIC 4.7uF 10% 10V C70 1-115-787-11 ELECT 320uF 20% 25V C71 1-115-666-11 CERAMIC 4.7uF 10% 10V C70 1-115-787-11 ELECT 320uF 20% 25V C71 1-115-666-11 CERAMIC 4.7uF 10% 10V C70 1-115-787-11 ELECT 320uF 20% 25V C71 1-115-666-11 CERAMIC 4.7uF 10% 10V C70 1-115-666-11 CERAMIC				(Ref	No. 20,0	000 Series)	000	1 115 500 11	OFDANNO	4.75	400/	34004
C1			< CAPACITOR >				1					
C2	0.4	4 445 504 44	5. 50 .							4.7uF		10V
C3							1					
C5					20 /0	201	004	1-107-002-11	CERAIVIIO	TUF	1076	100
C6						orv	1					
C6 9-880-401-01 FILM 0.47uF C8 250vF 29% 25V C69 1-115-787-11 ELECT 4.7uF 10% 10V C7 1-115-787-11 ELECT 820uF 20% 25V C69 1-115-566-11 CERAMIC 4.7uF 10% 10V C10 9-880-403-01 FILM 0.1uF 50V C70 1-115-566-11 CERAMIC 4.7uF 10% 10V C12 9-880-404-01 ELECT 470uF 25V C71 1-115-566-11 CERAMIC 4.7uF 10% 10V C13 9-880-404-01 ELECT 470uF 25V C73 1-107-682-11 CERAMIC 1uF 10% 16V C15 1-115-737-11 ELECT 0.001uF 20% 10V CN1 9-880-417-01 PIN, CONNECTOR P CONNECTOR CN1 1-107-682-11 CERAMIC 1uF 10% 16V C15 1-115-737-11 ELECT 0.001uF 20% 10V ***CN1 1-508-481-11 CONNECTOR P ***CN1 1-508-481-11 CONNECTOR P ***CN2 1-508-481-11 PIN, CONNECTOR P ***CN2 1-508-481-11	00	3-000-400-01	ELEGI	SSOUR		23V	1					
C8 1-115-787-11 ELECT 820µF 20% 25V C71 1-115-566-11 CERAMIC 4.7µF 10% 10V C71 1-115-787-11 ELECT 820µF 20% 25V C71 1-115-566-11 CERAMIC 4.7µF 10% 10V C72 1-107-682-11 CERAMIC 1µF 10% 16V C72 1-107-682-11 CERAMIC 1µF 10% 16V C73 9-880-405-01 CERAMIC 0.001µF 20% 10V C71 1-115-737-11 ELECT 0.001µF 20% 10V C71 1-115-737-11 ELECT 0.01µF 20% 10V C71 1-1506-487-11 PIN, CONNECTOR 4P C71 1-124-942-11 ELECT 180µF 20% 10V C71 1-506-487-11 PIN, CONNECTOR 6P C71 1-124-942-11 ELECT 180µF 20% 10V C71 1-506-487-11 PIN, CONNECTOR 6P C71 9-880-399-01 FILM 0.047µF C71 9-880-399-01 FILM 0.047µF C71 9-880-399-01 FILM 0.047µF C71 9-880-399-01 FILM 0.047µF C71 9-880-399-01 FILM 0.047µF C71 9-880-399-01 FILM 0.047µF C71 9-880-399-01 FILM 0.047µF C71 9-880-399-01 FILM 0.047µF C71 9-880-399-01 FILM 0.047µF C71 9-880-399-01 FILM 0.047µF C71 9-880-399-01 FILM 0.047µF C71 9-880-399-01 FILM 0.047µF C71 9-880-399-01 FILM 0.047µF C71 9-880-399-01 FILM 0.047µF C72 9-880-399-01 FILM 0.047µF C73 1-107-682-11 INDUCTOR 150µH C71 1-115-730-11 ELECT 180µF 25V C71 1-115-730-11 ELECT 180µF 2							II.	1-115-566-11	CERAMIC			
C10							C69	1-115-566-11	CERAMIC	4.7uF	10%	10V
C12 9-880-404-01 ELECT 470uF 25V C73 1-107-682-11 CERAMIC 1uF 10% 16V C13 9-880-405-01 CERAMIC 0.001uF 20% 10V C15 1-115-737-11 ELECT 0.001uF 20% 10V C16 9-880-406-01 ELECT 680uF C21 9-880-399-01 FILM 0.047uF C21 9-880-399-01 FILM 0.047uF C22 9-880-399-01 FILM 0.047uF C23 9-880-399-01 FILM 0.047uF C24 1-115-730-11 ELECT 180uF 20% 10V C25 9-880-399-01 FILM 0.047uF C25 9-880-399-01 FILM 0.047uF C25 9-880-399-01 FILM 0.047uF C26 9-880-399-01 FILM 0.047uF C26 9-880-399-01 FILM 0.047uF C27 9-880-399-01 FILM 0.047uF C28 9-880-402-01 ELECT 680uF 10V E25V C29 9-880-402-01 ELECT 680uF 10V E25V C26 9-880-406-01 ELECT 680uF 10V E25V C27 9-880-406-01 ELECT 680uF 10V E25V C28 9-880-402-01 FILM 0.047uF C29 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-406-01 ELECT 680uF 10V E25 9-880-411-01 INDUCTOR 150uH E25 9-880-406-01 ELECT 680uF 10V E25 9-880-411-01 INDUCTOR 150uH E25 9-880-411-01 INDUCTOR 150uH E25 9-880-411-01 INDUCTOR 150uH E25 9-880-411-01 INDUCTOR 150uH E25 9-880-411-01 INDUCTOR 150uH E25 9-880-411-01 INDUCTOR 150uH E25 9-880-411-01 INDUCTOR 150uH E25 9-880-411-01 INDUCTOR 150uH E25 9-880-411-01 INDUCTOR 150uH E25 9-880-411-01 INDUCTOR 150uH E25 9-880-412-01 INDUCTOR 150uH E25 9-880-412-01 INDUCTOR 150uH E15 9-880-412-01 INDUCTOR 150uH E15 9-880-412-01 INDUCTOR 150uH E15 9-880-412-01 INDUCTOR 150uH E15 9-880-412-01 INDUCTOR 150uH E15 9-880-412-01 INDUCTOR 150uH E15 9-880-412-01 INDUCTOR 150uH E15 9-880-412-01 INDUCTOR 150uH E15 9-880-412-01 INDUCTOR 150uH E15 9-880-412-01 INDUCTOR 150uH E15 9-880-412-01 INDUCTOR 150uH E15 9-880-412-01 INDUCTOR 150uH E15 9-880-412-01 INDUCTOR 150uH E15 9-880-412-01 IND	C10	9-880-403-01	FILM	0.1uF	2070		C70			4.7uF	10%	10V
C12 9-880-404-01 ELECT 470uF 25V C73 1-107-682-11 CERAMIC 1uF 10% 16V C13 9-880-405-01 CERAMIC 0.001uF 20% 10V C15 1-115-737-11 ELECT 0.001uF 20% 10V C16 9-880-406-01 ELECT 680uF 10V * CN1 9-880-417-01 PIN, CONNECTOR 4P * CN2 1-506-485-11 PIN, CONNECTOR 8P C18 1-124-942-11 ELECT 180uF 20% 10V * CN11 1-506-487-11 PIN, CONNECTOR 8P C19 9-880-399-01 FILM 0.047uF * CN12 1-506-487-11 PIN, CONNECTOR 8P C19 9-880-399-01 FILM 0.047uF * CN12 1-506-481-11 CONNECTOR 8P C19 9-880-399-01 FILM 0.047uF * CN12 1-506-487-11 PIN, CONNECTOR 8P C19 9-880-399-01 FILM 0.047uF * CN12 1-506-487-11 PIN, CONNECTOR 8P C19 9-880-399-01 FILM 0.047uF * CN12 1-506-487-11 PIN, CONNECTOR 8P C19 9-880-399-01 FILM 0.047uF * CN12 1-506-487-11 PIN, CONNECTOR 8P C19 9-880-399-01 FILM 0.047uF * CN12 1-506-487-11 CONNECTOR 2P C19 9-880-399-01 FILM 0.047uF * CN13 1-506-481-11 CONNECTOR 2P C19 9-880-399-01 FILM 0.047uF * CN13 1-506-481-11 CONNECTOR 2P C19 9-880-409-01 FILM 0.047uF 25V C19 9-880-409-01 ELECT 180uF 20% 10V L2 9-880-409-01 INDUCTOR 0.5mH C19 9-880-409-01 FILM 0.047uF 10V L2 9-880-409-01 INDUCTOR 150uH 10V L3 9-880-409-01 INDUCTOR 150uH 10V L3 9-880-409-01 FILM 0.01uF 10V L3 9-880-411-01 INDUCTOR 150uH 10V L3 9-880-411-01 INDUCTOR 150uH 10V L3 9-880-411-01 INDUCTOR 150uH 10V L3 9-880-411-01 INDUCTOR 150uH 10V L3 9-880-411-01 INDUCTOR 150uH 10V L3 9-880-411-01 INDUCTOR 150uH 10V L3 9-880-411-01 INDUCTOR 150uH 10V L5 9-880-411-01 INDUCTOR 150uH 10V L9 9-880-411-01 INDUCTOR 150uH 10V L9 9-880-411-01 INDUCTOR 150uH 10V L9 9-880-411-01 INDUCTOR 150uH 10V L19 9-880-411-01 INDUCTOR 150uH 10V L19 9-880-411-01 INDUCTOR 150uH 10V L19 9-880-411-01 INDUCTOR 150uH 10V L19 9-880-411-01 INDUCTOR 150uH 10V L10 9-880-411-01 INDUCTOR 150uH 10V L10 9-880-411-01 INDUCTOR 150uH 10V L10 9-880-411-01 INDUCTOR 150uH 10V L10 9-880-411-01 INDUCTOR 150uH 10V L10 9-880-411-01 INDUCTOR 150uH 10V L11 9-880-411-01 INDUCTOR 150uH 10V L11 9-880-411-01 INDUCTOR 150uH 10V L11 9-880-411-01 INDUCTOR 150uH 10V L11 9-880-411-01 INDUCTOR 150uH 10V L11 9-880-411-01 INDUCTOR 150uH	C11	1-115-787-11	ELECT	820uF	20%	25V	ì					
C13 9-880-405-01 CERAMIC 0.001	C12	9-880-404-01	ELECT	470uF		25V						
C15					•••							
C16 9-880-406-01 ELECT 680uF 10V						,			< CONNECTOR >			
C17 9-880-402-01 FILM 0.1 uF 50V					2070		1	9-880-417-01	PIN, CONNECTOR	R 4P		
C18	017	0_880_402_01	EII M	0.1uE		EOV.						
C19 9-880-399-01 FILM 0.047uF					20%						•	
C21 9-880-399-01 FILM 0.047uF							* CN12					
C22 9-880-402-01 FILM 0.1uF 50V							* CN13	1-506-481-11	CONNECTOR 2P			
C23 9-880-399-01 FILM 0.047uF C24 1-115-730-11 ELECT 180uF 20% 10V C25 9-880-404-01 ELECT 470uF 25V C26 9-880-399-01 FILM 0.047uF C27 9-880-407-01 CERAMIC 0.0022uF C28 9-880-406-01 ELECT 680uF 10V C29 9-880-406-01 ELECT 680uF 10V C30 9-880-406-01 FILM 0.01uF C31 9-880-406-01 ELECT 680uF 10V C32 1-115-785-11 ELECT 680uF 10V C33 1-124-534-11 ELECT 680uF 25V C34 9-880-402-01 FILM C35 1-115-785-11 ELECT 680uF 20% 16V C36 9-880-402-01 FILM C37 1-115-785-11 ELECT 120uF 20% 16V C38 9-880-403-01 FILM C39 9-880-403-01 FILM C30 9-880-403-01 FILM C31 9-880-403-01 FILM C32 1-115-754-11 ELECT 120uF 20% 16V C33 1-15-754-11 ELECT 120uF 20% 16V C34 9-880-403-01 FILM C35 1-115-750-11 ELECT 120uF 20% 16V C36 9-880-403-01 FILM C37 1-115-730-11 ELECT 180uF 20% 10V C38 9-880-399-01 FILM C39 9-880-399-01 FILM C39 9-880-402-01 FILM C39 9-880-402-01 FILM C30 0.047uF C39 9-880-412-01 INDUCTOR 15uH C39 9-880-412-01 INDUCTOR 15uH C39 9-880-412-01 INDUCTOR 15uH C39 9-880-412-01 INDUCTOR 15uH C39 9-880-412-01 INDUCTOR 15uH C39 9-880-412-01 FILM C30 0.047uF C39 9-880-412-01 FILM C30 0.047uF C30 0.047uF C31 0.047uF C32 0.047uF C33 0.047uF C34 0.047uF C35 0.047uF C36 0.047uF C37 0.047uF C38 0.047uF C39 0.047uF C39 0.047uF C30 0.							0.1.0	7 000 101 11				
C24						50V			< FUSE >			
C26 9-880-399-01 FILM 0.047uF < COIL > C27 9-880-407-01 CERAMIC 0.0022uF L1 9-880-408-01 INDUCTOR 0.5mH C28 9-880-406-01 ELECT 680uF 10V L2 9-880-409-01 INDUCTOR 1mH C29 9-880-406-01 ELECT 680uF 10V L3 9-880-410-01 INDUCTOR 150uH C30 9-880-402-01 FILM 0.01uF L4 1-459-407-00 COIL, FERRITE CHOKE 68uH C31 9-880-406-01 ELECT 680uF 10V L5 9-880-412-01 INDUCTOR 150uH C32 1-115-785-11 ELECT 470uF 25V L6 9-880-412-01 INDUCTOR 15uH C33 1-124-534-11 ELECT 680uF 20% 16V L8 9-880-412-01 INDUCTOR 330uH C34 9-880-402-01 FILM 0.01uF L9 9-880-412-01 INDUCTOR 15uH C35 1-115-754-11 ELECT 120uF 20% 16V L11 <td< td=""><td></td><td></td><td></td><td></td><td>20%</td><td>10V</td><td> ⚠ F2</td><td>9-880-416-01</td><td>FUSE (T5A/250V)</td><td></td><td></td><td></td></td<>					20%	10V	 ⚠ F2	9-880-416-01	FUSE (T5A/250V)			
C27 9-880-407-01 CERAMIC 0.0022uF C28 9-880-406-01 ELECT 680uF 10V L2 9-880-409-01 INDUCTOR 0.5mH C29 9-880-406-01 ELECT 680uF 10V L3 9-880-410-01 INDUCTOR 150uH C30 9-880-402-01 FILM 0.01uF C31 9-880-406-01 ELECT 680uF 10V L5 9-880-411-01 INDUCTOR 150uH C32 1-115-785-11 ELECT 470uF 25V L6 9-880-412-01 INDUCTOR 15uH C33 1-124-534-11 ELECT 680uF 20% 16V L8 9-880-413-01 INDUCTOR 330uH C34 9-880-402-01 FILM 0.01uF C35 1-115-754-11 ELECT 120uF 20% 16V L11 9-880-414-01 INDUCTOR 15uH C36 9-880-403-01 FILM 0.1uF 50V L12 9-880-415-01 INDUCTOR 150uH C37 1-115-730-11 ELECT 180uF 20% 10V L13 9-880-415-01 INDUCTOR C38 9-880-399-01 FILM 0.047uF C39 9-880-402-01 FILM 0.047uF C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.047uF C39 9-880-402-01 FILM 0.01uF L15 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.047uF C30 0.047uF C30 0.047uF C30 0.0408-01 INDUCTOR 0.0408-01 INDUCTOR 15uH C30 0.047uF C30 0.0408-01 INDUCTOR 15uH C30 0.047uF C30 0.0408-01 INDUCTOR 15uH C30 0.047uF C30 0.0408-01 INDUCTOR 15uH C30 0.047uF C30 0.0408-01 INDUCTOR 15uH C30 0.047uF C30 0.0408-01 INDUCTOR 15uH C30 0.047uF C30 0.0408-01 INDUCTOR 15uH C30 0.047uF C30 0.0408-01 INDUCTOR 15uH C30 0.047uF C30 0.0408-01 INDUCTOR 15uH C30 0.047uF C30 0.0408-01 INDUCTOR 15uH C30 0.047uF C30 0.0408-01 INDUCTOR 15uH C30 0.047uF C30 0.0408-01 INDUCTOR 15uH C30 0.047uF C30 0.0408-01 INDUCTOR 15uH C						25V			2011			
C28 9-880-406-01 ELECT 680uF 10V L2 9-880-409-01 INDUCTOR 1mH C29 9-880-406-01 ELECT 680uF 10V L3 9-880-410-01 INDUCTOR 150uH C30 9-880-402-01 FILM 0.01uF L4 1-459-407-00 COIL, FERRITE CHOKE 68uH C31 9-880-406-01 ELECT 680uF 10V L5 9-880-411-01 INDUCTOR 150uH C32 1-115-785-11 ELECT 470uF 25V L6 9-880-412-01 INDUCTOR 15uH C33 1-124-534-11 ELECT 680uF 20% 16V L8 9-880-413-01 INDUCTOR 330uH C34 9-880-402-01 FILM 0.01uF L9 9-880-412-01 INDUCTOR 15uH C35 1-115-754-11 ELECT 120uF 20% 16V L11 9-880-414-01 INDUCTOR 15uH C36 9-880-403-01 FILM 0.1uF 50V L12 9-880-415-01 INDUCTOR 15uH C37 1-115-730-11 ELECT 180uF 20% 10V L13 9-880-412-01 INDUCTOR 15uH C38 9-880-399-01 FILM 0.047uF L15 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH C39 9-880-412-01 INDUCTOR 15uH C39 9-880-412-01 INDUCTOR 15uH C30 9-880-412-01 INDUCTOR 15uH C30 9-880-412-01 INDUCTOR 15uH C30 9-880-412-01 INDUCTOR 15uH C30 9-880-412-01 INDUCTOR 15uH C31 9-880-412-01 INDUCTOR 15uH C32 9-880-412-01 INDUCTOR 15uH C33 9-880-412-01 INDUCTOR 15uH C34 9-880-412-01 INDUCTOR 15uH C35 1-115-730-11 ELECT 180uF 20% 10V L13 9-880-412-01 INDUCTOR 15uH C39 9-880-412-01 INDUCTOR 15uH C30 9-880-412-01 INDUCTOR 15uH	020	9-000-099-01	FILIVI	0.04747					< GUIL >			
C29 9-880-406-01 ELECT 680uF 10V L3 9-880-410-01 INDUCTOR 150uH C30 9-880-402-01 FILM 0.01uF C31 9-880-406-01 ELECT 680uF 10V L5 9-880-411-01 INDUCTOR 150uH C32 1-115-785-11 ELECT 470uF 25V L6 9-880-412-01 INDUCTOR 150uH C33 1-124-534-11 ELECT 680uF 20% 16V L8 9-880-413-01 INDUCTOR 330uH C34 9-880-402-01 FILM 0.01uF C35 1-115-754-11 ELECT 120uF 20% 16V L11 9-880-412-01 INDUCTOR 15uH C36 9-880-403-01 FILM 0.1uF 50V L12 9-880-415-01 INDUCTOR C37 1-115-730-11 ELECT 180uF 20% 10V L13 9-880-412-01 INDUCTOR 15uH C38 9-880-399-01 FILM 0.047uF C39 9-880-402-01 FILM 0.01uF L15 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.047uF C39 9-880-402-01 FILM 0.01uF L15 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH C30 0.01uF L10 0.047uF C30 0.01uF C30 0.01uF C30 0.01uF C30 0.01uF C30 0.01uF C30 0.01uF C30 0.01u										1		
C30 9-880-402-01 FILM 0.01uF 10V L5 9-880-411-01 INDUCTOR 150uH C31 9-880-406-01 ELECT 470uF 25V L6 9-880-412-01 INDUCTOR 150uH C32 1-115-785-11 ELECT 470uF 25V L8 9-880-413-01 INDUCTOR 330uH C33 1-124-534-11 ELECT 680uF 20% 16V L8 9-880-413-01 INDUCTOR 330uH C34 9-880-402-01 FILM 0.01uF L9 9-880-412-01 INDUCTOR 15uH C35 1-115-754-11 ELECT 120uF 20% 16V L11 9-880-414-01 INDUCTOR 150uH C36 9-880-403-01 FILM 0.1uF 50V L12 9-880-415-01 INDUCTOR C37 1-115-730-11 ELECT 180uF 20% 10V L13 9-880-412-01 INDUCTOR 15uH C38 9-880-399-01 FILM 0.047uF L15 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH C30 1-115-730-11 ELECT 180uF 20% 10V L13 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH										ı		
C32 1-115-785-11 ELECT 470uF 25V L6 9-880-412-01 INDUCTOR 15uH C33 1-124-534-11 ELECT 680uF 20% 16V L8 9-880-413-01 INDUCTOR 330uH C34 9-880-402-01 FILM 0.01uF L9 9-880-412-01 INDUCTOR 15uH C35 1-115-754-11 ELECT 120uF 20% 16V L11 9-880-414-01 INDUCTOR 15ouH C36 9-880-403-01 FILM 0.1uF 50V L12 9-880-415-01 INDUCTOR C37 1-115-730-11 ELECT 180uF 20% 10V L13 9-880-412-01 INDUCTOR 15uH C38 9-880-399-01 FILM 0.047uF L15 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF	C30	9-880-402-01	FILM	0.01uF			L4					
C33 1-124-534-11 ELECT 680uF 20% 16V L8 9-880-413-01 INDUCTOR 330uH C34 9-880-402-01 FILM 0.01uF L9 9-880-412-01 INDUCTOR 15uH C35 1-115-754-11 ELECT 120uF 20% 16V L11 9-880-414-01 INDUCTOR 150uH C36 9-880-403-01 FILM 0.1uF 50V L12 9-880-415-01 INDUCTOR C37 1-115-730-11 ELECT 180uF 20% 10V L13 9-880-412-01 INDUCTOR 15uH C38 9-880-399-01 FILM 0.047uF L15 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH	C31	9-880-406-01	ELECT	680uF		10V	L5	9-880-411-01	INDUCTOR 150uH	l		
C34 9-880-402-01 FILM 0.01uF L9 9-880-412-01 INDUCTOR 15uH C35 1-115-754-11 ELECT 120uF 20% 16V L11 9-880-414-01 INDUCTOR 150uH C36 9-880-403-01 FILM 0.1uF 50V L12 9-880-415-01 INDUCTOR C37 1-115-730-11 ELECT 180uF 20% 10V L13 9-880-412-01 INDUCTOR 15uH C38 9-880-399-01 FILM 0.047uF L15 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH	C32	1-115-785-11	ELECT	470uF		25V	L6	9-880-412-01	INDUCTOR 15uH			
C35 1-115-754-11 ELECT 120uF 20% 16V L11 9-880-414-01 INDUCTOR 150uH C36 9-880-403-01 FILM 0.1uF 50V L12 9-880-415-01 INDUCTOR C37 1-115-730-11 ELECT 180uF 20% 10V L13 9-880-412-01 INDUCTOR 15uH C38 9-880-399-01 FILM 0.047uF L15 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH					20%	16V				1		
C36 9-880-403-01 FILM 0.1uF 50V L12 9-880-415-01 INDUCTOR C37 1-115-730-11 ELECT 180uF 20% 10V L13 9-880-412-01 INDUCTOR 15uH C38 9-880-399-01 FILM 0.047uF L15 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH					20%	16V				I		
C38 9-880-399-01 FILM 0.047uF L15 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH										• .		
C38 9-880-399-01 FILM 0.047uF L15 9-880-412-01 INDUCTOR 15uH C39 9-880-402-01 FILM 0.01uF L16 9-880-412-01 INDUCTOR 15uH	C37	1-115-730-11	ELECT	180uF	20%	10V	13	9-880-412-01	INDUCTOR 150H			
	C38	9-880-399-01	FILM	0.047uF			L15	9-880-412-01	INDUCTOR 15uH			
0.01ul L1/ 9-000-412-01 INDUCTOR 13un						·						
	U+U	J-000-402-01	1 (LIVI	o.orur		; ;	L1/	J-00U-41Z-U1	HUCLON 194H	· ·		 1

The components identified by mark ♠ or dotted line with mark ♠ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque A sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

R	E-32

							L				
Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	<u>Description</u>			<u>Remark</u>
		< DIODE >				Z3		IC LM2576T-ADJ	II B03		
		< DIODE >		•		Z4		IC uPC29L03J	LDUG		
D1	8-719-500-70	DIODE D5S4M	1								
D2	8-719-109-89					Z5	8-759-069-28				
D3	8-719-500-70					Z6		IC TD62305AP			
D4	8-719-043-76					Z7		IC LM2575T-ADJ			
D5	8-719-018-83	DIODE D2S4M				Z8		IC LM2575T-ADJ	LB03		
			-			Z10	8-759-089-53	IC uPC79M05HF			
D6	8-719-018-83						. ===	10.000000			
D7	8-719-107-94					Z11	8-759-098-24	IC PQ30RV11			
D8	8-719-107-94	DIODE 1SS202	2-1			 					
		< TRANSISTOR >				*	A-7072-470-A	RE-32 BOARD, C	OMDI ETE		
		< THANSISTON >					M-1013-410-A	**********			
Q1 ·	8-729-201-53	TRANSISTOR 2S	A1015-GR					•	(Be	ef.No. 7	,000 Series)
Q2		TRANSISTOR 2S									,,
Q3	8-729-281-53	TRANSISTOR 2S	C1815-GR					< CAPACITOR >			
Q4	8-729-203-76	TRANSISTOR 2S	C3328-Y								
						C101	1-163-243-11		47P F	5%	50V
		< RESISTOR >				C102	1-163-243-11		47PF	5%	50V
		040000	0.611	# ~'	4 (114)	C103	1-163-243-11		47PF	5%	50V
R1	1-247-839-11		2.2K	5%	1/4W	C104		CERAMIC CHIP	47PF	5%	50V
R2	1-215-454-00		24K	1%	1/4W	C105	1-163-243-11	CERAMIC CHIP	47PF	5%	50V
R3 R4	1-215-427-00 1-215-429-00		1.8K 2.2K	1% 1%	1/4W 1/4W	C106	1-163-243-11	CERAMIC CHIP	47PF	5%	50V
R5		METAL OXIDE	560	1% 5%	174VV 1W	C108	1-163-243-11		0.022uF	5% 10%	25V
กง	1-210-401-11	WE TAL OXIDE	300	J /0	1 44	C115	1-163-038-91	CERAMIC CHIP	0.022ui	10 /0	25V 25V
R6	1-215-857-11	METAL OXIDE	10	5%	1W	0110	1 100 000 51	OLITAWIO OTIII	0.141		201
R7	1-215-443-00		8.2K	1%	1/4W	Ì		< CONNECTOR >			
R8	1-215-416-00		620	1%	1/4W						
R9	1-215-429-00		2.2K	1%	1/4W	CN101	1-764-129-11	CONNECTOR, FP	C 15P		
R10	1-216-448-11	METAL OXIDE	39	5%	2W	CN102	1-764-129-11	CONNECTOR, FP	C 15P		
R11	1-249-417-11		1K	5%	1/4W			< DIODE >			
R12	1-249-424-11		3.9K	5%	1/4W	D404	0 710 401 50	DIODE MASOZE	M/A /TV\		
R14	1-249-417-11 1-247-847-11		1K	5%	1/4W 1/4W	D101 D102	0-719-421-59	DIODE MA3075 DIODE MA3075	WA- (TX)		
R15 R16	1-247-047-11		4.7K 56	5% 5%	1/4W	D103		DIODE MA3075			
1110	1-243-402-11	CARBON	30	J /0	117700	D104		DIODE MA3075			
R17	1-249-402-11	CARBON	56	5%	1/4W	D105		DIODE MA3075			
R18	1-249-402-11		56	5%	1/4W				(,		
R19	1-247-847-11	CARBON	4.7K	5%	1/4W	D106	8-719-421-59	DIODE MA3075	WA- (TX)		
R21	1-249-417-11	CARBON	1K	5%	1/4W	D107		DIODE MA3075			
R22	1-215-857-11	METAL OXIDE	10	5%	1W	D108		DIODE MA3075			
						D109		DIODE MA3075			
R23	1-215-387-00		39	1%	1/4W	D110	8-719-421-59	DIODE MA3075	WA- (TX)		
R24	1-215-408-00		300	1%	1/4W	5444	0 740 401 50	DIODE MASS	\AIA /T\^		
R25	1-215-405-00		220	1%	1/4W	D111		DIODE MA3075			
R26	1-215-431-00		2.7K	1% 1%	1/4W	D112		DIODE MASO75			
R27	1-215-449-00	MEIWE	15K	1%	1/4W	D113		DIODE MA3075 DIODE MA3075			
R28	1-215-430-00	METAI	2.4K	1%	1/4W	D114		DIODE MA3075			
R29	1-247-841-11		2.4K 2.7K	5%	1/4W	1 5113	O 710 721-05	DIODE WAGOTO	HA (IA)		
R30	1-249-417-11		1K	5%	1/4W			< FERRITE BEAD	>		
R31	1-215-447-00		12K	1%	1/4W	Į.					
R32	1-215-423-00		1.2K	1%	1/4W	FB101	1-500-241-22	FERRITE	0uH		
						FB102	1-500-241-22		0uH		
R33	1-215-423-00		1.2K	1%	1/4W	FB103	1-500-241-22	FERRITE	0uH		
R43	1-215-857-11		10	5%	1W	FB104	1-500-241-22		0uH		
R45	1-215-443-00		8.2K	1%	1/4W	FB105	1-500-241-22	FERRITE	0uH		
R46	1-215-413-00		470	1%	1/4W						
R47	1-215-429-00	METAL	2.2K	1%	1/4W	FB106	1-500-241-22	FERRITE	0uH		
R48	1-247-839-11	CARRON	2.2K	5%	1/4W	1		< JACK >			
R49	1-247-039-11		56	5% 5%	1/4W			~ U/U/U/ >			
R50	1-247-855-11		10K	5%	1/4W	J101	1-694-410-11	TERMINAL BOAR	n		
R53	1-215-857-11		10	5%	1W] ""	. 557 710 11	. E. WINNE DOM		UTPLIT	(MONITOR)
	. 2.0 007 77								(
	,	< IC >						< JUMPER RESIS	TOR >		
	0 700 461 65	10 1 100000						0110.00			
Z1		IC LM2577-ADJ				JR101	1-216-296-91		0		
Z2	8-759-520-49	IC PUSURVZI				JR102	1-216-296-91	PHORI	0		

RE-32 RP-228

	Ref. No.	Part No.	<u>Description</u>			Remark	Ref. No.	Part No.	Description			Remark	
	JR103	1-216-296-91	SHORT	0			C772	1-164-156-11	CERAMIC CHIP	0.1uF		25V	
	JR104	1-216-296-91		0			C773		CERAMIC CHIP	0.1uF 0.47uF		10V	
	JR105	1-216-296-91		0			0,,0	1 110-015-11	CENAIMO OTTI	0.47 ui		100	
							C774	1-164-360-11	CERAMIC CHIP	0.1uF		16V	
	JR106	1-216-296-91	SHORT	0			C775	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
	JR107	1-216-296-91	SHORT	0			C776	1-162-923-11	CERAMIC CHIP	47PF	5%	50V	
	JR108	1-216-296-91		0			C777	1-162-923-11	CERAMIC CHIP	47PF	5%	50V	
	JR109	1-216-296-91		0			C778	1-162-974-11	CERAMIC CHIP	0.01uF		50V	
	JR110	1-216-296-91	SHORT	0									
		4 040 000 04		,			C779		CERAMIC CHIP	0.01uF		50V	
	JR111	1-216-296-91		0			C780		CERAMIC CHIP	0.01uF		50V	
	JR112	1-216-296-91		0			C781		CERAMIC CHIP	0.01uF		50V	
	JR113 JR114	1-216-296-91 1-216-296-91		0			C782		CERAMIC CHIP	0.1uF	000/	25V	
	JR115	1-216-296-91		0			C783	1-130-201-11	TANTALUM CHIP	TOUF	20%	4V	
	011110	1 210 230 31	OHOITI	U			C784	1-162-070-11	CERAMIC CHIP	0.01uF	10%	25V	
	JR116	1-216-296-91	SHORT	0			C786	1-162-974-11		0.01uF	10 /0	50V	
	JR117	1-216-296-91		0			C788		TANTALUM CHIP		20%	10V	
	JR118	1-216-296-91		0			C789		CERAMIC CHIP	0.01uF	20 /0	50V	
	JR119	1-216-296-91	SHORT	0			C791		CERAMIC CHIP	0.01uF		50V	
	JR120	1-216-296-91	SHORT	0								•••	
							C792	1-119-750-11	TANTALUM CHIP	22uF	20%	6.3V	
	JR121	1-216-296-91		0			C793		CERAMIC CHIP	0.1uF	10%	16V	
		1-216-296-91		0			C794		CERAMIC CHIP	0.1uF	10%	16V	
	JR123	1-216-296-91	SHORT	0			C795	1-128-004-11		10uF	20%	16V	
							C796	1-162-974-11	CERAMIC CHIP	0.01uF		50V	
			< RESISTOR >				0707	4 407 000 04					
	Dios	1 016 005 01	CHODE	^			C797		CERAMIC CHIP	0.1uF	10%	16V	
	R105	1-216-295-91		0 75	E0/	4 /4 0) 44	C798		CERAMIC CHIP	0.01uF	5 0/	50V	
	R106 R107	1-216-022-00 1-216-022-00		75 75	5% 5%	1/10W 1/10W	C799		CERAMIC CHIP	150PF	5%	50V	
	R108	1-216-022-00		75 75	5% 5%	1/10W	C803 C811		CERAMIC CHIP	150PF	5%	50V	
	R109	1-216-295-91		0	J /0	17 10 44	0011	1-113-019-11	GENAIVIIG GRIP	0.47uF		10V	
	11100	7 210 200 01	OHOTH	v			C813	1-162-974-11	CERAMIC CHIP	0.01uF		50V	
	R110	1-216-295-91	SHORT	0			C814		CERAMIC CHIP	0.01uF	10%	25V	
		1-216-295-91		Ō			C815		CERAMIC CHIP	0.001uF	10%	50V	
		1-216-295-91		Ō			C816		CERAMIC CHIP	0.001uF	10%	50V	
		1-216-295-91	SHORT	0			C817		TANTALUM CHIP		20%	10V	
	R114	1-216-295-91	SHORT	0									
				*			C818	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	
	R115	1-216-295-91	SHORT	0			C819		CERAMIC CHIP	0.01uF		50V	
							C821		CERAMIC CHIP	0.1uF		16V	
			< SWITCH >				C822		CERAMIC CHIP	0.1uF		16V	
	0404	4 570 074 44	OMITOU OLIDE	(0) (1) (0)			C823	1-164-360-11	CERAMIC CHIP	0.1uF		16V	
	S101	1-5/0-9/4-11	SWITCH, SLIDE (SYNC)			0004	4 400 070 44	OED AMIO OLUB	0.04 F	400/	05)/	
•							C824		CERAMIC CHIP	0.01uF	10%	25V	
*		A_7067_122_A	RP-228 BOARD,	COMDIETE	/DCD-20	MD)	C825 C826		CERAMIC CHIP	470PF	5%	50V	
*			RP-228 BOARD, (C827		CERAMIC CHIP	0.01uF 0.01uF		50V 50V	
		A 7007 120 A	***********			ו יִשׁוּאוּ	C828		CERAMIC CHIP	0.01uF		50V	
				(Re	f.No. 3.00	00 Series)	0020	1 102 374 11	OLIMANIO OIII	0.0141		300	
						30,00,100,	C829	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	
		1-776-149-11	CABLE, FLEXIBLE	FLAT 30P			C830		CERAMIC CHIP	0.1uF		16V	
			CABLE, FLEXIBLE		-245)		C831		TANTALUM CHIP		20%	6.3V	
				,	•		C832		CERAMIC CHIP	0.1uF		16V	
			< CAPACITOR >				C833	1-162-974-11	CERAMIC CHIP	0.01uF		50V	
			CERAMIC CHIP	0.01uF	10%	25V	C834	1-162-974-11		0.01uF		50V	
			CERAMIC CHIP	0.01uF		50V	C835	1-162-974-11		0.01uF		50V	
			CERAMIC CHIP		10%	25V	C836	1-162-974-11	· ·	0.01uF		50V	
			CERAMIC CHIP		10%	50V	C837	1-162-970-11		0.01uF	10%	25V	
	C703	1-164-174-11	CERAMIC CHIP	0.0082uF	10%	25V	C838	1-162-913-11	CERAMIC CHIP	8PF	0.5PF	50V	
	C704	1_162_067_11	CERAMIC CHIP	0.0033uF	10%	50V	C839	1-162-913-11	CEDAMIC CHID	8PF	0 EDE	EOV.	
			CERAMIC CHIP	0.0033uF		50V 50V	C841	1-162-913-11		47PF	0.5PF	50V	
				0.0039uF		50V 50V	C842	1-162-923-11		4/PF 0.1uF	5%	50V 16V	
			CERAMIC CHIP	0.0059ur	1070	16V	C843	1-164-677-11		0.1ur 0.033uF	10%	16V 16V	
			CERAMIC CHIP	0.1uF		16V	C844	1-164-677-11		0.033uF	10%	16V	
							50.1			5,000ui	1070		
	C763	1-164-360-11	CERAMIC CHIP	0.1uF		16V	C845	1-164-357-11	CERAMIC CHIP	1000PF	5%	50V	
	C770		TANTALUM CHIP	10uF	20%	4V	C847	1-162-974-11		0.01uF		50V	
			CERAMIC CHIP	0.01uF		50V	C848		TANTALUM CHIP		20%	10V	

											1 -220
Ref. No.	Part No	Description			Damanda	Def No	D t. N.	.			
	Part No.	<u>Description</u>			Remark	Ref. No.	<u>Part No.</u>	<u>Description</u>			<u>Remark</u>
C850		CERAMIC CHIP			50V	Q773		TRANSISTOR			
C853	1-162-974-11	CERAMIC CHIP	0.01uF		50V	Q774		TRANSISTOR			
C854	1-104-851-11	TANTALUM CHI	P 10uF	20%	10V	Q775 Q776		TRANSISTOR TRANSISTOR			
C855	1-104-851-11	TANTALUM CHI	P 10uF	20%	10V	Q777		TRANSISTOR		เาบธ์(1	IX).5U
C857		CERAMIC CHIP		5%	50V		0 720 007 02	THANOIOTOR	200221	oo-an (11,30
C859		CERAMIC CHIP			50V	Q778	8-729-037-52	TRANSISTOR	2SD221	6J-QR (1	TX).SO
C861.	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	Q779		TRANSISTOR	2SD221		
0000	1 100 070 44	OFDAMA OUR	0.04.5	400/		Q784	8-729-037-53	TRANSISTOR	2SB146	2J-QR (T	X).SO
C862 C874		CERAMIC CHIP	0.01uF 0.01uF	10%	25V			D=010m0m			
C875		TANTALUM CHI		20%	50V 6.3V			< RESISTOR >	•		
	1 100 200 11	TANTALOW OTT	i ioui	20 /0	0.34	R117	1-216-807-11	METAL CHIP	68	5%	1/16W
		< CONNECTOR:	>			R118	1-216-833-91		10K	5%	1/16W
						R120	1-216-864-11		0	5%	1/16W
CN101	1-750-345-11	CONNECTOR, FI	FC/EPC (ZIF)	30P		R121		METAL CHIP		5%	1/16W
CN102	1-750-345-11	CONNECTOR, FI	C/EPC (ZIF)	30P		R122	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
CN103 CN771	1-750-345-11	CONNECTOR, FI	C/EPC (ZIF)	30P		D400	4 040 004 44				
CN775		CONNECTOR, FI		ADD 20E		R123	1-216-864-11	METAL CHIP	0	5%	1/16W
011770	1 700 000 41	OOMNEOTON, D	UAND IU DO	AND ZUF		R124	1-216-864-11	METAL CHID	0	5%	DSR-20MD)
		< DIODE >				11127	1-210-004-11	WILTAL CHIP	U		1/16W SR-20MDP)
						R137	1-216-807-11	METAL CHIP	68	5%	1/16W
D771		DIODE MA111				R138	1-216-833-91		10K	5%	1/16W
D772		DIODE MA111-				R143	1-216-833-91	RES, CHIP	10K	5%	1/16W
D773		DIODE KV1470									
D774 D775		DIODE 1SS351 DIODE 1SS351				R144	1-216-831-11		6.8K	5%	1/16W
	0-119-032-21	ומספבו ומספטו	-10			R147 R206	1-216-864-11 1-216-821-11		0	5%	1/16W
D791	8-719-073-01	DIODE MA111-	TX			R308	1-216-821-11		1K 1K	5% 5%	1/16W 1/16W
						R309	1-216-821-11		1K	5%	1/16W
		< FILTER >							***	0 /0	17 1000
						R310	1-216-821-11	METAL CHIP	1K	5%	1/16W
FL770	1-411-951-21	DELAY LINE, LC	(23NS)			R311	1-216-821-11		1,K	5%	1/16W
FL771	1-233-/34-21	FILTER, LOW PA	SS			R312	1-216-821-11		1K	5%	1/16W
		< IC >				R313	1-216-821-11		1K	5%	1/16W
		10 /				R314	1-216-821-11	METAL UHIP	1K	5%	1/16W
10770	8-759-445-93	IC AK6440AM-I	2			R315	1-216-864-11	METAL CHIP	0 .	5%	1/16W
IC771	8-759-426-25	IC MB88346LP	FV-G-BND-E	R		R316	1-216-833-91		10K	5%	1/16W
IC772		IC CXD2302Q-1				R701	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
IC773		IC CXA1762Q-T				R702	1-216-829-11		4.7K	5%	1/16W
IC774	8-752-386-38	IC CXD3105R-7	6			R703	1-216-809-11	METAL CHIP	100	5%	1/16W
IC775	8-752-074-50	IC CXA2023R-T	۸.	•		D704	1 010 010 11	METAL OLUB	400		
IC777		IC CXA2018Q-T				R704 R705	1-216-810-11 1-216-825-11		120	5%	1/16W
IC791		IC TK11228BM				R706	1-216-829-11		2.2K 4.7K	5% 5%	1/16W 1/16W
						R707	1-216-809-11		100	5%	1/16W
		< COIL >				R708	1-216-810-11		120	5%	1/16W
	4 44 4 000 44	MALIOTOR									
L105 L770	1-414-398-11 1-414-398-11		10uH		ĺ	R770	1-216-845-11		100K	5%	1/16W
L773	1-414-398-11		10uH 10uH			R772	1-216-296-91		0		
L774	1-414-398-11		10uH			R774 R776	1-216-841-11 1-216-818-11		47K	5%	1/16W
L776	1-414-398-11		10uH			R779	1-216-847-11		560 150K	5% 5%	1/16W 1/16W
							. 2.001. 11	WIL ITTE OTHE	10010		1/1044
L779		INDUCTOR CHIP	0.47uH			R780	1-216-837-11	METAL CHIP	22K	5%	1/16W
L781	1-412-963-11		100uH			R782	1-216-833-91		10K	5%	1/16W
L782	1-412-963-11		100uH			R783	1-216-833-91		10K	5%	1/16W
L783 L784	1-414-398-11		10uH			R786	1-216-817-11		470	5%	1/16W
L/04	1-414-398-11	INDUCTOR	10uH			R787	1-202-924-11	RES, CHIP	240	5%	1/16W
L789	1-414-398-11	INDUCTOR	10uH			R788	1-202-924-11	DEC CHID	240	E0/	4 /4 CM
			, , , , ,			R789	1-216-824-11		1.8K	5% 5%	1/16W 1/16W
		< TRANSISTOR >				R790	1-216-841-11		47K	5%	1/16W
						R791	1-216-815-11	METAL CHIP	330	5%	1/16W
	8-729-037-52		2SD2216J-			R792	1-216-814-11		270	5%	1/16W
	8-729-037-52		2SD2216J-		50	D700	4 040 000 11				
	8-729-013-04 8-729-013-04		2SC4851-T			R793	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
	8-729-037-72		UN9211J- (R794 R796	1-216-816-11 1-216-809-11		390	5% 5%	1/16W
			3.1321 TO (R797	1-216-827-11		100 3.3K	5% 5%	1/16W 1/16W
							11		0.0K	J /0	1/ 1000

RP-228	RS-78	VA-102

Ref. No.	Part No.	Description			<u>Remark</u>	Ref. No.	Part No.	Description			<u>Remark</u>
R798	1-216-815-11	METAL CHIP	330	5%	1/16W			< 10 >			
R799 R800	1-216-825-11 1-216-833-91	METAL CHIP RES, CHIP	2.2K 10K	5% 5%	1/16W 1/16W	IC002	8-759-521-15	IC MAX232CW	E-TE-2		
R801	1-216-833-91		10K	5%	1/16W			< COIL >			
R802 R804	1-216-841-11 1-216-839-11	METAL CHIP METAL CHIP	47K 33K	5% 5%	1/16W 1/16W	L001	1_/112_020_11	INDUCTOR CHIP	10 U		
1100-1	1 210 000 11	WEIAE OIII	OOK	3 /0	17 1000	2001	1-412-023-11	INDUOTOR OTH	TOUT		
R806	1-216-821-11	METAL CHIP	1K	5%	1/16W	١.		1/4 400 BOABB			
R808 R810	1-216-821-11 1-216-837-11	METAL CHIP METAL CHIP	1K 22K	5% 5%	1/16W 1/16W	*		VA-102 BOARD, VA-102 BOARD.			
R812	1-216-837-11	METAL CHIP	22K	5%	1/16W		M-1001-201-M	*********			OIVIDE)
R814	1-216-853-11	METAL CHIP	470K	5%	1/16W				(R	ef.No. 1,6	000 Series)
R815	1-216-853-11	METAL CHIP	470K	5%	1/16W			< CAPACITOR >			
R818	1-216-837-11	METAL CHIP	22K	5%	1/16W]					
R819	1-216-839-11	METAL CHIP	33K	5%	1/16W	C051		CERAMIC CHIP	0.47uF		10V
R820	1-216-803-11 1-216-834-11	METAL CHIP	33	5%	1/16W	C052		CERAMIC CHIP	220PF	5%	50V
R822	1-210-034-11	METAL CHIP	12K	5%	1/16W	C053 C055		CERAMIC CHIP	0.47uF 0.1uF		10V 16V
R824	1-216-821-11	METAL CHIP	1K	5%	1/16W	C056		CERAMIC CHIP	0.1uF		16V 16V
R825	1-216-841-11	METAL CHIP	47K	5%	1/16W	0000	1 101 000 11	OLI II III III OI III	o. rui		104
R826	1-216-839-11		33K	5%	1/16W	C057	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
R827	1-216-821-11		1K	5%	1/16W	C058	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
R830	1-216-831-11	METAL CHIP	6.8K	5%	1/16W	C059	1-124-778-00		22uF	20%	6.3V
						C101	1-128-004-11		10uF	20%	16V
R832 R843	1-216-807-11 1-216-822-11		68	5%	1/16W	C102	1-164-360-11	ÇERAMIC CHIP	0.1uF		16V
R844	1-216-822-11	METAL CHIP	1.2K 22K	5% 5%	1/16W 1/16W	C103	1-164-260-11	CERAMIC CHIP	0.1uF		16V
R849	1-218-837-11	METAL CHIP	390	0.5%	1/16W	C103	1-164-360-11		0.1uF		16V
R850	1-218-835-11	METAL CHIP	330	0.5%	1/16W	C105		CERAMIC CHIP	0.1uF		16V
						C106		CERAMIC CHIP	0.1uF		16V
R851	1-218-835-11	METAL CHIP	330	0.5%	1/16W	C107	1-164-360-11	CERAMIC CHIP	0.1uF		16V
R852	1-218-837-11	METAL CHIP	390	0.5%	1/16W	2122					
R858	1-216-816-11	METAL CHIP	390	5%	1/16W	C108	1-164-360-11	CERAMIC CHIP	0.1uF		16V
•						C109 C110	1-164-360-11	CERAMIC CHIP	0.1uF 0.1uF		16V 16V
*	A-7073-472-A	RS-78 BOARD, C	OMPLETE			C111	1-164-360-11		0.1uF		16V
		******			•	C201	1-124-778-00		22uF	20%	6.3V
			(R	ef.No. 6,0	000 Series)		2 - 1 Dec 15				
		OADAGITOD				C202	1-124-778-00		22uF	20%	6.3V
		< CAPACITOR >				C203 C204		CERAMIC CHIP	0.1uF	000/	16V 6.3V
C001	1-164-346-11	CERAMIC CHIP	1uF		16V	C204	1-126-206-11	CERAMIC CHIP	100uF 0.01uF	20% 10%	25V
C002			1uF		16V	C206		CERAMIC CHIP	0.01uF	10%	25V 25V
C003		CERAMIC CHIP	1uF		16V		, 102 010 11		0.0141	1070	201
C004	1-164-346-11	CERAMIC CHIP	1uF		16V	C207	1-162-958-11	CERAMIC CHIP	270PF	5%	50V
C005	1-164-346-11	CERAMIC CHIP	1uF		16V	C208		CERAMIC CHIP	0.1uF		16V
0000	4 404 000 44	OFDANIO OUID	0.4		4004	C209		CERAMIC CHIP	0.1uF	5 0/	16V
C006 C007	1-164-360-11	CERAMIC CHIP	0.1uF 100uF	20%	16V 6.3V	C210 C211	1-162-923-11	CERAMIC CHIP	47PF 22uF	5% 20%	50V 6.3V
0007	1-120-200-11	LLLO1 OIIII	10001	2070	0.50	0211	1-124-770-00	ELLOT OTHE	22ui	20,76	0.57
		< CONNECTOR >				C212	1-124-778-00	ELECT CHIP	22uF	20%	6.3V
						C213	1-128-003-11		22uF	20%	4V
CN001		CONNECTOR, FFO			0.0000	C214	1-128-003-11		22uF	20%	4V
CN002	1-565-388-21	CONNECTOR, D-	SOR AL (KI	EMOTE K	S-232C)	C215		CERAMIC CHIP	0.01uF	10%	25V
		< DIODE >				C216	1-128-003-11	ELECT OHIP	22uF	20%	4V
						C217	1-164-360-11	CERAMIC CHIP	0.1uF		16V
D001		DIODE MA3200				C218	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
D002		DIODE MA3200				C219		CERAMIC CHIP	0.01uF	10%	25V
D003		DIODE MA3200	The second second			C220		CERAMIC CHIP	0.01uF	10%	25V
D004 D005		DIODE MA32001				C221	1-102-915-11	CERAMIC CHIP	10PF	0.5PF	50V
, 2000	3 7 13 00Z∓13	STODE WINOZUU				C223	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V
		< FERRITE BEAD	>			C224	1-126-206-11		100uF	20%	6.3V
					.	C225		CERAMIC CHIP	0.01uF	10%	25V
FB001	1-500-241-22		0uH		4	C226	1-124-778-00		22uF	20%	6.3V
FB002	1-500-241-22		OuH			C227	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
FB003 FB004	1-500-241-22 1-500-241-22		OuH OuH			C228	1-164-360-11	CERAMIC CHIP	0.1uF	;	16V
FB005	1-500-241-22		0uH			C229	1-128-007-11		2.2uF	20%	35V

											L	
Re	<u>f. No.</u>	Part No.	Description			Remark	Ref. No.	Part No.	<u>Description</u>			Remark
	C230 C231		CERAMIC CHIP	0.01uF 4.7uF	20%	50V 25V	C291	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V R-20MDP)
	C232		CERAMIC CHIP	4.7uF	2070 .	16V	C292	1-126-205-11	ELECT CHIP	47uF	20%	6.3V
							C293	1-126-205-11	ELECT CHIP	47uF	20%	6.3V
	C233	1-126-205-11		47uF	20%	6.3V	C294		CERAMIC CHIP	0.01uF	10%	25V
	C234		CERAMIC CHIP	0.1uF		16V	C295	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
	C235	1-124-778-00		22uF	20%	6.3V						
	C236	1-128-006-11		4.7uF	20%	25V	C297	1-128-003-11		22uF	20%	4V
	C237	1-162-9/0-11	CERAMIC CHIP	0.01uF	10%	25V	C300	1-164-360-11	CERAMIC CHIP	0.1uF	100	16V
	0000	1 104 770 00	CI COT OUID	00	000/	c ov	0004	1 100 007 11	OFDAMIO OUID	40000		R-20MDP)
	C238 C239	1-124-778-00	CERAMIC CHIP	22uF 0.1uF	20%	6.3V 16V	C301	1-162-92/-11	CERAMIC CHIP	100PF	5%	50V R-20MDP)
	C239		CERAMIC CHIP	0.1uF		16V 16V	C304	1-126-205-11	ELECT CHIP	47uF	20%	6.3V
	C241	1-128-004-11		10uF	20%	16V	C305	1-126-205-11		47uF	20%	6.3V
	C242		CERAMIC CHIP	0.1uF	2070	16V	1				2070	0.01
							C307	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
	C243	1-164-360-11	CERAMIC CHIP	0.1uF		16V	C308		CERAMIC CHIP	0.01uF	10%	25V
	C244	1-164-360-11	CERAMIC CHIP	0.1uF		16V	C309	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C245	1-164-360-11	CERAMIC CHIP	0.1uF		16V					(DS	R-20MDP)
	C246		CERAMIC CHIP	0.001uF	10%	50V	C311	1-128-004-11	ELECT CHIP	10uF	20%	16V
1	C247	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V					(DS	R-20MDP)
							C312	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C248		CERAMIC CHIP	0.01uF	10%	25V					(มร	R-20MDP)
	C249	1-128-006-11	ELECT CHIP	4.7uF	20%	25V	0010	1-126-206-11	EL FOT CUID	100	000/	0.01
	C250 C251		CERAMIC CHIP	0.1uF 6PF	0.5PF	16V 50V	C313 C314	1-126-206-11		100uF 100uF	20% 20%	6.3V 6.3V
	0201	1-102-911-11	CENAIVIIC CHIP	UFF		SR-20MD)	C401	1-126-205-11		47uF	20%	6.3V
	C251	1-162-910-11	CERAMIC CHIP	5PF	0.25PF		C402		CERAMIC CHIP	0.01uF	10%	25V
	0201	1 102 010 11	OLIVIANIO OTIM	0		R-20MDP)	C403	1-128-003-11		22uF	20%	4V
					•	,						
	C252	1-164-360-11	CERAMIC CHIP	0.1uF		16V	C404	1-128-003-11		22uF	20%	4V
	C253	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	C405	1-128-003-11	ELECT CHIP	22uF	20%	4V
	C254	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C406	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
	C255	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C407		CERAMIC CHIP	0.01uF	10%	25V
İ	C256	1-164-360-11	CERAMIC CHIP	0.1uF		16V	C408	1-162-970-11	CERAMIC CHIP	0.01 u F	10%	25V
	C257	1-128-003-11	ELECT CHIP	22uF	20%	4V	C409	1-128-003-11	ELECT CHIP	22uF	20%	4V
	C258	1-128-003-11		22uF	20%	4V	C410	1-128-007-11		2.2uF	20%	35V
	C260			100PF	5%	50V	C411	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
	C261	1-162-919-11	CERAMIC CHIP	22PF	5%	50V	C412	1-126-205-11		47uF	20%	6.3V
	C262	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C413	1-162-970-11		0.01uF	10%	25V
	C264		CERAMIC CHIP	0.1uF		16V	C414	1-124-778-00		22uF	20%	6.3V
	C265		CERAMIC CHIP	0.001uF	10%	50V	C415	1-128-003-11		22uF	20%	4V
	C266		CERAMIC CHIP	1uF		10V	C416	1-128-003-11		22uF	20%	4V
	C268 C269		CERAMIC CHIP	0.47uF 0.1uF		10V 16V	C417 C418		CERAMIC CHIP	330PF	5%	50V
,	0203	1-104-300-11	OLITAINIO GITIF	o. Tui		100	0410	1-102-919-11	CERAMIC CHIP	22PF	5%	50V
1	C270	1-115-156-11	CERAMIC CHIP	1uF		10V	C419	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
	C271	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C420	1-115-156-11	CERAMIC CHIP	1uF		10V
	C272	1-164-360-11	CERAMIC CHIP	0.1uF		16V	C421	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
	C273		CERAMIC CHIP	0.1uF		16V	C422		CERAMIC CHIP	0.056uF	10%	25V
(C274	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V	C423	1-163-139-00	CERAMIC CHIP	820PF	5%	50V
,	0275	1-128-006-11	EI ECT CHID	4.7uF	20%	25V	C425	1-169-070-11	CERAMIC CHIP	0.01uF	10%	25V
	G276	1-126-206-11		100uF	20%	6.3V	C426		CERAMIC CHIP	0.01ur	10%	25V 25V
	C277		CERAMIC CHIP	0.047uF	10%	16V	C427		CERAMIC CHIP	0.022ui	10%	25V
	0278		CERAMIC CHIP	0.01uF	10%	25V	C429		CERAMIC CHIP	1uF	1070	10V
	0279	1-128-006-11		4.7uF	20%	25V	C430		CERAMIC CHIP	1uF		10V
	C280	1-128-003-11		22uF	20%	4V	C433		CERAMIC CHIP	1uF		10V
	0281		CERAMIC CHIP	6PF	0.5PF	50V	C434		CERAMIC CHIP	1uF		10V
	2282		CERAMIC CHIP	0.001uF	10%	50V	C435		CERAMIC CHIP	1uF	100/	10V
	283		CERAMIC CHIP	10PF	0.5PF	50V	C436		CERAMIC CHIP	0.01uF	10%	25V
	C284	1-104-300-11	CERAMIC CHIP	0.1uF		16V	C437	1-128-003-11	ELECT CHIP	22uF	20%	4V
(285	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C438	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
	C286		CERAMIC CHIP	0.1uF		16V	C441		CERAMIC CHIP	0.01uF	10%	25V
	2287	1-126-206-11		100uF	20%	6.3V	C443		CERAMIC CHIP	0.01uF	10%	25V
	2288		CERAMIC CHIP	0.001uF	10%	50V	C444	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
(2290	1-128-003-11	ELECT CHIP	22uF	20%	4V	C445	1-115-156-11	CERAMIC CHIP	1uF		10V

						m		Б. 1.11			Damada
Ref. No.	Part No.	<u>Description</u>			Remark	Ref. No.	Part No.	Description			<u>Remark</u>
C446	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V					=0/	5017
C447	1-164-360-11	CERAMIC CHIP	0.1uF		16V	C612	1-162-920-11	CERAMIC CHIP	27PF	5%	50V
C448	1-124-778-00		22uF	20%	6.3V	0040	4 400 004 44	OCDANIO CUID	2205	5%	SR-20MD) 50V
C449		CERAMIC CHIP	0.01uF	10%	25V	C612	1-162-921-11	CERAMIC CHIP	33PF		R-20MDP)
C450	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C613	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V
0454	1 100 070 11	CERAMIC CHIP	0.01uF	10%	25V	C614	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V 50V
C451 C453	1-162-970-11 1-164-360-11	CERAMIC CHIP	0.01uF	1076	16V	C615		CERAMIC CHIP	15PF	5%	50V
C453	1-162-970-11	CERAMIC CHIP	0.7uF	10%	25V	0013	1-102-317-11	OLIMANIO OIII	1011		SR-20MD)
C455		CERAMIC CHIP	0.01uF	10%	25V 25V					(5)	orr zowib,
C456		CERAMIC CHIP	0.01uF	10%	25V	C616	1-124-778-00	ELECT CHIP	22uF	20%	6.3V
0400	1 102 010 11	OLI II MAITO OTTI	0.0141	1070		C618	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C457	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C619	1-124-778-00	ELECT CHIP	22uF	20%	6.3V
C459	1-115-156-11	CERAMIC CHIP	1uF		10V	C621	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C460	1-124-778-00		22uF	20%	6.3V	C624	1-164-360-11	CERAMIC CHIP	0.1uF		16V
C461		CERAMIC CHIP	0.01uF	10%	25V						
C462	1-124-778-00	ELECT CHIP	22uF	20%	6.3V	C628	1-164-360-11	CERAMIC CHIP	0.1uF		16V
						C629	1-164-230-11	CERAMIC CHIP	220PF	5%	50V
C463		CERAMIC CHIP	0.01 uF	10%	25V	C630	1-128-004-11	ELECT CHIP	10uF	20%	16V
C464	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C631	1-164-360-11	CERAMIC CHIP	0.1uF		16V
C465	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C651	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C466	1-124-778-00		22uF	20%	6.3V					000/	401
C467	1-126-205-11	ELECT CHIP	47uF	20%	6.3V	C652	1-128-004-11	ELECT CHIP	10uF	20%	16V
	4 404 000 44	0504440 01110	0.4.5		4014	C653	1-162-909-11	CERAMIC CHIP	4PF	0.25PF	
C468	1-164-360-11	CERAMIC CHIP	0.1uF	000/	16V	0054	4 400 000 44	CL COT OLUD	20		R-20MDP) 4V
C469	1-124-778-00		22uF	20%	6.3V	C654	1-128-003-11	ELECT CHIP ELECT CHIP	22uF 10uF	20% 20%	4V 16V
C470	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V 16V	C655 C656	1-128-004-11 1-162-927-11	CERAMIC CHIP	100F 100PF	20% 5%	50V
C471	1-164-360-11	CERAMIC CHIP ELECT CHIP	0.1uF 22uF	20%	6.3V	6000	1-102-927-11	CENAIVIIC CHIP	TOUFF	J /0	201
C472	1-124-778-00	ELECT ONIF	ZZUF	20 70	0.57	C657	1-162-928-11	CERAMIC CHIP	120PF	5%	50V
C473	1-126-206-11	ELECT CHIP	100uF	20%	6.3V	C658	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C473	1-126-205-11		47uF	20%	6.3V	C659	1-126-205-11	ELECT CHIP	47uF	20%	6.3V
C475	1-124-778-00		22uF	20%	6.3V	C660	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C476	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C662	1-128-007-11	ELECT CHIP	2.2uF	20%	35V
C477	1-162-909-11	CERAMIC CHIP	4PF	0.25PF			, ,=== ===,				
· · · ·					R-20MDP)	C663	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
				,		C664	1-126-205-11	ELECT CHIP	47uF	20%	6.3V
C478	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C665	1-164-237-11	CERAMIC CHIP	16PF	5%	50V
C479	1-164-237-11	CERAMIC CHIP	16PF	5%	50V	C666	1-162-919-11		22PF	5%	50V
C480	1-126-206-11	ELECT CHIP	100uF	20%	6.3V	C667	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C481	1-162-919-11	CERAMIC CHIP	22PF	5%	50V						
C482	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C670		CERAMIC CHIP	0.01uF	10%	25V
		.				C671		CERAMIC CHIP	1uF	50 /	10V
C483		CERAMIC CHIP	0.1uF	=0.	16V	C672		CERAMIC CHIP	33PF	5%	50V
C484		CERAMIC CHIP	33PF	5%	50V	C673		CERAMIC CHIP	0.056uF 22PF	10% 5%	25V 50V
C485	1-162-919-11		22PF	5%	50V 16V	C674	1-102-919-11	CERAMIC CHIP	2277	J 70	301
C486		CERAMIC CHIP	0.1uF 10uF	20%	16V 16V	C675	1_163_130_00	CERAMIC CHIP	820PF	5%	50V
C487	1-128-004-11	ELECT ONLY	TOUF	2070	100	C676		CERAMIC CHIP	0.022uF	10%	25V
C489	1-162-920-11	CERAMIC CHIP	27PF	5%	50V	C678	1-128-003-11		22uF	20%	4V
C490	i i	CERAMIC CHIP	1PF	0.25PF		C680		CERAMIC CHIP	0.01uF	10%	25V
C491		CERAMIC CHIP	0.01uF	10%	25V	C681	1-126-206-11		100uF	20%	6.3V
C492	1-162-915-11		10PF	0.5PF	50V						
C493	1-128-004-11		10uF	20%	16V	C682	1-164-360-11	CERAMIC CHIP	0.1uF		16V
0.00	20 00					C683	1-126-927-11	ELECT	1000uF	20%	6.3V
C494	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C701	1-124-778-00	ELECT CHIP	22uF	20%	6.3V
C496	1-128-007-11		2.2uF	20%	35V	C702	1-124-778-00		22uF	20%	6.3V
C497	1-164-360-11		0.1uF		16V	C703	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
C498	1-128-003-11	ELECT CHIP	22uF	20%	4V						
C500	1-164-360-11	CERAMIC CHIP	0.1uF		16V	C704	1-164-360-11	CERAMIC CHIP	0.1uF		16V
						C705	1-162-923-11		47PF	5%	50V
C501	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C706	1-164-360-11	CERAMIC CHIP	0.1uF		16V
C503		CERAMIC CHIP	0.01uF	10%	25V	C707		CERAMIC CHIP	0.1uF	0001	16V
C505		CERAMIC CHIP	0.01uF	10%	25V	C708	1-128-004-11	ELECT CHIP	10uF	20%	16V
C506	1-128-004-11		10uF	20%	16V	0700	4 400 004 41	ELECT OUTD	105	000/	16/1
C601	1-124-778-00	ELECT CHIP	22uF	20%	6.3V	C709	1-128-004-11		10uF	20%	16V
0000	4 400 070 11	OFDAMIO OUE	0.04	100/	0511	C710		CERAMIC CHIP	22PF	5% 5%	50V 50V
C602		CERAMIC CHIP	0.01uF	10%	25V	C711		CERAMIC CHIP CERAMIC CHIP	22PF 0.1uF	J 70	16V
C603	1-128-004-11		10uF 1uF	20%	16V 10V	C713 C714		CERAMIC CHIP	0.1uF		16V
C604 C606	1-115-156-11	CERAMIC CHIP	10r 10uF	20%	16V	0/14	1-10 4-000- 11	OLITAINIO OTIIP			104
C608	1-128-004-11		10uF 10uF	20% 20%	16V 16V	C715	1-164-380-11	CERAMIC CHIP	300PF	5%	50V
0000	1-120-004-11	LLLUI UIIIF	· oui	LU /0		, 0,10	1 101 000 11				

_	Ref. No.	Part No.	<u>Description</u>			Remark	R	ef. No.	Part No.	Description			Remark
<u>r</u>							1					400/	
	C716		CERAMIC CHIP	0.1uF		16V	1	C855		CERAMIC CHIP	0.001uF	10%	50V
	C717		CERAMIC CHIP	300PF	5%	50V .	1	C856		CERAMIC CHIP	0.01uF	10%	25V
	C719		CERAMIC CHIP	0.1uF		16V		C858		CERAMIC CHIP	0.1uF		16V
	C720	1-164-360-11	CERAMIC CHIP	0.1uF		16V	1	C859	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C721	1-162-923-11	CERAMIC CHIP	47PF	5%	50V	-	C860	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C722	1-164-360-11	CERAMIC CHIP	0.1uF		16V		C861		CERAMIC CHIP	0.1uF		16V
	C723	1-124-778-00	ELECT CHIP	22uF	20%	6.3V		C862	1-126-204-11	ELECT CHIP	47uF	20%	16V
	C724		CERAMIC CHIP	300PF	5%	50V		C863	1-126-400-11	ELECT	22uF	20%	35V
	C725		CERAMIC CHIP	0.1uF		16V	-	C864	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C726	1-164-389-11	CERAMIC CHIP	300PF	5%	50V		C865	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C727	1-164-360-11	CERAMIC CHIP	0.1uF		16V		C866	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
	C728	1-162-923-11	CERAMIC CHIP	47PF	5%	50V	1	C867	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C729		CERAMIC CHIP	0.1uF		16V		C869	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C730		CERAMIC CHIP	0.1uF		16V		C870	1-128-013-11	ELECT CHIP	1uF	20%	50V
	C731	1-164-360-11	CERAMIC CHIP	0.1uF		16V		C871	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
	C732	1-124-778-00	ELECT CHIP	22uF	20%	6.3V		C872	1-162-975-11	CERAMIC CHIP	24PF	5%	50V
	C733	1-164-360-11	CERAMIC CHIP	0.1uF		16V		C874	1-126-204-11	ELECT CHIP	47uF	20%	16V
	C734	1-128-007-11		2.2uF	20%	35V	ŀ	C875	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C735	1-128-007-11		2.2uF	20%	35V		C876	1-164-360-11	CERAMIC CHIP	0.1uF		16V
						401/		0077	4 464 007 44	OED ANAIO OLUB	۵.0005	4.00/	0514
	C736		CERAMIC CHIP	0.1uF	F0/	16V		C877		CERAMIC CHIP	0.022uF	10% 20%	25V 6.3V
	C737		CERAMIC CHIP	300PF	5%	50V		C881	1-126-927-11		1000uF	20%	
	C738		CERAMIC CHIP	0.1uF	F 0/	16V		C883		CERAMIC CHIP	0.1uF	E0/	16V
	C739		CERAMIC CHIP	300PF	5%	50V		C886		CERAMIC CHIP	33PF	5%	50V
	C740	1-164-360-11	CERAMIC CHIP	0.1uF		16V		C887	1-162-921-11	CERAMIC CHIP	33PF	5%	50V
	C741	1-124-778-00	ELECT CHIP	22uF	20%	6.3V		C888	1-128-004-11	ELECT CHIP	10uF	20%	16V
	C742	1-164-389-11	CERAMIC CHIP	300PF	5%	50V	ı	C889	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C743	1-164-360-11	CERAMIC CHIP	0.1uF		16V	1	C890	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C744	1-164-389-11	CERAMIC CHIP	300PF	5%	50V	İ	C891	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
	C745	1-164-360-11	CERAMIC CHIP	0.1uF		16V		C892	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C746	1-164-360-11	CERAMIC CHIP	0.1uF		16V		C893	1-126-392-11	ELECT CHIP	100uF	20%	6.3V
	C747		CERAMIC CHIP	10PF	0.5PF	50V		C894		CERAMIC CHIP	0.1uF		16V
	C748		CERAMIC CHIP	0.1uF		16V		C895	1-126-392-11	ELECT CHIP	100uF	20%	6.3V
	C749		CERAMIC CHIP	0.1uF		16V	1	C896	1-126-206-11		100uF	20%	6.3V
	C750		CERAMIC CHIP	0.1uF		16V		C897	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C751	1-162-923-11	CERAMIC CHIP	47PF	5%	50V	1	C898	1-126-396-11	ELECT CHIP	47uF	20%	16V
	C752		CERAMIC CHIP	0.1uF	- / -	16V	1	C899	1-126-396-11		47uF	20%	16V
	C753		CERAMIC CHIP	0.1uF		16V		C900		CERAMIC CHIP	0.1uF		16V
	C754		CERAMIC CHIP	10PF	0.5PF	50V	1	C901		CERAMIC CHIP	0.1uF		16V
	C755		CERAMIC CHIP	0.033uF	10%	16V		C906		CERAMIC CHIP	0.1uF		16V
	C756	1-164-360-11	CERAMIC CHIP	0.1uF		16V		C907	1-164-360-11	CERAMIC CHIP	0.1uF		16V
	C757		CERAMIC CHIP	0.033uF	10%	16V		C908		CERAMIC CHIP	0.1uF		16V
	C758		CERAMIC CHIP	0.033uF	10%	16V	1	C909		CERAMIC CHIP	0.1uF		16V
	C759		CERAMIC CHIP	0.033uF	10%	16V	1	C910		CERAMIC CHIP	2.2uF	10%	10V
	C760	1-162-923-11		47PF	5%	50V		C912	1-104-905-11		0.22F		5.5V
	C761	1-164-677-11	CERAMIC CHIP	0.033uF	10%	16V		C913	1-126-206-11	ELECT CHIP	100uF	20%	6.3V
	C762		CERAMIC CHIP	0.033uF	10%	16V		C914		CERAMIC CHIP	100PF	5%	50V
	C763		CERAMIC CHIP	0.1uF	1070	16V	1	C915		CERAMIC CHIP	0.01uF	10%	25V
	C764	1-128-004-11		10uF	20%	16V		C916	1-128-013-11		1uF	20%	50V
	C765		CERAMIC CHIP	0.1uF	2070	16V		C917	1-126-197-11		10uF	20%	50V
		4 400 004 44	ELECT CUID	10uE	200/	161/		C010	1-126-204 11	ELECT CUID	47uF	20%	16V
	C766	1-128-004-11	CERAMIC CHIP	10uF 0.033uF	20% 10%	16V 16V		C918 C919	1-126-204-11	CERAMIC CHIP	47uF 0.1uF	ZU70	16V
	C767 C768		CERAMIC CHIP	0.033uF	10%	16V 16V		C920		CERAMIC CHIP	0.1uF		16V
			CERAMIC CHIP	0.033uF 0.1uF	10/0	4014		C921	1-126-393-11		33uF	20%	10V
	C771 C772		CERAMIC CHIP	47PF	5%	16V 50V		C922		CERAMIC CHIP	0.022uF	10%	25V
	פללט	1_16/_260 11	CERAMIC CHIP	0.1uF		16V				< CONNECTOR >			
	C773 C774		CERAMIC CHIP	47PF	5%	50V				- OCIVINEOTOR >			\$ 40 C
	C851		CERAMIC CHIP	0.1uF	Ų /0	16V		CN051	1-770-305-11	CONNECTOR, FFO	7/FPC 10D		
	C852		CERAMIC CHIP	0.1uF		16V		CN101		CONNECTOR, FF			
	C853		CERAMIC CHIP	0.1uF		16V		CN102		CONNECTOR, FFO			
	0000	1 104 000-11	OEIGHNIO OIRE	o. rui			1	CN401		CONNECTOR, FFO			
	C854	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	*	CN601		PIN, CONNECTOR			

Ref. No.	Part No.	<u>Description</u>	Remark	Ref. No.	Part No.	<u>Description</u>	<u>Remark</u>
CN602	1-779-369-11	CONNECTOR, SQUARE TYPE (INDI) 4	1P	IC104 IC105	8-759-079-53	IC TC74VHCT08FS (EL) IC TC74VHCT08FS (EL)	
* CN701	1-691-591-11	(D PIN, CONNECTOR (1.5mm) (SMD) 88 CONNECTOR, FFC/FPC 12P	V IN/OUT)	IC106 IC201		IC TC74VHCT08FS (EL) IC MM1115XFBE	
	1-774-767-11	CONNECTOR, FFC/FPC 15P CONNECTOR, FFC/FPC 30P		IC202 IC203		IC MM1031XML IC MM1115XFBE	
		PIN, CONNECTOR 8P		IC204 IC205	8-759-432-78 8-759-420-62	IC MM1111XFBE IC AN3916	
		< TRIMMER >		IC206		IC NJM2240M (TE2)	
		CAP, ADJ (DECODER FREERUN) CAP, ADJ (ENCODER FREERUN)		IC207 IC207 IC208	8-752-372-78	IC CXD2023Q (DSR-20MD) IC CXD2024AQ-TL (DSR-20MDP) IC M51271FP-70AD	
	1-141-424-11	< DIODE >		IC210 IC213	8-759-239-58	IC TC74HC221AF (EL) (DSR-20MDF IC TC7S00FU (TE85R) (DSR-20MDF	
DOE4	0.710.401.71					, , ,	,
D051 D052	8-719-421-71	DIODE MA132WA-TX DIODE MA132WA-TX		IC401 IC402	8-759-432-78	IC MM1115XFBE IC MM1111XFBE	
D201 D202		DIODE MA111-TX DIODE MA111-TX		1C403 1C404		IC LA7218M-TE-R IC CXA1592R-T4	
D401		DIODE 1T363-01-T8A		IC405		IC MB90089PF-G-196-BND-ER	
D403		DIODE MA111-TX		IC406		IC MM1196XFBE	
D404 D851		DIODE MA111-TX DIODE MA3075WA- (TX)		1C407 1C602		IC CXD2192Q-T4 IC MC68HC68VBIFB	
D852	8-719-421-59	DIODE MA3075WA- (TX)		IC651	8-759-368-82	IC MB90089PF-G-155-BND-ER	
D853	8-719-400-71	DIODE MA3082-TX		IC652		IC LA7218M-TE-R	
D855		DIODE MA738-TX		1C653 IC701		IC MM1115XFBE IC NJM2115V (TE2)	
D856 D858		DIODE MA729- (K8).S0 DIODE MA111-TX		IC702		IC TC74HC4053AFT (EL)	
D859	8-719-073-01	DIODE MA111-TX		IC703	8-759-523-02	IC TC74HC4053AFT (EL)	
D861	8-719-400-56	DIODE MA3062H-TX		IC704		IC NJM2115V (TE2)	
D862 D863		DIODE MA3075WA- (TX) DIODE RD6.2FM-T1		IC705 IC706		IC NJM2115V (TE2) IC NJM2115V (TE2)	
D864	8-719-421-27	DIODE MA728- (K8).S0		IC707	8-759-358-47	IC NJM2115V (TE2)	
D866 D867		DIODE MA111-TX DIODE MA738-TX		IC708 IC709		IC DS1801E-014TE2 IC NJM2115V (TE2)	
5007	0710 421 01			IC710		IC NJM2115V (TE2)	
		< DELAY LINE >		IC711	8-759-523-02	IC TC74HC4053AFT (EL)	
DL201	1-411-661-11	LINE, LC DELAY		IC712 IC713		IC NJM2115V (TE2) IC NJM2115V (TE2)	
		< FERRITE BEAD >		IC714		IC NJM2115V (TE2)	
FB851	1-543-948-22			IC715		IC NJM2115V (TE2)	
FB852 FB853	1-543-948-22 1-543-948-22			IC716 IC717		IC NJM2115V (TE2) IC NJM2115V (TE2)	
10000	1-345-340-22	TERRITE OUIT		IC718	8-759-358-47	IC NJM2115V (TE2)	
		< FILTER >		IC851	8-759-356-27	IC NJM2129M-TE2	
FL201		FILTER, LOW PASS		IC852		IC S579178PJ	
FL202 FL202		FILTER, BAND PASS (DSR-20MD) FILTER, BAND PASS (DSR-20MDP)		IC853 IC854		IC TC74HC4053AFT (EL) IC AK6440AM-E2	
FL203	1-233-501-11	FILTER, LOW PASS		IC856	1-473-301-11	CONVERTER UNIT, DC/DC	
FL204	1-233-500-11	FILTER, LOW PASS		IC857	8-759-538-14	IC S-3513BEFS-TB	
FL205 FL401		FILTER, LOW PASS FILTER, BAND PASS (DSR-20MD)		IC858 IC861		IC MM1256XF-BE IC TL1596CPW-ELM2000	
FL401		FILTER, BAND PASS (DSR-20MDP)		IC862	8-759-822-95	IC L79M05T-FA-TL	
		< IC >		IC863 IC864		IC PQ05TZ1U IC TL431CPSR	
IC051	8-759-032-23	IC TC74HC74AF (EL)		IC865		IC TC74VHC00FT (EL)	
IC052	8-759-521-97	IC HD6433837SC05H		IC866		IC TC7ST04FU (TE85R)	
IC053 IC101		IC TC7WU04FU (TE12R) IC TC74VHC08FT (EL)				< JACK >	
IC102		IC TC7W125FU-TE12R		1054	1,579 700 44		UI S IVI)
IC103	8-759-524-04	IC TC74VHC125FT (EL)		J851	1-010-140-11	JACK, MINIATURE (DIA. 3.5) (CONTR	OL O IN)

Ref. No.	Part No.	Description	<u>Remark</u>	Ref. No.	Part No.	Description	Remark
J852	1-573-798-11	JACK, MINIATUI	RF (DIA 3.5)	Q202	8-729-905-35	TRANSISTOR	2SC4081T106R
0002	. 0.0 .00	onor, minimo	(CONTROL S OUT)	Q203	8-729-905-35		2SC4081T106R
J853	1-691-258-11	JACK (LANC)	(Q204	8-729-905-35		2SC4081T106R
				Q205	8-729-026-52		2SA1576A-T106-R
		< COIL >					
				Q206	8-729-905-35		2SC4081T106R
L051	1-412-029-11			Q207	8-729-026-52		2SA1576A-T106-R
L201		INDUCTOR CHIP		Q208	8-729-427-83		XP6501-TXE
L202		INDUCTOR CHIP		Q209	8-729-905-35		2SC4081T106R
L203		INDUCTOR CHIP		Q210	8-729-026-52	TRANSISTOR	2SA1576A-T106-R
L204	1-412-029-11	INDUCTOR CHIP	TOUH	0014	0 700 000 50	TDANCIOTOD	00445704 T400 B
L205	1_/12_020_11	INDUCTOR CHIP	1004	Q211 Q212	8-729-026-52 8-729-026-52		2SA1576A-T106-R
L205	1-412-029-11			0213	8-729-905-35		2SA1576A-T106-R 2SC4081T106R
L207		INDUCTOR CHIP		Q214	8-729-905-35		2SC4081T106R 2SC4081T106R
L208		INDUCTOR CHIP		Q215	8-729-905-35		2SC4081T106R
L211	1-412-808-21		470uH	QL 10	0 720 000 00	MANOGOTON	2504001110011
,				Q216	8-729-905-35	TRANSISTOR	2SC4081T106R
L213	1-412-031-11	INDUCTOR CHIP	47uH	Q217	8-729-026-52		2SA1576A-T106-R
L216		INDUCTOR CHIP		Q218	8-729-026-52		2SA1576A-T106-R
L217		INDUCTOR CHIP		Q221	8-729-905-35		2SC4081T106R
L218	1-412-029-11	INDUCTOR CHIP	10uH	Q222	8-729-905-35		2SC4081T106R
L219	1-412-029-11	INDUCTOR CHIP	10uH				
			•	Q223	8-729-905-35	TRANSISTOR	2SC4081T106R
L220			10uH (DSR-20MDP)	Q224	8-729-427-83	TRANSISTOR	XP6501-TXE
L401		INDUCTOR CHIP		Q225	8-729-905-35	TRANSISTOR	2SC4081T106R
L402		INDUCTOR CHIP		Q226	8-729-905-35	TRANSISTOR	2SC4081T106R
L403		INDUCTOR CHIP		Q227	8-729-905-35	TRANSISTOR	2SC4081T106R
L404	1-412-029-11	INDUCTOR CHIP	10uH				
1.400	4 440 000 44	INDUCTOR OUID	00.11	Q228	8-729-427-83		XP6501-TXE
L406		INDUCTOR CHIP		Q229	8-729-026-52		2SA1576A-T106-R
L407		INDUCTOR CHIP		Q231	8-729-905-35		2SC4081T106R
L408		INDUCTOR CHIP		Q232	8-729-427-83		XP6501-TXE
L409 L410		INDUCTOR CHIP		Q233	8-729-905-35	TRANSISTOR	2SC4081T106R
L410	1-410-385-11	INDUCTOR CHIP	22un	0402	0 700 005 05	TDANCIOTOD	000400174000
L411	1_/112_020_11	INDUCTOR CHIP	10.04	Q403 Q404	8-729-905-35 8-729-905-35		2SC4081T106R
L412		INDUCTOR CHIP		Q4Q4 Q405	8-729-905-35		2SC4081T106R 2SC4081T106R
L601		INDUCTOR CHIP		Q406	8-729-905-35		2SC4081T106R 2SC4081T106R
L602			47uH (DSR-20MD)	Q407	8-729-427-83		XP6501-TXE
L602			39uH (DSR-20MDP)	Q 107	0 120 421 00	THAINGIGTOR	AL GOOT-TAL
				Q408	8-729-402-42	TRANSISTOR	UN5213-TX
L603	1-412-029-11	INDUCTOR CHIP	10uH	Q409	8-729-015-76		UN5211-TX
L604	1-412-029-11	INDUCTOR CHIP	10uH	Q410	8-729-905-35		2SC4081T106R
L651		INDUCTOR CHIP		Q411	8-729-905-35		2SC4081T106R
L652		INDUCTOR CHIP		Q412	8-729-905-35	TRANSISTOR	2SC4081T106R
L653	1-410-385-11	INDUCTOR CHIP	22uH				
				Q413	8-729-905-35		2SC4081T106R
L654		INDUCTOR CHIP		Q414	8-729-905-35		2SC4081T106R
L655		INDUCTOR CHIP	****	Q415	8-729-427-83		XP6501-TXE
L656		INDUCTOR CHIP		Q416	8-729-402-84		XN4601-TW
L657		INDUCTOR CHIP	7.7.1	Q417	8-729-427-83	TRANSISTOR	XP6501-TXE
L851	1-412-020-11	INDUCTOR CHIP	iufi -	0440	0 700 005 05	TDANCIOTOR	0004004T400D
1 850	1_//10_00611	INDUCTOR CHIP	1,,,,	Q419	8-729-905-35		2SC4081T106R
L852 L853		INDUCTOR CHIP		Q420	8-729-905-35		2SC4081T106R
L854		INDUCTOR CHIP		Q601 Q602	8-729-905-35 8-729-905-35		2SC4081T106R
L855		INDUCTOR CHIP	· · · · · · · · · · · · · · · · · · ·	Q604	8-729-905-35		2SC4081T106R 2SC4081T106R
L856		INDUCTOR CHIP		Q004	0-729-900-00	INANSISTON	23040011100h
			117 MII	Q605	8-729-905-35	TRANSISTOR	2SC4081T106R
L857	1-412-028-11	INDUCTOR CHIP	4.7uH	Q606	8-729-905-35		2SC4081T106R
L858		INDUCTOR CHIP		Q607	8-729-026-52		2SA1576A-T106-R
			·	Q613	8-729-026-52		2SA1576A-T106-R
Jack Are		< TRANSISTOR >		Q651	8-729-905-35		2SC4081T106R
			r selfact 1				e e e e e e e e e e e e e e e e e e e
Q101	8-729-015-76		UN5211-TX	Q653	8-729-905-35	TRANSISTOR	2SC4081T106R
Q102	8-729-015-76		UN5211-TX	Q655	8-729-026-52		2SA1576A-T106-R
Q103	8-729-015-76	and the second of the second o	UN5211-TX	Q656	8-729-905-35		2SC4081T106R
Q107	8-729-015-76		UN5211-TX	Q658	8-729-026-52		2SA1576A-T106-R
Q108	8-729-015-76	IRANSISTOR	UN5211-TX	Q701	8-729-015-76	TRANSISTOR	UN5211-TX
0004	0.700.005.05	TDANGIOTOS	000400474000	0=4-			
Q201	8-729-905-35	TRANSISTOR	2SC4081T106R	Q702	8-729-015-74	TRANSISTOR	UN5111-TX

Ref. No	o. Part No.	<u>Description</u>			Remark	Ref. No.	Part No.	<u>Description</u>			Remark
Q70	3 8-729-905-35	TRANSISTOR	2SC408	1T106R		R124	1-216-809-11		100	5%	1/16W
Q70		TRANSISTOR	2SC408				, ,		,,,,	0 70	.,
Q70		TRANSISTOR	UN5213			R125	1-216-809-11	METAL CHIP	100	5%	1/16W
Q70		TRANSISTOR	UN5113			R126	1-216-809-11		100	5%	1/16W
						R127	1-216-797-11		10	5%	1/16W
Q70°	7 8-729-015-76	TRANSISTOR	UN5211	-TX		R128	1-216-809-11		100	5%	1/16W
Q70		TRANSISTOR	UN2225			R129	1-216-797-11		10	5%	1/16W
Q70			UN2225			120	1 210 101 11	WILLIAM OTTO	10	0 70	17 1000
Q71		TRANSISTOR	UN2225			R130	1-216-809-11	METAL CHIP	100	5%	1/16W
Q71		TRANSISTOR	UN2225			R131	1-216-809-11		100	5%	1/16W
	. 0.2002070		ONLLLO	. (174)		R132	1-216-797-11		100	5%	1/16W
Q71:	2 8-729-028-70	TRANSISTOR	UN2225	T_ /TY\		R133	1-216-809-11		100	5%	1/16W
Q71:		TRANSISTOR	UN2225			R134	1-216-797-11		100		
Q85			2SC408			1104	1-210-191-11	METAL UNIP	10	5%	1/16W
Q85		TRANSISTOR	UN5213			R135	1-216-809-11	METAL CHIP	100	En/	4/4034
Q85		TRANSISTOR	2SD218			R136	1-216-809-11		100	5%	1/16W
QU.	0-129-014-91	INAMOISTON	200210	10-1X					100	5%	1/16W
Q854	1 9-720-005-25	TRANSISTOR	2SC4081	TIOOD		R137	1-216-809-11	METAL CHIP	100	5%	1/16W
Q85		TRANSISTOR				R138	1-216-809-11		100	5%	1/16W
Q856			2SC4081			R139	1-216-809-11	METAL CHIP	100	5%	1/16W
Q857		TRANSISTOR	UN5113-			D140	1 010 000 11	METAL OLUB	400	5 0/	4 4 0 4 1
Q05	0-129-402-42	INAMOISTUR	UN5213-	-17		R140	1-216-809-11		100	5%	1/16W
		DECICTOR				R141	1-216-809-11		100	5%	1/16W
		< RESISTOR >				R142	1-216-809-11	METAL CHIP	100	5%	1/16W
D0C-	1 010 000 01	DEG OUID	401/	F 0/	4400	R143	1-216-809-11		100	5%	1/16W
R05			10K	5%	1/16W	R144	1-216-809-11	METAL CHIP	100	5%	1/16W
R052			10K	5%	1/16W						
R053			10K	5%	1/16W	R145	1-216-809-11	METAL CHIP	100	5%	1/16W
R054			10K	5%	1/16W	R146	1-216-797-11	METAL CHIP	10	5%	1/16W
R056	6 1-216-864-11	METAL CHIP	0	5%	1/16W	R147	1-216-797-11	METAL CHIP	10	5%	1/16W
B0=						R148	1-216-797-11		.10	5%	1/16W
R059			1.5K	5%	1/16W	R152	1-216-833-91	RES, CHIP	10K	5%	1/16W
R060			22	5%	1/16W						
R061			1M	5%	1/16W	R153	1-216-833-91		10K	5%	1/16W
R062			22	5%	1/16W	R154	1-216-833-91		10K	5%	1/16W
R063	3 1-216-801-11	METAL CHIP	22	5%	1/16W	R155	1-216-821-11	METAL CHIP	1K	5%	1/16W
						R156	1-216-809-11	METAL CHIP	100	5%	1/16W
R064			10K	5%	1/16W	R157	1-216-809-11	METAL CHIP	100	5%	1/16W
R065	1-216-864-11	METAL CHIP	0	5%	1/16W						* * * * * * * * * * * * * * * * * * *
				(D:	SR-20MDP)	R158	1-216-809-11	METAL CHIP	100	5%	1/16W
R066	1-216-801-11	METAL CHIP	- 22	5%	1/16W	R159	1-216-809-11	METAL CHIP	100	5%	1/16W
R067	1-216-857-11	METAL CHIP	1M	5%	1/16W	R160	1-216-809-11	METAL CHIP	100	5%	1/16W
R068	1-216-801-11	METAL CHIP	22	5%	1/16W	R161	1-216-809-11	METAL CHIP	100	5%	1/16W
						R162	1-216-809-11	METAL CHIP	100	5%	1/16W
R069	1-216-830-11	METAL CHIP	5.6K	5%	1/16W						
R070	1-216-833-91	RES, CHIP	10K	5%	1/16W	R163	1-216-809-11	METAL CHIP	100	5%	1/16W
R071	1-216-833-91	RES, CHIP	10K	5%	1/16W	R164	1-216-809-11	METAL CHIP	100	5%	1/16W
R101	1-216-797-11	METAL CHIP	10	5%	1/16W	R165		METAL CHIP	100	5%	1/16W
R102		METAL CHIP	10	5%	1/16W	R166	1-216-833-91		10K	5%	1/16W
						R167	1-216-809-11		100	5%	1/16W
R103	1-216-833-91	RES, CHIP	10K	5%	1/16W				,,,,,	- , ,	
R104			10K	5%	1/16W	R168	1-216-809-11	METAL CHIP	100	5%	1/16W
R105		METAL CHIP	10	5%	1/16W	R169		METAL CHIP	100	5%	1/16W
R106		METAL CHIP	10	5%	1/16W	R170		RES, CHIP	10K	5%	1/16W
R107			10	5%	1/16W	R171	1-216-809-11		100	5%	1/16W
				0 /0		R172	1-216-809-11		100	5%	1/16W
R108	1-216-833-91	RES CHIP	10K	5%	1/16W	11172	1 210 000 11	WEIAL OIII	100	J /0	1/1044
R109		•	1010	5%	1/16W	R173	1-216-809-11	METAL CUID	100	E0/	4 /4 (5)4/
R110			10	5%	1/16W	R173	1-216-809-11			5%	1/16W
R112		RES, CHIP	10K						100	5%	1/16W
R113			0	. 5% 5%	1/16W	R175	1-216-809-11		100	5%	1/16W
niio	1-216-864-11	METAL CHIP	0 .	5%	1/16W	R176		METAL CHIP	100	5%	1/16W
R114	1-216-809-11	METAL OUID	100	E0/	1/101/	R177	1-216-809-11	WETAL CHIP	100	5%	1/16W
		METAL CHIP	100	5%	1/16W	D470	4 040 000 44	NACTAL OUTS	400	E01	* /* ***
R115		METAL CHIP	100	5%	1/16W	R178		METAL CHIP	100	5%	1/16W
R117		METAL CHIP	100	5%	1/16W	R179		METAL CHIP	100	5%	1/16W
R118		METAL CHIP	10	5%	1/16W	R180		METAL CHIP	100	5%	1/16W
R119	1-216-797-11	METAL CHIP	10	5%	1/16W	R181	1-216-809-11	and the second s	100	5%	1/16W
				(DS	R-20MDP)	R201	1-216-805-11	METAL CHIP	47	5%	1/16W
	3 0-0 000	A SETTAL CALL	400								
R120		METAL CHIP	100	5%	1/16W	R202		METAL CHIP	1K	5%	1/16W
R121		METAL CHIP	100	5%	1/16W	R203	1-216-810-11		120	5%	1/16W
R122		METAL CHIP	100	5%	1/16W	R204		METAL CHIP	1K	5%	1/16W
R123	1-216-809-11	METAL CHIP	100	5%	1/16W	R205	1-216-837-11	METAL CHIP	22K	5%	1/16W

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
			4.01/	E0/				•	412	E0/	
R206	1-216-833-91	RES, CHIP	10K	5%	1/16W	R272 R273	1-216-821-11 1-216-819-11		1K	5%	1/16W
R207	1-216-821-11	METAL CHIP	1K	5%	1/16W	R274	1-216-818-11		680 560	5% 5%	1/16W 1/16W
R208	1-216-825-11		2.2K	5%	1/16W	R275	1-216-809-11		100	5%	1/16W
R209	1-216-821-11		1K	5%	1/16W	1127-0	1-210-009-11	MILIAL OITH	100	J /0	1/1044
R210	1-216-821-11		1K	5%	1/16W	R276	1-216-821-11	METAL CHIP	1K	5%	1/16W
R211	1-216-837-11		22K	5%	1/16W	R277	1-216-864-11		0	5%	1/16W
11211	1 210 007 11	WILLIAL OTT		0 70	171011	R279	1-216-821-11		1K	5%	1/16W
R212	1-216-834-11	METAL CHIP	12K	5%	1/16W	R280	1-216-825-11		2.2K	5%	1/16W
R213	1-216-821-11		1K	5%	1/16W	R281	1-216-817-11		470	5%	1/16W
R214	1-216-817-11		470	5%	1/16W	1				•	
R215	1-216-816-11		390	5%	1/16W	R282	1-218-899-11	METAL CHIP	150K	0.5%	1/16W
R216	1-216-821-11	METAL CHIP	1K	5%	1/16W	R283	1-218-871-11	METAL CHIP	10K	0.5%	1/16W
						R284	1-216-825-11		2.2K	5%	1/16W
R217	1-216-807-11	METAL CHIP	68	5%	1/16W	R285	1-216-864-11	METAL CHIP	0	5%	1/16W
R218	1-216-837-11		22K	5%	1/16W	R287	1-218-879-11	METAL CHIP	22K	0.5%	1/16W
R219	1-216-833-91		10K	5%	1/16W						
R220	1-216-821-11		1K	5%	1/16W	R288	1-216-844-11		82K	5%	1/16W
R221	1-216-817-11	METAL CHIP	470	5%	1/16W	R289	1-216-825-11		2.2K	5%	1/16W
						R290	1-218-869-11		8.2K	0.5%	1/16W
R222	1-216-823-11		1.5K	5%	1/16W	R291	1-216-817-11		470	5%	1/16W
R223	1-216-821-11		1K	5%	1/16W	R292	1-218-871-11	METAL CHIP	10K	0.5%	1/16W
R224	1-216-841-11		47K	5%	1/16W					_ :	
R225	1-216-817-11		470	5%	1/16W	R293	1-216-833-91	RES, CHIP	10K	5%	1/16W
R226	1-216-809-11	METAL CHIP	100	5%	1/16W	D004	4 040 004 44	METAL OLUB			SR-20MD)
D007	. 4 040 004 44	METAL CHID	41/	E0/	4 /4 0\A	R294	1-216-821-11		1K	5%	1/16W
R227	1-216-821-11		1K	5%	1/16W	R295	1-216-853-11		470K	5%	1/16W
R228	1-216-809-11		100	5%	1/16W	R296	1-216-825-11		2.2K	5%	1/16W
R229 R231	1-216-821-11 1-216-823-11		1K 1.5K	5% 5%	1/16W 1/16W	R297	1-216-819-11	WETAL CHIP	680	5%	1/16W
R232	1-216-825-11		2.2K	5% 5%	1/16W	R298	1-216-818-11	METAL CHIP	560	5%	1/16W
11202	1-210-025-11	MILIAE OIIII	2.21	J /0	171000	R299	1-216-829-11		4.7K	5%	1/16W
R233	1-216-825-11	METAL CHIP	2.2K	5%	1/16W	R300	1-216-805-11		47	5%	1/16W
R234	1-216-809-11		100	5%	1/16W	R301	1-216-815-11	METAL CHIP	330	5%	1/16W
R235	1-216-845-11		100K	5%	1/16W	R302	1-216-837-11		22K	5%	1/16W
R236	1-216-829-11		4.7K	5%	1/16W		1 270 001 11		be let 1	0,0	171011
R237	1-216-828-11		3.9K	5%	1/16W	R303	1-216-864-11	METAL CHIP	0	5%	1/16W
											R-20MDP)
R241	1-216-864-11	METAL CHIP	0	5%	1/16W	R304	1-216-864-11	METAL CHIP	0	5%`	1/16W [^]
				(DS	SR-20MDP)					(D	SR-20MD)
R242	1-216-833-91	RES, CHIP	10K	5%	1/16W	R305	1-216-819-11	METAL CHIP	680	5%	1/16W
R244	1-216-823-11	METAL CHIP	1.5K	5%	1/16W	R306	1-216-811-11	METAL CHIP	150	5%	1/16W
R246	1-216-825-11		2.2K	5%	1/16W	R308	1-216-816-11	METAL CHIP	390	5%	1/16W
R248	1-216-813-11	METAL CHIP	220	5%	1/16W						
						R309	1-216-845-11		100K	5%	1/16W
R249	1-216-864-11	METAL CHIP	0	5%	1/16W	R310	1-216-837-11		22K	5%	1/16W
2050	1 040 000 44		2 21		OSR-20MD)	R311	1-216-837-11		22K	5%	1/16W
R250	1-216-828-11		3.9K	5%	1/16W	R312	1-216-818-11		560	5%	1/16W
R251	1-216-813-11		220	5%	1/16W	R313	1-216-821-11	METAL CHIP	1K	5%	1/16W
R252	1-216-825-11		2.2K	5%	1/16W	D04.4	1 010 000 11	METAL OLUD	0.71/	E0/	4 14 0141
R253	1-216-818-11	WE IAL CHIP	560	5%	1/16W	R314	1-216-826-11		2.7K	5%	1/16W
R254	1-218-863-11	METAL CHID	4.7K	0.5%	1/16W	R315 R316	1-216-825-11 1-216-821-11		2.2K	5%	1/16W
R255	1-218-707-11		4.7K 4.3K	5%	1/16W 1/16W	R317	1-216-825-11		1K 2.2K	5% 5%	1/16W 1/16W
R256	1-218-269-11	•	360	5% 5%	1/16W	R318	1-216-837-11		2.2K 22K	5% 5%	1/16W
R257	1-216-864-11	•	0	5%	1/16W	11010	1-210-007-11	WILLIAL OTTIF	221	J 70	1/10VV
11207	1-210-004-11	WEIAL OITH	U		SR-20MD)	R319	1-216-840-11	METAL CHIP	39K	5%	1/16W
R258	1-218-823-11	METAL CHIP	100	0.5%	1/16W	11013	1-210-040-11	WIETAL OTT	JJK		R-20MDP)
11200	1 210 020 11	MEME OM	100		171000	R320	1-216-837-11	METAL CHIP	22K	5%	1/16W
R259	1-216-864-11	METAL CHIP	0	5%	1/16W	R321	1-216-839-11		33K	5%	1/16W
R260	1-216-825-11		2.2K	5%	1/16W	R323	1-216-818-11		560	5%	1/16W
R261	1-216-849-11		220K	5%	1/16W	R324	1-216-809-11		100	5%	1/16W
R262	1-216-809-11		100	5%	1/16W		550 11	Otti		J 70	.,
R263	1-216-821-11		1K	5%	1/16W	R325	1-216-816-11	METAL CHIP	390	5%	1/16W
						R326	1-216-821-11		1K	5%	1/16W
R264	1-216-818-11	METAL CHIP	560	5%	1/16W	R327	1-216-825-11		2.2K	5%	1/16W
R265	1-216-825-11	METAL CHIP	2.2K	5%	1/16W	R328	1-216-839-11	METAL CHIP	33K	5%	1/16W
R266	1-216-825-11		2.2K	5%	1/16W					(DSI	R-20MDP)
R269	1-216-837-11		22K	5%	1/16W	R329	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R270	1-216-864-11	METAL CHIP	0	5%	1/16W						. •
.= ==						R330	1-218-869-11		8.2K	0.5%	1/16W
R271	1-216-837-11	METAL CHIP	22K	5%	1/16W	R401	1-216-821-11	METAL CHIP	1 K	5%	1/16W

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
R402	1-216-864-11	METAL CHIP	0	5%	1/16W	R465			212	0 Fo/	
R404	1-216-864-11		0	5%	1/16W	R466	1-216-829-11	METAL CHIP METAL CHIP	1K	0.5%	1/16W
	. 2.0 007 71	MENTE OIL	U		SR-20MDP)	R467		METAL CHIP	4.7K 47K	5%	1/16W
R406	1-216-864-11	METAL CHIP	0	5%	1/16W	R468	1-216-841-11		47K 47K	5% 5%	1/16W 1/16W
			•		DSR-20MD)	11400	1 210 041 11	WEIAL OITH	4/ N	3 /0	1/ TOW
				`		R469	1-216-839-11	METAL CHIP	33K	5%	1/16W
R407	1-216-835-11		15K	5%	1/16W	R470	1-216-819-11		680	5%	1/16W
R408	1-216-833-91	RES, CHIP	10 K	5%	1/16W	R471	1-216-841-11		47K	5%	1/16W
R410	1-216-817-11	METAL CHIP	470	5%	1/16W	R472	1-216-864-11		0	5%	1/16W
R411	1-216-864-11		0	5%	1/16W	R473	1-216-821-11		1K	5%	1/16W
R412	1-216-837-11	METAL CHIP	22K	5%	1/16W						
						R474	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R413	1-216-817-11		470	5%	1/16W	R477	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R414	1-216-819-11		680	5%	1/16W	R480	1-216-864-11		0	5%	1/16W
R415	1-216-864-11		0	5%	1/16W	R481		METAL CHIP	0	5%	1/16W
R416	1-216-835-11		15K	5%	1/16W	R482	1-216-864-11	METAL CHIP	0	5%	1/16W
R417	1-216-833-91	RES, CHIP	10K	5%	1/16W					(DS	R-20MDP)
R418	1-216-835-11	METAL CHIP	15K	5%	1/16W	R484	1 016 064 11	METAL OLUB	•	50 /	4/4/0044
R419	1-216-833-91		10K	5%	1/16W	N404	1-210-004-11	METAL CHIP	0	5%	1/16W
R420	1-216-813-11		220	5%	1/16W	R485	1-216-864-11	METAL CHIP	0		SR-20MD)
R421	1-216-828-11		3.9K	5%	1/16W	R486	1-216-821-11		1K	5% 5%	1/16W 1/16W
R422	1-216-847-11		150K	5%	1/16W	R487	1-216-821-11		1K	5% 5%	1/16W 1/16W
				070	.,	R488	1-216-833-91		10K	5%	1/16W 1/16W
R423	1-216-864-11	METAL CHIP	0	5%	1/16W	11100	1 210 000 01	neo, om	1010	J /0	171000
R424	1-216-821-11	METAL CHIP	1K	5%	1/16W	R489	1-216-821-11	METAL CHIP	1K	5%	1/16W
R425	1-216-817-11	METAL CHIP	470	5%	1/16W	R492		METAL CHIP	1K	5%	1/16W
R426	1-216-818-11	METAL CHIP	560	5%	1/16W	R493	1-216-833-91		10K	5%	1/16W
R427	1-216-821-11	METAL CHIP	1K	5%	1/16W	R494	1-216-022-00	METAL CHIP	75	5%	1/10W
				(DS	SR-20MDP)	R495	1-216-833-91		10K	5%	1/16W
R428	1-216-821-11	METAL CHIP	11/	E0/	1.400	D.400	4 040 044 4				
R429	1-216-829-11	METAL CHIP	1K 4.7K	5%	1/16W	R496	1-216-841-11		47K	5%	1/16W
R430	1-216-833-91		4.7K 10K	5% 5%	1/16W 1/16W	R497	1-216-022-00		75	5%	1/10W
R431	1-216-825-11	,	2.2K	5% 5%	1/16W	R498 R499	1-216-013-00		33	5%	1/10W
R433	1-216-833-91		10K	5%	1/16W	R500	1-216-833-91 1-216-015-00		10K	5%	1/16W
11100	1 210 000 51	nzo, om	TOR	J /0	1/1000	กอบบ	1-210-010-00	METAL CHIP	39	5%	1/10W
R434	1-216-821-11	METAL CHIP	1K	5%	1/16W	R501	1-216-817-11	METAL CHIP	470	5%	1/16W
				(DS	R-20MDP)	R502	1-216-845-11		100K	5%	1/16W
R436	1-216-817-11	METAL CHIP	470	5%	1/16W	R503	1-216-821-11		1K	5%	1/16W
R437	1-216-821-11	METAL CHIP	1K	5%	1/16W	R504	1-216-864-11	METAL CHIP	0	5%	1/16W
R438	1-216-864-11		0	5%	1/16W	R505	1-216-845-11	METAL CHIP	100K	5%	1/16W
R439	1-216-837-11	METAL CHIP	22K	5%	1/16W						
D440	1 010 001 11	METAL OLUB	416			R506	1-216-864-11		0	5%	1/16W
R440	1-216-821-11		1K	5%	1/16W	R507	1-216-845-11		100K	5%	1/16W
R441	1-216-819-11		680	5%	1/16W	R508	1-216-845-11	METAL CHIP	100K	5%	1/16W
R442	1-216-837-11		22K	5%	1/16W	R509	1-216-845-11		100K	5%	1/16W
R443 R444	1-216-819-11		680	5%	1/16W	R510	1-216-845-11	METAL CHIP	100K	5%	1/16W
דידיוו	1-216-837-11	WILLIAL CITIF	22K	5%	1/16W	DE11	1-216-845-11	METAL OURD	4001/	F 0/	4 (4 (0) 14)
R445	1-218-838-11	METAL CHIP	430	0.5%	1/16W	R511		METAL CHIP	100K	5% 5%	1/16W
R446	1-216-833-91		10K	5%	1/16W	R512 R513	1-216-864-11	METAL CHIP	0	5% 5%	1/16W
R447	1-216-817-11		470	5%	1/16W	R514	1-216-829-11 1-216-849-11		4.7K	5%	1/16W
R449	1-216-864-11	METAL CHIP	0	5%	1/16W	R514	1-216-864-11	METAL CHIP	220K 0	5% 5%	1/16W
			·		SR-20MD)	11017	1-210-004-11	WILIAL OIMP	U	J 70	1/16W
R450	1-218-839-11	METAL CHIP	470	0.5%	1/16W	R519	1-216-864-11	METAL CHIP	0	5%	1/16W
						R520		RES, CHIP	10K	5%	1/16W
R451	1-218-846-11	METAL CHIP	910	0.5%	1/16W	R521	1-216-864-11	METAL CHIP	0	5%	1/16W
R452	1-216-864-11	METAL CHIP	0	5%	1/16W	R524		METAL CHIP	1K	5%	1/16W
					R-20MDP)	R525	1-216-833-91	RES, CHIP	10K	5%	1/16W
R453	1-216-819-11		680	5%	1/16W						
R454	1-216-864-11		0	5%	1/16W	R526			10K	5%	1/16W
R458	1-216-864-11	METAL CHIP	0	5%	1/16W	R527	1-216-821-11	METAL CHIP	1K	5%	1/16W
R459	1-216-864-11	METAL CHIP	n	En/	1/1014	DE00	4 040 004 44	NACTA: O			1-20MDP)
R460			0	5%	1/16W	R528		METAL CHIP	0	5%	1/16W
R461		METAL CHIP METAL CHIP	0 0	5% 5%	1/16W 1/16W	R529	1-216-864-11	METAL CHIP	0	5%	1/16W
.,.01	. 210 004-11	WEIGE VIIIF			R-20MDP)	R531	1-016 064 14	METAL OUD	0		R-20MD)
R462	1-216-842-11	METAL CHIP	56K	5%	1/16W	nool	1-216-864-11	WEIAL UHIP	0	5%	1/16W
R463		RES, CHIP	10K	5%	1/16W	R533	1-216-864-11	METAL CHIP	0	5%	1/16W
R464		METAL CHIP	0	5%	1/16W	R534		METAL CHIP	0		1/16W
					SR-20MD)	R535		METAL CHIP	0		1/16W
				,	• • •	-			-	- /-	., • •

											L	
R	ef. No.	Part No.	Description			<u>Remark</u>	Ref. No.	Part No.	Description			<u>Remark</u>
			•	0	E0/	1/16/1		1-216-833-91	RES, CHIP	10K	5%	1/16W
	R536	1-216-864-11		0	5%	1/16W	R702					
	R537	1-216-864-11	METAL CHIP	0	5%	1/16W	R703	1-216-833-91		10K	5%	1/16W
							R704	1-216-833-91	•	10K	5%	1/16W
	R539	1-216-821-11	METAL CHIP	- 1K	5%	1/16W	R705	1-216-833-91	RES, CHIP	10K	5%	1/16W
	R540	1-216-864-11	METAL CHIP	0	5%	1/16W						
	R541	1-216-864-11		0	5%	1/16W	R706	1-216-833-91	RES. CHIP	10K	5%	1/16W
	R542	1-216-864-11		o ·	5%	1/16W	R707	1-216-833-91		10K	5%	1/16W
		1-216-864-11		0	5%	1/16W	R708	1-216-833-91		10K	5%	1/16W
	R543	1-210-004-11	METAL CHIP								5%	1/16W
					. (1	DSR-20MD)	R709	1-216-849-11		220K		
							R710	1-216-849-11	METAL CHIP	220K	5%	1/16W
	R543	1-211-983-11	METAL CHIP	39	0.5%	1/16W	ļ					
					(D	SR-20MDP)	R711	1-216-839-11	METAL CHIP	33K	5%	1/16W
	R601	1-216-841-11	METAL CHIP	47K	5%	1/16W	R712	1-216-839-11	METAL CHIP	33K	5%	1/16W
	R602	1-216-841-11		47K	5%	1/16W	R713	1-216-835-11	METAL CHIP	15K	5%	1/16W
	R603	1-216-813-11		220	5%	1/16W	R714	1-216-835-11		15K	5%	1/16W
								1-216-839-11		33K	5%	1/16W
	R604	1-216-849-11	METAL UNIP	220K	5%	1/16W	R715	1-210-039-11	WILLIAL OTHE	331	J /0	17 10 00
										2014	F0 /	4 (4 0) 41
	R605	1-216-837-11		22K	5%	1/16W	R716	1-216-839-11		33K	5%	1/16W
	R606	1-216-839-11	METAL CHIP	33K	5%	1/16W	R717	1-216-835-11	METAL CHIP	15K	5%	1/16W
	R610	1-216-817-11	METAL CHIP	470	5%	1/16W	R718	1-216-835-11	METAL CHIP	15K	5%	1/16W
	R611	1-216-816-11	METAL CHIP	390	5%	1/16W	R719	1-216-864-11	METAL CHIP	0	5%	1/16W
	R612	1-216-821-11		1K	5%	1/16W	R721	1-216-809-11		100	5%	1/16W
	11012	1 210 021 11	WEINE OIM	***	0 / 0	.,		. 2.0 000				
	DC10	1 010 017 11	METAL CLUD	470	5%	1/16W	R722	1-216-841-11	METAL CHID	47K	5%	1/16W
	R613	1-216-817-11										
	R615	1-216-864-11		0	5%	1/16W	R723	1-216-837-11		22K	5%	1/16W
	R616	1-216-821-11	METAL CHIP	1K	5%	1/16W	R724	1-216-864-11		0	5%	1/16W
	R619	1-216-815-11	METAL CHIP	330	5%	1/16W	R726	1-216-809-11	METAL CHIP	100	5%	1/16W
	R621	1-216-821-11	METAL CHIP	1K	5%	1/16W	R727	1-216-845-11	METAL CHIP	100K	5%	1/16W
	R622	1-216-833-91	BES CHIP	10K	5%	1/16W	R728	1-216-845-11	METAL CHIP	100K	5%	1/16W
	R623	1-216-853-11	,	470K	5%	1/16W	R729	1-216-845-11		100K	5%	1/16W
										100K	5%	1/16W
	R629	1-216-833-91		10K	5%	1/16W	R730	1-216-845-11				
	R630	1-216-836-11		18K	5%	1/16W	R731	1-216-837-11		22K	5%	1/16W
	R631	1-216-837-11	METAL CHIP	22K	5%	1/16W	R732	1-216-833-91	RES, CHIP	10K	5%	1/16W
							1					
	R635	1-216-864-11	METAL CHIP	0	5%	1/16W	R733	1-216-833-91	RES, CHIP	10K	5%	1/16W
	R636	1-216-833-91		10K	5%	1/16W	R734	1-216-841-11	METAL CHIP	47K	5%	1/16W
	R639	1-216-821-11		1K	5%	1/16W	R735	1-216-833-91		10K	5%	1/16W
	R640	1-216-841-11		47K	5%	1/16W	R736	1-216-833-91		10K	5%	1/16W
		1-216-841-11		47K	5%	1/16W	R737	1-216-833-91		10K	5%	1/16W
	R641	1-210-041-11	WEIAL UTIP	4/ N	3 70	17 TOW	N/3/	1-210-000-91	RLO, UTIL	1010	J /6	171044
	m 040	4 040 004 44	MATTAL OLUB	414	E0/	4 (4 0) 4 (D700	4 040 000 04	DE0 0111D	4014	EO/	4/4014
	R642	1-216-821-11		1K	5%	1/16W	R738	1-216-833-91		10K	5%	1/16W
	R643	1-216-845-11	METAL CHIP	100K	5%	1/16W	R739	1-216-819-11		680	5%	1/16W
	R652	1-216-819-11	METAL CHIP	680	5%	1/16W	R740	1-216-819-11	METAL CHIP	680	5%	1/16W
	R653	1-216-864-11	METAL CHIP	0	5%	1/16W	R741	1-216-833-91	RES, CHIP	10K	5%	1/16W
	R654	1-216-864-11		0	5%	1/16W	R742	1-216-833-91		10K	5%	1/16W
	11001	1 210 001 11		·	0,70	,,						
	R657	1-216-831-11	METAL CHID	6.8K	5%	1/16W	R743	1-216-841-11	METAL CHIP	47K	5%	1/16W
								1-216-833-91		10K	5%	1/16W
	R658	1-216-834-11	METAL CHIP	12K	5%	1/16W	R744					
	R659	1-216-825-11		2.2K	5%	1/16W	R745	1-216-833-91		10K	5%	1/16W
	R660	1-216-821-11	METAL CHIP	1K	5%	1/16W	R746	1-216-841-11		47K	5%	1/16W
	R662	1-216-821-11	METAL CHIP	1K	5%	1/16W	R747	1-216-833-91	RES, CHIP	10K	5%	1/16W
	R665	1-216-817-11	METAL CHIP	470	5%	1/16W	R748	1-216-833-91	RES, CHIP	10K	5%	1/16W
	R666	1-216-864-11	METAL CHIP	0	5%	1/16W	R749	1-216-833-91		10K	5%	1/16W
	R667	1-216-828-11		3.9K	5%	1/16W	R750	1-216-833-91		10K	5%	1/16W
							1					1/16W
	R668	1-216-847-11		150K	5%	1/16W	R753	1-218-332-11		130K	5%	
	R669	1-216-818-11	METAL CHIP	560	5%	1/16W	R754	1-218-332-11	RES, CHIP	130K	5%	1/16W
		,										
	R670	1-216-817-11		470	5%	1/16W	R755	1-216-833-91		10K	5%	1/16W
	R676	1-216-025-91	RES, CHIP	100	5%	1/10W	R756	1-218-293-11	RES, CHIP	24K	5%	1/16W
	R677	1-216-025-91		100	5%	1/10W	R757	1-218-293-11		24K	5%	1/16W
	R678	1-216-021-00		68	5%	1/10W	R758	1-216-833-91		10K	5%	1/16W
	R679			0	5%	1/16W	R759	1-216-841-11		47K	5%	1/16W
	DO/9	1-216-864-11	WE IAL UNIP	U	J 70	17 10 10	פפוח	1-210-041-11	WILIAL UNIT	711	. J /0	1/1044
	mcac		BAPTAL OUT	•	Fo/	4 /4 0144	D700	4 040 000 41	DEC OUR	4001	F0/	4 (4 ()) 2 (
	R680	1-216-864-11		0	5%	1/16W	R760	1-218-332-11		130K	5%	1/16W
	R681	1-216-864-11	METAL CHIP	0	5%	1/16W	R761	1-218-332-11		130K	5%	1/16W
	R682	1-216-864-11	METAL CHIP	0	5%	1/16W	R762	1-216-841-11	METAL CHIP	47K	5%	1/16W
	R683	1-216-864-11	METAL CHIP	0	5%	1/16W	R763	1-216-833-91	RES, CHIP	10K	5%	1/16W
	R684	1-216-864-11		0	5%	1/16W	R764	1-216-849-11	METAL CHIP	220K	5%	1/16W
		- • • • •							••			
	R701	1-216-833-91	RES, CHIP	10K	5%	1/16W	R765	1-216-833-91	RES, CHIP	10K	5%	1/16W
	•							•				

Ref. No	. Part No.	Description			Remark	Ref. No.	Dort No.	December	,		.
						nei. IVO.	Part No.	<u>Description</u>			<u>Remark</u>
R766			30K	0.5%	1/16W	R865	1-216-821-11	METAL CHIP	1K -	5%	1/16W
R767		1 METAL CHIP	4.3K	0.5%	1/16W	R866	1-216-864-11	METAL CHIP	0	5%	1/16W
R768		1 RES, CHIP	10K	5%	1/16W	R867	1-216-817-11	METAL CHIP	470	5%	1/16W
R769	1-216-833-9	1 RES, CHIP	10K	5%	1/16W	R868	1-216-817-11		470	5%	1/16W
										0,0	171011
R770	1-216-833-9	1 RES, CHIP	10K	5%	1/16W	R869	1-216-817-11	METAL CHIP	470	5%	1/16W
R771			10K	5%	1/16W	R870	1-216-817-11		470	5%	1/16W
R772		1 METAL CHIP	2.2K	5%	1/16W	R871	1-216-817-11		470		
R773		METAL CHIP	2.2K	5%	1/16W	R872				5%	1/16W
R774						1		METAL CHIP	470	5%	1/16W
1377-4	1-210-033-9	i neo, unir	10K	5%	1/16W	R873	1-216-817-11	METAL CHIP	470	5%	1/16W
D775	1 010 000 1	ATTAL OLUB	400	=6/							
R775			100	5%	1/16W	R874	1-216-817-11		470	5%	1/16W
R776			4.7K	5%	1/16W	R875	1-216-817-11	METAL CHIP	470	5%	1/16W
R777		METAL CHIP	4.7K	5%	1/16W	R876	1-216-817-11	METAL CHIP	470	5%	1/16W
R778	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	R877	1-216-817-11	METAL CHIP	470	5%	1/16W
R779	1-216-828-11	METAL CHIP	3.9K	5%	1/16W	R878	1-216-817-11	METAL CHIP	470	5%	1/16W
									., •	0 /0	1,71011
R780	1-216-828-11	METAL CHIP	3.9K	5%	1/16W	R879	1-216-817-11	METAL CHIP	470	5%	1/16W
R781	1-216-849-11		220K	5%	1/16W	R880	1-216-817-11				
R782			100	5%	1/16W	R881			470	5%	1/16W
R783			6.2K		1/16W	1	1-216-817-11		470	5%	1/16W
R784	1-218-290-11			5%		R882	1-216-827-11		3.3K	5%	1/16W
n/04	1-210-290-11	RES, CHIP	6.2K	5%	1/16W	R883	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
D70F	1 010 001 11	METAL OLUB									
R785		METAL CHIP	6.8K	5%	1/16W	R884	1-216-833-91	RES, CHIP	10K	5%	1/16W
R786		METAL CHIP	30K	0.5%	1/16W	R885	1-216-817-11	METAL CHIP	470	5%	1/16W
R787	1-218-862-11	METAL CHIP	4.3K	0.5%	1/16W	R886	1-216-833-91	RES, CHIP	10K	5%	1/16W
R788	1-216-831-11	METAL CHIP	6.8K	5%	1/16W	R887	1-216-817-11		470	5%	1/16W
R789	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	R888	1-216-864-11		0	5%	1/16W
						///	. 2.0 00	WEINE OIM	Ū	070	17 1044
R790	1-216-809-11	METAL CHIP	100	5%	1/16W	R889	1-216-817-11	METAL CHID	470	5%	1/16W
R791	1-216-809-11		100	5%	1/16W	R890	1-216-864-11	METAL CHIP			
R792	1-216-840-11		39K	5%	1/16W	R891			0	5%	1/16W
R793	1-216-809-11		100			į.	1-216-817-11		470	5%	1/16W
R794				5%	1/16W	R892	1-216-833-91		10K	5%	1/16W
n/94	1-216-833-91	RES, CHIP	10K	5%	1/16W	R893	1-216-864-11	METAL CHIP	0	5%	1/16W
						ł					
R795	1-216-840-11		39K	5%	1/16W	R894	1-216-833-91	RES, CHIP	10K	5%	1/16W
R796	1-216-809-11	METAL CHIP	100	5%	1/16W	R895	1-216-864-11	METAL CHIP	0	5%	1/16W
R797	1-216-821-11		1K	5%	1/16W	R896	1-216-817-11	METAL CHIP	470	5%	1/16W
R798	1-216-821-11	METAL CHIP	1K	5%	1/16W	R897	1-216-833-91		10K	5%	1/16W
R799	1-216-821-11	METAL CHIP	1K	5%	1/16W	R898	1-216-864-11	METAL CHIP	0	5%	1/16W
						11000	1 210 001 11	WIL IAL OTH	Ū	3 /0	171000
R800	1-216-813-11	METAL CHIP	220	5%	1/16W	R899	1-216-817-11	METAL CHID	470	E0/	1/16/1/
R801	1-216-813-11		220	5%	1/16W	R900				5%	1/16W
R802	1-216-813-11		220				1-216-833-91		10K	5%	1/16W
R803				5%	1/16W	R901	1-216-833-91		10K	5%	1/16W
	1-216-813-11		220	5%	1/16W	R902	1-216-864-11		0	5%	1/16W
R804	1-216-840-11	METAL CHIP	39K	5%	1/16W	R903	1-216-817-11	METAL CHIP	470	5%	1/16W
R805	1-216-840-11		39K	5%	1/16W	R904	1-216-833-91	RES, CHIP	10K	5%	1/16W
R807	1-216-864-11	METAL CHIP	- 0	5%	1/16W	R905	1-216-833-91	RES, CHIP	10K	5%	1/16W
R808	1-216-864-11	METAL CHIP	0	5%	1/16W	R906	1-216-864-11	METAL CHIP	0	5%	1/16W
R809	1-216-833-91	RES, CHIP	10K	5%	1/16W	R907	1-216-833-91		10K	5%	1/16W
R810	1-216-833-91	RES. CHIP	10K	5%	1/16W	R908	1-216-864-11		0	5%	1/16W
		•				7.000	. 2,0 00 / 11	WE ITTE OTH	Ū	5 70	1/1044
R811	1-216-833-91	RES. CHIP	10K	5%	1/16W	R909	1-216-817-11	METAL CHID	470	E0/	4 /4 (344
R812	1-216-833-91		10K	5%						5%	1/16W
R813	1-216-833-91				1/16W	R910	1-216-817-11		470	5%	1/16W
			10K	5%	1/16W	R911	1-216-833-91		10K	5%	1/16W
R814	1-216-833-91		10K	5%	1/16W	R912	1-216-817-11		470	5%	1/16W
R815	1-216-864-11	METAL CHIP	0	5%	1/16W	R913	1-216-833-91	RES, CHIP	10K	5%	1/16W
R832	1-216-801-11		22	5%	1/16W	R914	1-216-841-11	METAL CHIP	47K	5%	1/16W
R855	1-216-841-11	METAL CHIP	47K	5%	1/16W	R915	1-216-817-11		470	5%	1/16W
R856	1-216-817-11		470	5%	1/16W	R916	1-216-833-91		10K	5%	1/16W
R857	1-216-841-11		47K	5%	1/16W	R917	1-216-817-11		470	5% 5%	1/16W
R858	1-216-833-91		10K	5%	1/16W	R918	1-216-833-91		10K		
		,		Ų /U	1,71044	11310	1-210-000-01	ILO, UIIIF	IUN	5%	1/16W
R859	1-216-833-91	BEG UNID	10K	E0/	1/1/01/1/	D040	1 010 015 11	METAL OUT	40011	5 0.	4.44
R860				5%	1/16W	R919	1-216-845-11		100K	5%	1/16W
	1-216-833-91		10K	5%	1/16W	R920	1-216-841-11		47K	5%	1/16W
R861	1-216-833-91		10K	5%	1/16W	R921	1-216-817-11		470 ·	5%	1/16W
R862	1-216-829-11		4.7K	5%	1/16W	R922	1-216-833-91		10K	5%	1/16W
R863	1-216-817-11	METAL CHIP	470	5%	1/16W	R923	1-216-841-11	METAL CHIP	47K	5%	1/16W
_											
R864	1-216-817-11	METAL CHIP	470	5%	1/16W	R924	1-216-833-91	RES, CHIP	10K	5%	1/16W
								-		•	

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			<u>Remark</u>
R927	1-216-817-11	METAL CHIP	470	5%	1/16W	R997	1-216-817-11	METAL CHIP	470	5%	1/16W
R928	1-216-864-11		0	5%	1/16W	R998	1-216-864-11	METAL CHIP	0	5%	1/16W
R930	1-216-864-11		Ö	5%	1/16W	R999	1-216-864-11		Ō	5%	1/16W
R931	1-216-864-11		Ŏ.	5%	1/16W	R1001	1-216-817-11		470	5%	1/16W
			_			R1002	1-216-817-11		470	5%	1/16W
R932	1-216-864-11	METAL CHIP	0	5%	1/16W						
R933	1-216-864-11	METAL CHIP	0	5%	1/16W	R1003	1-216-817-11	METAL CHIP	470	5%	1/16W
R934	1-216-864-11		0	5%	1/16W	R1004	1-216-801-11		22	5%	1/16W
R935	1-216-864-11		0	5%	1/16W	R1005	1-216-817-11		470	5%	1/16W
R936	1-216-864-11	METAL CHIP	0	5%	1/16W	R1027	1-216-817-11		470	5%	1/16W
			_			R1028	1-216-817-11	METAL CHIP	470	5%	1/16W
R937	1-216-864-11		0	5%	1/16W	D4000	4 040 007 00	METAL OLUB	400	Fo.	4./4.038/
R938	1-216-864-11		0	5%	1/16W	R1029	1-216-027-00		120	5%	1/10W 1/10W
R940	1-216-864-11		0	5% 5%	1/16W 1/16W	R1030 R1031	1-216-025-91 1-216-166-00		100 47	5% 5%	1/10W
R941	1-216-821-11 1-216-844-11		1K 82K	5% 5%	1/16W	R1031	1-216-166-00		47	5%	1/8W
R942	1-210-044-11	WE TAL CHIP	02N	376	1/1044	R1032	1-216-864-11		0	5%	1/16W
R943	1-216-841-11	METAL CHID	47K	5%	1/16W	111000	1-210-004-11	MILIAL OTT	U	0 /0	171011
R944	1-216-853-11		470K	5%	1/16W	R1034	1-216-850-11	METAL CHIP	270K	5%	1/16W
R946	1-216-826-11		2.7K	5%	1/16W	R1035	1-216-845-11	METAL CHIP	100K	5%	1/16W
R948	1-216-170-00		68	5%	1/8W	R1036	1-216-829-11		4.7K	5%	1/16W
R949	1-216-170-00		68	5%	1/8W						
	. 210 00	.,		-,-	.,			< VARIABLE RES	SISTOR >		
R950	1-216-833-91	RES, CHIP	10K	5%	1/16W						
R951	1-216-037-00		330	5%	1/10W	RV201	1-238-853-11	RES, ADJ, CERN	/IET 1K (C (GAIN)	
R952	1-216-170-00	RES, CHIP	68	5%	1/8W	RV202	1-238-853-11	RES, ADJ, CERN	/IET 1K (AG	iC)	
R953	1-216-170-00	RES, CHIP	68	5%	1/8W	RV203	1-238-853-11				
R955	1-216-170-00	RES, CHIP	68	5%	1/8W	RV204	1-238-852-11	RES, ADJ, CERN			
						RV205	1-238-852-11	RES, ADJ, CERN	/IET 470 (R	EC Y LEV	(EL)
R956	1-216-170-00	•	68	5%	1/8W						
R957	1-216-061-00		3.3K	5%	1/10W	RV206	1-238-852-11				
R958	1-216-801-11		22	5%	1/16W	RV207	1-238-855-11				
R959	1-218-867-11		6.8K	0.5%	1/16W	RV401	1-238-853-11				
R960	1-218-871-11	METAL CHIP	10K	0.5%	1/16W	RV402	1-238-853-11	RES, ADJ, CERN	IEI IK (PB		SR-20MDP)
R961	1-216-864-11	METAL CHID	0	5%	1/16W	RV404	1-238-853-11	RES, ADJ, CERN	AET 1K /EE	,	,
R962	1-216-817-11		470	5%	1/16W	1117404	1-200-000-11	TILO, ADO, OLITA	111 (LL	O LLVLL	1
R963	1-216-833-91		10K	5%	1/16W	RV406	1-238-853-11	RES, ADJ, CERN	AFT 1K (PR	C LEVEL	`
R964	1-216-864-11		0	5%	1/16W	110100	1 200 000 11	1120, 1120, 02111		0 22122	7
7,007	. 2.0 00		•		R-20MDP)			< TEST PIN >		-	
R965	1-216-817-11	METAL CHIP	470	5%`	1/16W [^]						
						TP201	1-535-757-11	CHIP, CHECKER			
R966	1-216-864-11	METAL CHIP	0	5%	1/16W	TP401	1-535-757-11	CHIP, CHECKER			
R967	1-216-864-11	METAL CHIP	0	5%	1/16W	TP859	1-535-757-11	CHIP, CHECKER			
R968	1-216-833-91	RES, CHIP	10K	5%	1/16W	TP860	1-535-757-11	CHIP, CHECKER			
R969	1-216-817-11		470	5%	1/16W						
R970	1-216-864-11	METAL CHIP	0	5%	1/16W			< VIBRATOR >			
D070	1 010 005 11	MATTAL OLUD	77	F0/	4 (4 (3) 8)	VOC4	4 570 405 44	VIDDATOD OFD	ABAIC (084)	1-1	
R972	1-216-805-11		47	5%	1/16W	X051		VIBRATOR, CER VIBRATOR, CER			
R973	1-216-841-11		47K	5%	1/16W	X052					U-1\
R974 R975	1-216-841-11 1-216-841-11		47K 47K	5% 5%	1/16W 1/16W	X201	1-018-130-21	VIBRATOR, CRY	UIML (14.3		DSR-20MD)
R976	1-216-817-11		470	5% 5%	1/16W	X201	1_570_780_91	VIBRATOR, CRY	STAL /17.7		
N910	1-210-017-11	WIETAL OTHE	470	3 70	1/1000	, A201	1-373-700-21	VIDITATOR, OTT	OINE (II.I		SR-20MDP)
R977	1-216-154-00	RES CHIP	15	5%	1/8W	X401	1-577-165-11	VIBLATOR, CERA	AMIC (500))
R978	1-216-154-00		15	5%	1/8W	"	1 077 100 11	VIDEAL ON, CEN			
R979	1-216-844-11		82K	5%	1/16W	X402	1-567-900-11	OSCILLATOR, CI	RYSTAL (14	4.31818N	ЛHz)
R980	1-216-841-11		47K	5%	1/16W				· · · · · · · · · · · · · · · · · · ·		SR-20MD)
R981	1-216-841-11		47K	5%	1/16W	X402	1-567-733-11	VIBRATOR, CRY	STAL (17.7	•	,
				7,7					,		SR-20MDP)
R982	1-219-570-11	RES, CHIP	10M	5%	1/16W	X403	1-579-738-21	VIBRATOR, CRY	STAL (14.3	•	
R985	1-216-837-11	METAL CHIP	22K	5%	1/16W				•	(£	SR-20MD)
R986	1-216-833-91		10K	5%	1/16W	X403	1-579-780-21	VIBRATOR, CRY	STAL (17.7		
R988	1-216-817-11	METAL CHIP	470	5%	1/16W					•	R-20MDP)
R989	1-216-864-11	METAL CHIP	0	5%	1/16W	X601	1-579-466-11	VIBRATOR, CRY	STAL (3.57		•
		a amina a	4		4 14 0011					([SR-20MD)
R992	1-216-817-11		470	5%	1/16W	Vood	4 E70 004 04	OCCULATOR OF	OVETAL /4	4000405	#L1~\
R993	1-216-845-11		100K	5%	1/16W	X601	1-5/9-661-21	OSCILLATOR, CI	110 IAL (4.		
R994	1-216-817-11 1-216-833-91		470 10K	5% 5%	1/16W 1/16W	X651	1-567-000-11	OSCILLATOR, CI	RVSTAL (1)		SR-20MDP)
R995 R996	1-216-833-91		470	5% 5%	1/16W	Λου Ι	1-201-200-11	JUDILLATUR, UI	HOIME (14		SR-20MD)
ספפח	1-210-01/-11	WILLIAL UTIL	7/0	J /0	1/1044	1				15	יסוני בטועוטן

Ref. No.	Part No.	<u>Description</u> Remark
X651	1-567-733-11	VIBRATOR, CRYSTAL (17.734475MHz)
		(DSR-20MDP)
X652	1-577-165-11	VIBLATOR, CERAMIC (500kHz)
X851	1-767-450-11	VIBRATOR, CERAMIC (20MHz)
X852	1-760-458-21	VIBRATOR, CRYSTAL (32.768kHz)
X853		VIBRATOR, CRYSTAL (32.768kHz)

MISCELLANEOUS

55 56	1-782-823-11 1-782-825-11	CABLE, FLAT (FVH-4) CABLE, FLAT (FVF-8)
57	1-782-824-11	CABLE, FLAT (FVJ-7)
 ∆ 58	1-468-441-11	POWER BLOCK (U-1/U-2) (DSR-20MD)
 ∆ 58	1-468-442-11	POWER BLOCK (U-1/U-2) (DSR-20MDP)
60	1-782-822-11	CABLE, FLAT (FVR-9)
62	1-782-826-11	CABLE, FLAT (FVR-10)
65	1-958-841-11	HARNESS (DP-73)
∆67	1-958-585-11	HARNESS (AC-227)
68	1-958-059-11	HARNESS (VP-72)
101	1-776-148-11	CABLE, FLAT (FCM-11) 15P
102	1-776-145-11	CABLE, FLAT (FCM-8) 16P
105	1-764-137-11	CONNECTOR, TRANSLATION 15P
113	1-958-288-11	HARNESS (CM-130)
114	1-776-151-11	CABLE, FLAT (FCM-12) 14P
115	1-776-147-11	CABLE, FLAT (FCM-10) 15P
116	1-776-146-11	CABLE, FLAT (FCM-9) 9P
117	1-958-057-11	HARNESS (CP-79)
118	1-958-061-11	HARNESS (VJ-103)
119	1-958-058-11	HARNESS (JP-55)
120	1-958-060-11	HARNESS (VJ-102)
121	1-543-793-11	FILTER, CLAMP (FERRITE CORE)
755	A-7044-015-A	,
851	1-658-990-11	FP-406 FLEXIBLE BOARD
CN901	1-770-312-21	CONNECTOR 4P
J901	1-564-603-41	CONNECTOR (WITH DC SW) 4P
M901	X-3944-897-2	FPC ASSY, MOTOR
M902	8-835-545-01	MOTOR, DC SCD11A/J-N (CAPSTAN)
M903	X-3945-784-1	MOTOR ASSY, LM (LOADING)
M904	8-835-537-01	MOTOR, DC SRD11A/J-N (REEL)
M905	1-698-534-31	FAN, DC
S001	1-762-550-11	SWITCH, ROTARY (MODE)
S901	1-762-551-11	SWITCH, PUSH (REC PROOF)
S902	1-572-288-11	SWITCH, PUSH (C IN SW)

Ref. No.	Part No.	Description	Remark
*		ACCESSORIES	

	1_475_603_11	REMOTE COMMANDER (RMT-DS20)	
Δ	1-559-945-11	CORD, POWER (DSR-20MD)	
Δ.	1-551-631-22	•	
	3-867-983-11	MANUAL, INSTRUCTION (ENGLISH, F	RENCH)
· I	3-867-983-21	MANUAL, INSTRUCTION (GERMAN, IT	(ALIAN)
		(DSR	-20MDP)

HARDWARE LIST

#1	7-685-533-19	SCREW +BTP 2.6X6 TYPE2 N-S
#2	7-682-552-09	SCREW +P 3X16
#3	7-682-547-09	SCREW +B 3X6
#4	7-685-132-19	SCREW +P 2.6X5 TYPE2 NON-SLIT
#5	7-682-147-01	SCREW +P 3X6
#6	7-628-253-20	SCREW +PS 2X6
#7	7-682-646-09	SCREW +PS 3X5
#8	7-628-253-00	SCREW +PS 2X4
#9	7-627-553-37	SCREW (M2X3), SPECIAL HEAD
#10	7-685-871-01	SCREW +BVTT 3X6 (S TIGHT)

DSR-20MD/20MDP

SONY

SERVICE MANUAL

US Model
Canadian Model
DSR-20MD
AEP Model
Australian Model
New Zealand Model
DSR-20MDP

SUPPLEMENT-1

File this supplement with the service manual.

Addition of specifications.

SPECIFICATIONS

Medical Specifications

Protection against electric shock:

Class I

Protection against harmful ingress of water:

Ordinary

Degree of safety in the presence of flammable

anesthetics or oxygen:

Not suitable for use in the presence of flammable anesthetics or oxygen

Mode of operation:

Continuous